# Robostar Robot Controller Manual

# **ROBOSTAR ROBOT**

# RCS-8000 Series USER MANUAL

- ▼ RCS8000 MANUAL
- ☐ OPTION MANUAL
- ☐ UNI-HOST MANUAL







# **About Product Warranty**

Products of Robostar Co., Ltd. are manufactured under the strict quality control. All the Robostar products' warranty period is one year from the date of manufacture. During this period, Robostar is only responsible for the mechanical failures due to negligence of Robostar, or the problems on design and manufacture occurring during normal use, in which the service is free of charge. However, the service is not free of charge service in the following cases:

- (1) after the warranty period has expired
- (2) failures arising due to improper repair, alteration, redeployment, or other mishandling, under the instruction of you or any third party
- (3) failures as a result of using parts, grease, etc. which have not been designated by Robostar
- (4) failures caused by accidents, such as fire, disaster, earthquake, storms, or other natural disasters
- (5) failures caused in manure, flooding, or other environment
- (6) failures caused by the consumption of consumable parts
- (7) failures arising when not being operated under the instructions listed in the user or instruction manual and the maintenance manual
- (8) damages in cost other than the cost of robot repairing

# Address and contact points of Robostar Robostar Co., Ltd.

- Head Office & Factory
   119-38, Sasa-dong, Sangnok-gu,
   Ansan-City, Gyeonggi-do, Republic of
   Korea (426-220)
- 2<sup>nd</sup> Factory
   960, Gosaek-dong, Gwonseon-gu,
   Suwon-City, Gyeonggi-do, Republic of
   Korea (441-813)
- Request for service and Inquiry of products
  - Information on Marketing TEL. 031-400-3600
     FAX. 031-419-4249
  - Customer Service TEL. 1588-4428



www.robostar.co.kr



# For Safe Use

# 1. Safety for Robot (Generals)

Be sure to fully understand the manuals for safe use of this product. Each manual includes the following notations for subjects requiring carefulness necessary for the safe use of this product, and therefore carefully read the manual before using this product.

# ■ Safety Sings

Sign	Meaning			
DANGER	This sign indicates that, if handled incorrectly, the serious life or property damage may be caused.			
WARNING	This sign indicates that, if handled incorrectly, the product failure, malfunction or accident may arise.			
CAUTION	This sign indicates that the product may malfunction or may not work due to incorrect use, and shows a matter requiring attention.			
PROHIBITION	This sign shows the matter that is to be prohibited for normal use of the product.  E.g.) Never use a fire.			
Required	This sign shows the matter that must be performed for normal use of the product.  E.g.) Compulsory ground is required.			



Since this robot and robot controller are industrial equipments manufactured with advanced technology, please be sure to observe the following matters in order to prepare for accidents that may occur.



For safer and more efficient use, please operate the robot after reading all the documentations.





All of the load and power must be used within the range of rated load and power spec. In particular, make sure before use that the input power is AC 220V.






When installed, the robot must be securely fixed so as not to be shaken.





For safe operation, a safety net must be installed around the robot.







Make sure to check the wirings of a controller before powering on it.

Due to the incorrect wirings, the machine may not work properly.





To prevent electrical shock, be sure to install FG. (Frame Ground)





DANGER

Be careful not to enter into the range of motion of a robot while the robot is operating or in the operable state.

Please note such subject even if the robot is in stationary state.





If many people work at the same time, especially in powering ON/OFF and driving a motor manually, be sure to check the mutual safety before starting the work.





When in maintenance of the robot, be sure to unplug a power cord of the controller.





# **Constitution of User Manual**

The user manual for this product is constituted as follows. When using this product first, please fully read all the manuals before use

#### **■** RCS8000 MANUAL

- General contents on the controller are described. Outline, installation and interfacing method with external devices of the controller are explained.
- Along with general method of using the controller, parameter setting, JOB program editing and the robot driving are explained.
   RRL (Robostar Robot Language), which is a robot program of Robostar and how to prepare the robot program by RRL are explained.
- Gain setting method and responsibility according to change of gain value needed at the time of startup is explained.
- Causes and actions for the alarm status which may occur during the controller operation are explained.

#### ■ Option MANUAL

 Overall contents for CC-Link, Profibus and Device Net which are options of the controller are explained.

#### **■ UNIHOST MANUAL**

- 'Uni-host', which is an online PC program of Robostar is explained.



# Contents

СН.1	FUN	CTION AND CONFIGURATION	1-1
1.1	SUMM	MARY	1-1
1.2	PROD	UCT CODE	1-2
1.3	NAME	EPLATE CONFIGURATION	1-3
1.4	SPECI	IFICATIONS	1-4
1.4	.1	General Specifications	1-4
1.5	Name	es of Each Unit	1-6
1.5	.1	Controller	1-6
1.5	.2	TEACH PENDANT	1-7
	1.5.2.1	External Look	1-7
	1.5.2.2	Screen Configuration	1-7
СН.2	INST	ALLING METHOD OF CONTROLLER	2-1
2.1	GETT	ING PROPER INSTALLATION ENVIRONMENT	2-1
2.1	.1	Conditions for Installation Environment	2-1
2.1	.2	Ambient Temperature and Humidity	2-1
2.2	INSTA	ALLATION CONTROLLER	2-2
СН.3	WIR	ING AND INTERFACE	3-1
3.1	Func	TION BLOCK DIAGRAM	3-1
3.2	ELEC	TRIC WIRING	3-2
3.3	INPUT	T/OUTPUT CIRCUIT DIAGRAM FOR USER I/O	3-3
3.3	.1	NPN TYPE	3-3
3.3	.2	PNP TYPE	3-4
3.4	Powe	ER SUPPLY SYSTEM INTERFACE	3-5
3.5	SERVO	O MOTOR ENCODER OUTPUT	3-7
3.6	SERIA	AL INTERFACE	3-8
3.7	I/O IN	VTERFACE	3-9
3.8	Enco	DER INTERFACE	3-10
3.9	MPG	AND BRAKE CONNECTION	3-11
3.10	I/O R	ELAY TERMINAL BLOCK AND RELAY CABLE	3-12



3	3.10.1 I/O Relay Terminal Bloack (NPN Type)		3-12
3.	10.2	I/O Relay Terminal Block (PNP Type)	3-13
3.	10.3	Wiring Method	3-14
СН.4	HOV	W TO CONTROL CONTROLLER	4-1
4.1	MEN	NU Configuration	4-1
4.2	PARA	A(PARAMETER)	4-2
4.2	2.1	Shift to Parameter Menu	4-2
4.2	2.2	Parameter Configuration and Value Change	4-3
4.3	ORG	G(ORIGIN)	4-5
4	3.1	ORIGIN Operation	4-5
4.3	3.2	Run ORIGIN and check out Z-phase (INC serial encoder)	4-6
4	3.3	Run ABS Encoder ORIGIN	4-7
4.3	3.4	ORIGIN Fail	4-11
4.4	PRO	G (PROGRAM)	4-12
4.4	4.1	Command	4-12
	4.4.1.1 Operating Command		4-12
	4.4.1.2	Control Command	4-13
4.4	4.2	Write New Program	4-14
4.4	4.3	Edit Program	4-16
	4.4.3.1	View Written Program	4-16
	4.4.3.2	Insert Program	4-17
4.4	4.4	Save Program	4-18
4.4	4.5	Copy Program	4-19
4.4	4.6	Delete Program	4-20
4.4	4.7	How to Set and Save Program Block	4-21
	4.4.7.1	Copying Multi-row Command	4-21
	4.4.7.2	Copying Single-row Command	4-23
	4.4.7.3	Copying Job using READ, WRITE	4-25
	4.4.7.4	Copying Job using JMP	4-27
	4.4.7.5	Deleting Command from Job Program	4-30
	4.4.7.6	How to Move within Written Job Program	4-31
	4.4.7.7	How to Save Written Program	
4.5	POSI	ITION TEACHING	
4.5	5.1	Manual Data Input (MDI) Teaching	
4.5	5.2	JOG Teaching	
		-	



4.3	5.3	Inching Jog Teaching	4-39
4	5.4	Forward(FWRD) Teaching	4-42
4.6	RUN	I (ROBOT PROGRAM)	4-44
4.0	6.1	How to Select Robot Program to Run	4-44
4.0	6.2	How to Implement AUTO RUN	4-46
4.0	6.3	How to Implement STEP RUN	4-48
4.0	6.4	How to Convert STEP RUN to AUTO RUN	4-50
4.0	6.5	Initialize Robot Program Step	4-51
4.0	6.6	Run from Stopped Step	4-52
4.7	PLC.		4-53
4.7	7.1	Select PLC Program	4-53
4.7	7.2	Run PLC Program	4-55
4.7	7.4	Check out I/O Connection	4-57
	4.7.4.1	Check out Input/Output Contact Status and TEST Method	4-57
4.8	VIEV	W	4-58
4.8	8.1	How to Check out Alarm Message	4-58
4.8	8.2	Alarm History	4-59
4.8	8.3	INT(INTEGER) Variable	4-1
СН.5	PAR	AMETER SETTINGS	5-2
	1111		_
5.1	OVER	RVIEW	5-2
5.2	PARA	AMETER TYPES	5-3
5.3	How	TO SET PARAMETERS	5-4
5	3.1	How to Set SERVO-related Parameters	5-4
	5.3.1.1	AMP / MOT	5-4
	5.3.1.2	GAIN	5-9
	5.3.1.3	PROT	5-11
5	3.2	How to Set Mechanism (MECH) related Parameters	5-14
5	3.3	How to Set Operation(OPER) related Parameters	5-18
	5.3.3.1	MODE	5-18
	5.3.3.2	JOG	5-29
	5.3.3.3	DFT	5-30
5	3.4	SET	5-33
	5.3.4.1	COM	5-33
	5.3.4.2	ETC	5-34
	5.3.4.3	IP	5-39



5	5.3.5 How to Set Input/Output(I/O) related Parameters		5-40
	5.3.5.1 How to Set System Input Contact		5-40
	5.3.5.2	How to Set System Output Contact	5-44
СН.6	INPU	UT/OUTPUT(I/O) CONNECTION	6-1
6.1	I/O D	DESCRIPTION	6-1
6.	1.1	Port Structure	6-1
6.	1.2	Contact point description	6-2
6.	1.3	Signal Format in Connecting Input/Output(I/O) Connectors	6-4
СН.7	VIEV	W SETTING	7-1
7.1	OVE	RVIEW	7-1
7.2	SERV	VO STATUS	7-2
СН.8	WRI	TTING JOB PROGRAM	8-1
8.1	OVE	RVIEW OF JOB PROGRAM WRITING	8-1
8.	1.1	Robot Commands (Reference in Program Input)	8-2
8.2	WRIT	TING NEW JOB PROGRAM USING EXAMPLES	8-3
8	2.1	Description of Program Operation	8-3
8	2.2	Job Program Writing	
	8.2.2.1	How to Handle Teach Pendant for Writing Job Program	8-4
СН.9	DES	CRIPTION OF ROBOT COMMANDS	9-1
9.1	Сом	MANDS FOR OPERATING CONDITIONS	9-1
9.	1.1	SERVO	9-2
9.	1.2	ALARM	9-3
9.	1.3	SPD (SPEED)	9-4
9.	1.4	PCLR (POSITION CLEAR)	9-5
9.	1.5	ACC (ACCELERATION), DEC (DECELERATION)	9-6
9.	1.6	FOS	9-8
9.2	OPER	RATING COMMANDS	9-10
9	2.1	MOVA	9-11
9	2.2	MOVI	9-12
9.	2.3	REF, MOVR	9-13



9.2	.4	MOVT	9-15
9.3	VARIA	BLE PROCESSING COMMAND	9-16
9.3	.1	I, P	9-16
9.4	INPUT	OUTPUT PROCESSING COMMAND	9-18
9.4	.1	B, BB	9-18
9.5	Progl	RAM CONTROL COMMAND	9-19
9.5	.1	STOP	9-20
9.5	.2	<i>IF</i>	9-21
9.5	.3	XIF	9-23
9.5	.4	WAIT	9-24
9.5	.5	CALL, SBRT, RET	9-25
9.5	.6	GOTO, LBL	9-26
9.5	.7	LOOP, ENDL	9-27
9.5	.8	JPGM	9-28
9.5	.9	PEND	9-29
СН.10	EXA	MPLES FOR ROBOT PROGRAM	10-1
10.1	Loca	TION MOVEMENT PROGRAM AT REGULAR INTERVALS	10-1
10.1		FION MOVEMENT PROGRAM USING CONTACT	
10.3		MENT PROGRAM AT INFINITELY CONSTANT SPEED	
10.4		ET RUN PROGRAM	
10.5		IPLE RUN PROGRAM	
10.6		E PICK & PLACE SYSTEMS WITH PALLETIZER FUNCTION	
СН.11	RUN	NING ROBOT PROGRAM AND PLC PROGRAM	11-8
11.1	Use o	F I/O CONTACT	11-8
11.	1.1	Operating Contact in JOG Operation	11-8
1	1.1.1.1	Operation Timing Diagram in JOG Operation	11-9
11.	1.2	ORIGIN Operation Using External Contact (In using absolute value encoder)	11-10
1	1.1.2.1	Operating Contact in ORIGIN Operation	11-10
1	1.1.2.2	Operation Timing Diagram in ORIGIN Operation	11-10
11.	1.3	Robot Program Operation Using External Contact	
	1.1.3.1	Operating Contact in Robot Program Operation	
	1.1.3.2	Operation Timing Diagram in Putting Program in AUTO RUN	
	1.1.3.3	Operation Timing Diagram in Putting Program in STEP RUN	



CH.12	DESCRIPTION OF PLC COMMAND	12-1
12.1	LOGICAL OPERATION COMMAND	12-1
12.2	CONTACT INPUT/OUTPUT COMMAND	12-1
12.3	RELATION COMMAND	12-2
СН.13	ALARM	13-1
13.1	ALARM LIST	13-1
13.	1.1 Over Current (E01.00~E01.02)	13-1
13.	1.2 Over Load (E02.00)	13-1
13.	1.3 Over Voltage (E03.00 ~ E03.01)	13-1
13.	1.4 Power Fail (E05.00 ~ E05.01)	13-1
13.	1.5 Data Back-up Error (E06.00)	13-1
13.	1.6 Encoder Error (E07.00 ~ E07.13)	13-2
13.	1.7 H/W Limit (E08.00 ~ E08.01)	13-2
13.	1.8 S/W Limit (E09.00 ~ E09.03)	13-2
13.	1.9 Following Error (E10.00)	13-2
13.	1.10 Program Error (E11.00 ~ E11.04, E11.50 ~ E11.51)	13-3
13.	1.11 Emergency Stop (E12.00 ~ E12.03)	13-3
13.	1.12 Over Speed (E13.00 ~ E13.02)	13-3
13.	1.13 Program Error (E14.00 ~ E14.04)	13-3
13.	1.14 Software Alarm (E15.00)	13-3
13.	1.15 JOB (E20.00 ~ E20.19)	13-4
13.	1.16 JOB Command (E20.50~20.99)	13-5
13.	1.17 PLC (E21.00 ~ E21.13)	13-5
13.	1.18 ETC (E22.00 ~ 22.20)	13-6
13.	1.19 Alarm End Code (E99.98 ~ E99.99)	13-6
13.2	ALARM SCENE AND TROUBLESHOOTING (ALARM CODE DESCRIPTION)	13-7
13	2.1 Over Current (E01.00 ~ E01.02)	13-7
13	2.2 Over Load (E02.00)	13-9
13	2.3 Over Voltage (E03.00 ~ E03.01)	13-10
13	2.4 Power Fail (E05.00 ~ E05.01)	13-11
13		
13		
13	2.7 H/W Limit (E08.00 ~ E08.01)	13-18
13		



13	2.9 Following Error (E10.00)	13-21
13	2.10 Program Error (E11.00 ~ E11.04, E11.50 ~ E11.51)	13-21
13	2.11 Emergency Stop (E12.00 ~ E12.03)	13-23
13	2.12 Over Speed (E13.00 ~ E13.02)	13-25
13	2.13 Parameter Error (E14.00 ~ E14.04)	13-26
13	2.14 Software Alarm (E15.00)	13-27
13.3	WARNING CODE SCENE AND TROUBLESHOOTING (ALARM CODE DESCRIPTION)	13-28
13	3.1 JOB (E20.00 ~ E20.24)	13-28
13	3.2 JOB Command (E20.50~20.99)	13-36
13	3.3 PLC (E21.00 ~ E21.13)	13-42
13	3.4 ETC (E22.00 ~ 22.20)	13-46
13	3.5 Alarm End Code (E99.98 ~ E99.99)	13-53
СН.14	ABNORMAL SYMPTOM TROUBLESHOOTING	14-1
14.1	TROUBLESHOOTING FOR ABNORMAL SYMPTOMS LIKELY TO OCCUR IN JOG OPERATION	14-1
14.2	MOVE ROBOT BY JOG TO CHECK OUT OPERATING STATUS OF LIMIT SENSOR ON AXIS	
СН.15	TEACH PENDANT MENU TREE	15-1
15.1	MAIN MENU	15-1
15.2	ROBOT MENU	15-2
15.3	PLC MENU	15-3
15.4	PARAMETER MENU	15-4
15.5	VIEW MENU	15-5
СН.16	DESCRIPTION OF OPERATING MODES PER FUNCTION	16-1
16.1	INITIALIZATION SETTING MODE (HIDDEN INITIAL MODE)	16-1
СН.17	FRONT 7-SEGMENT DISPLAY	17-1
17.1	Normal Condition	17-1
17.2	ALARM OCCURRENCE	17-2
17.3	DURING ROBOT PROGRAM OPERATION	17-2
17.4	DISPLAY BY SETTING USER MODE PARAMETER	17-3
17.	Display Input Contact when User Mode Parameter is '200'	17-3
17.	1.2 Display Output Contact when User Mode Parameter is '201'	17-4



4.3 Display DC LINK Voltage when User Mode Parameter is '202'	17-4
EXTERNAL-LOOK DIMENSION DRAWING	18-1
CABLE	19-1
CONFIGURATION OF ROBOT CABLE MODEL	19-1
ROBOT CABLE TYPE	19-2
2.1 RAK1 Robot Cable (STRAIGHT/ELBOW Type)	19-3
2.2 RAK1 Robot Cable (HOUSING Type)	19-4
2.3 RCK1 Robot Cable (STRAIGHT/ELBOW Type)	
2.4 RCK1 Robot Cable (HOUSING Type)	19-6
2.5 Serial Cable (RS 232C)	19-7
PC COMMUNICATION	20-1
Protocol	20-1
CAUTIONS ON INSTALLING SERVO MOTOR	21-1
CHECK ITEM WHEN THE GOODS ARRIVES	21-1
MEASURES BEFORE THE INSTALLATION	21-1
SELECTION GOOD PLACE TO INSTALL	21-1
USE CIRCUMSTANCE	21-2
COMBINATION WITH THE OPPOSITE MACHINERY	21-2
ALLOWABLE LAOD OF BEARING	21-2
CHECK ITEM WHEN TESTING THE OPERATION	21-3
MAINTENANCE AND INSPECTIONS	21-3
PROBLEM AND MEASURES	21-4
	CABLE



## ch.1 FUNCTION AND CONFIGURATION


### 1.1 Summary

- 1) The single controller can construct the control system independently without other peripheral equipment because it is united with the single axis controller, AC servo drive and PLC function.
- 2) Besides the single operation function, the single controller can also operate the synchronous operation, the unlimited rotation operation, the determined position operation by external contact point.
- 3) Embedded PLC has contact point arithmetic, counter, and timer functions, enabling it to process several switch signals and sensors installed within the system.
- 4) This product is easily programmable due to the various program methods, and can respond to many kinds of AC servomotors according to digital control.
- 5) Enables remote operation by serial communication as well as Upload/Download of entered program and parameters.
- 6) Basic user I/O functions are user selectable through the contact point terminal.
- 7) Available for single and three-phase power source. (RCS-8008, 10, 15 : three-phase power source)
- 8) This product can be used for linear movements, rotations, conveyor systems, turret machines, and roll feeders.



#### **Product Code** 1.2

#### **RCS SERIES**



Standard(8000 excluded)


E: CE인증품


CASE만(CC-LINK B/D excluded)



# 1.3 Nameplate Configuration

The model name of this controller is specified in the attachment spot and is attached on the side of the controller as shown below. To check out the model name, refer to the product code.





	Туре	Description
1	MODEL	Controller product
	WODEL	code
2	SOURCE	Controller power
	SOURCE	capacity
3	MOTOR SPEED	Motor speed
4	WEIGHT	Controller weight
5	SER.NO	Serial number



# 1.4 Specifications

1.4.1 General Specifications

# **■** Installation Environment

	Model			R	cs		
Item		8001C	8002C	8004C	8008C	8010C	8015C
Main Voltage/Freq- Power uency		AC200V ~ 230V, 50 / 60Hz 1Φ		AC200V	AC200V ~ 230V, 50 / 60Hz 1Ф, 3Ф		
(GPS)	Watt (KVA)	0.3	0.46	0.89	1.35	1.89	2.67
Control Power	Voltage/Freq- uency	AC200V	~ 230V, 50 /	60Hz 1Ф	AC200V ~ 230V, 50 / 60Hz 1Φ		
(UPS)	Watt (W)				5		
Regene	rative Resistor	-	50Ω / 50W	50Ω / 50W	50Ω / 140W	30Ω / 400W	30Ω / 400W
Cooling Type		Natural Air C	Cooling			<u> </u>	<u></u>
Control Type		3 phase sine wave modulated PWM					
Encoder Type		Incremental Encoder, Serial Encoder					
Input-	USER	User I/O (19	points/16 po	ints)			
Output (I/O)	SYSTEM	Option I/O (	32 points/24 <sub> </sub>	ooints)			
Prog	gramming	Teach Pendant or PC (Above PC Windows XP)					
Robot	JOB	Maximum 8	pieces				
Program	JOB Step	1000Line					
Support	Position	1024 pieces					
Standard	l Integer	255 pieces					
External Communication (option)		CC-Link, Profibus, DeviceNet, C-net					
Error	Indications	Front 7-Segment, Teach Pendent					
On-Lir	ne Functions		ter, Integer, Po				



# ■ Weight per Product Model

1) Net Weight : Controller Itself

2) Gross Weight : Controller + Package

Weight	8001C, 8002C	8004C	8008C	8010C	8015C
Net (kg)	1.2	1.5	2.2	2.2	2.2
Gross (kg)	1.4	1.7	2.52+	2.52+	2.52+


# ■ Table for Adopted Motor per Controller Capacity

Size	Model	Adopted Motor	Size	Model	Adopted Motor
	RCS-8001C	50W, 100W		RCS-8008C	750W
Small	RCS-8002C	200W	Middle	RCS-8010C	1kW
	RCS-8004C	400W		RCS-8015C	1.5kW




# 1.5 Names of Each Unit

- 1.5.1 Controller
- Small Capacity (8001C, 8002C, 8004C)



■ Medium Capacity (8008C, 8010C, 8015C)




No.		Name-Application	
(1)	DC-Link Charge Display LED		
(2)	Status Dis	play 7-Segment	
(3)	L1	Main Dower Input	
(4)	L2	Main Power Input	
(5)	r	Control Dowar Input	
(6)	t	Control Power Input	
(7)	Р	Regenerative Resistor	
(8)	В	Connecting Terminal	
(9)	U		
(10)	V	Motor Connecting Terminal	
(11)	W		
(12)	FG	Ground Connecting Terminal	
(13)	CN4	Encoder Signal Output	
		Serial Connector	
(14)	CN3	Teach Pendant, PC	
		Communication	
(1E)	CN1	I/O Connector	
(15)	CIVI	Input, Output Contact	
(16)	CN2	Encoder Connector	
(16)	CINZ	Motor Encoder Communication	

No.		Name-Application
(1)	DC-Link Charge Display LED	
(2)	Status Dis	play 7-Segment
(3)	L1	
(4)	L2	Main Power Input
(5)	L3	
(6)	r	Control Power Input
(7)	t	Control Fower Input
(8)	Р	Regenerative Resistor
(9)	В	Connecting Terminal
(10)	U	
(11)	V	Motor Connecting Terminal
(12)	W	
(13)	FG	Ground Connecting Terminal
(14)	CN4	Encoder Signal Output
		Serial Connector
(15)	CN3	Teach Pendant, PC
		Communication
(16)	CN1	I/O Connector
(10)	CIVI	Input, Output Contact
(17)	CN2	Encoder Connector
(17)	CIVZ	Motor Encoder Communication
(18)	CN5	Not used.




#### 1.5.2 TEACH PENDANT

1.5.2.1 External Look



No.	Name-Application
(1)	Emergency Stop Button When the button is pressed, the controller stops its operation.
(2)	LCD Display  Communications with the controller are displayed.
(3)	Status Light  PWR – Turns ON while Teach Pendant is running  ORG – Turns ON at completion of home return  SVON – Turns on when power is applied to the  motor  ALRM – Turns on when the controller shows an abnormality
(4)	Mode Selection Button Used when selecting a mode.
(5)	Number Key Used for numeric input or selection of a direction.
(6)	ESC(Escape) 메뉴 탈출 버튼입니다.
(7)	BS(Back space) Program 작성 중 삭제 버튼
(8)	ENT(Enter) 선택 버튼

1.5.2.2 Screen Configuration



As shown in the figure, move the 4th or 8th line in Teach pendant to the corresponding menu using 'Mode Selection Button' in TP.

(Line settings in Teach Pendant can be done at 'PARA→OPER→SET→ETC'의 TP\_LINE.)



# ch.2 Installing Method of Controller

# 2.1 Getting Proper Installation Environment

#### 2.1.1 Conditions for Installation Environment

- Since the robot and the controller are not intended to be of anti-explosion, dust-proof, or drop-proof standard, they cannot be installed at the following places.
  - 1) Environment where flammable gases, flammable liquids, etc. is used
  - 2) Environment where conductive materials such as metal processed chip is scattering.
  - 3) Environments with acid or alkali corrosive gas.
  - 4) Environments with the mist such as cutting liquid or grinding liquid.
  - 5) Environments with the mist such as cutting liquid or grinding liquid containing the oil component.
  - 6) Environment close to the electrical noise sources, such as a large inverter, high-power frequency oscillator, a large conductor, welding machine, etc.
  - 7) Do not attach the magnet to the controller.

#### 2.1.2 Ambient Temperature and Humidity

Environment	Condition
Ambient temperature for use	0°C ~ 40°C (No freeze formed)
Ambient humidity for use	20 ~ 80% RH 이하 (No dew formed)
Ambient temperature for storage	-15℃ ~ +60℃ RH (No dew formed)
Ambient humidity for storage	10 ~ 90% RH (No dew formed)
Room Condition	No dust or corrosive Gas
Vibration	0.6G



> When a magnetic material is placed around the controller, the saved data may be damaged.




#### 2.2 Installation Controller

Prepare the enough space taking into consideration the robot cable bending, interference or the like, as shown below.

#### **■** Preparation of Installation Space

- 1) For natural cooling, gaps over 10mm for right and left sides, over 50mm for top and bottom of the controller are needed.
- 2) If more than 2 controllers are operated, make gaps over 50mm for right and left sides, over 80mm for top side, 50mm for bottom side, and 10mm between two controllers.
- 3) For spacious wiring, over 80mm for front is required.
- 4) Emission resistance of regenerative energy which is connected to the controller P-B terminal generates heat proportional to rated motor output power. So Emission resistance of regeneration energy shall be attached to the place where heat is well radiated and it shall be away over 20mm from the controller.
- 5) Installation should be done in a well ventilated place with low humidity and little dust.
- 6) Installation should be done in a place made easy for inspection and cleaning.




# **CAUTION**

- > Pay attention to internal components damage due to the shock when the controller is moved.
- > Attachment to wrong direction may cause malfunction.
- Maintain the gap between the controller and control panel inner side over specified distance.



# ch.3 WIRING AND INTERFACE


# 3.1 Function Block Diagram





# 3.2 Electric Wiring

■ SMALL (1Φ)



- All devices and components used in the devices shall have countermeasures for electromagnetic waves so that they have no malfunction by electromagnetic waves. All devices and components shall not cause electromagnetic interchange over reasonable level at the places where they are used. And they shall have tolerance of proper level against electromagnetic waves.
- If MOTOR DRIVE, INVERTER and SMPS are used, countermeasures for electromagnetic waves suggested in the manual prepared by manufacturer shall be applied.
- Make sure that a ground wire shall be connected at one point of the terminal block.
- If additional countermeasures are needed depending on electromagnetic waves test results, install NOISE-FILTER in MAIN power supply. Products as follows are recommended.


Type	Model	Manufacturer
Noise Filter	ES1-F20	DONG IL(DIT)
Ring core	ESD-R-47B	KEMET



If NOISE-FILTER is used, make sure that input wires and output wires shall be separated. They shall not be in the same duct or be tied together.



#### ■ MIDDLE(1Φ)



All devices and components used in the devices shall have countermeasures for electromagnetic waves so that they have no malfunction by electromagnetic waves. All devices and components shall not cause electromagnetic interchange over reasonable level at the places where they are used. And they shall have tolerance of proper level against electromagnetic waves.

- If MOTOR DRIVE, INVERTER and SMPS are used, countermeasures for electromagnetic waves suggested in the manual prepared by manufacturer shall be applied.
- Make sure that a ground wire shall be connected at one point of the terminal block.
- If additional countermeasures are needed depending on electromagnetic waves test results, install NOISE-FILTER in MAIN power supply. Products as follows are recommended.


Туре	Model	Menufacturer
Noise Filter	WYFTH30T1A	WOONYOUNG
Ring core	ESD-R-47B	KEMET



> If NOISE-FILTER is used, make sure that input wires and output wires shall be separated. They shall not be in the same duct or be tied together.



#### ■ MIDDLE(3Φ)



- All devices and components used in the devices shall have countermeasures for electromagnetic waves so that they have no malfunction by electromagnetic waves. All devices and components shall not cause electromagnetic interchange over reasonable level at the places where they are used. And they shall have tolerance of proper level against electromagnetic waves.
- If MOTOR DRIVE, INVERTER and SMPS are used, countermeasures for electromagnetic waves suggested in the manual prepared by manufacturer shall be applied.
- Make sure that a ground wire shall be connected at one point of the terminal block.
- If additional countermeasures are needed depending on electromagnetic waves test results, install NOISE-FILTER in MAIN power supply. Products as follows are recommended.

Туре	Model	Menufacturer
Noise Filter	WYFTH30T1A	WOONYOUNG
Ring core	ESD-R-47B	KEMET




➤ If NOISE-FILTER is used, make sure that input wires and output wires shall be separated. They shall not be in the same duct or be tied together.



### 3.3 Input/Output Circuit Diagram for USER I/O

3.3.1 NPN TYPE

1) USER Input: B000 ~ B022 2) USER Output: B030 ~ B047






- Inside parenthesis represents the I/O Address.
- When wiring the power source, confirm that the connection polarity of DC 24V is correct.
- Mis-wiring may cause the internal parts to be destroyed. In particular, take extra caution about the polarity of a common terminal for P-type and N-type.
- ➤ The external supply voltage has to be DC 24V±10%.
- > When soldering connector pins, provide pins with tubes to prevent short-circuit of pins.



#### 3.3.2 PNP TYPE

1) USER Input: B000 ~ B022 2) USER Output: B030 ~ B047



# **CAUTION**

- > Inside parenthesis represents the I/O Address.
- > When wiring the power source, confirm that the connection polarity of DC 24V is correct.
- Misswiring may cause the internal parts to be destroyed. In particular, take extra caution about the polarity of a common terminal for P-type and N-type.
- ➤ The external supply voltage has to be DC 24V±10%.
- When soldering connector pins, provide pins with tubes to prevent short-circuit of pins.




# 3.4 Power supply system interface

#### ■ SMALL

: It is separated into the robot power and control power. Only single phase can be applied.

Connector on Controller Side	BR1002TL-9P-8L(BEE-RYONG)
Connector on Cable Side	Spade Terminal



PIN No	Signal
L1	Dobot Dower
L2	Robot Power
r	Control Power
t	

PIN No	Signal
Р	Do non overtivo, vocieto v
В	Regenerative resistor

PIN No	Signal
U	
V	Motor Power
W	

PIN No	Signal	
FG	Frame Ground	

- 1) Connect L1, L2 to the motor power and connect r, t to the control power.
- 2) Connect the ground(FG) of the motor on a small-capacity controller to Heat Sink FG terminal.
- 3) When used as a single power supply
  - Use after connecting motor power L1 and controlling power r.
  - Use after connecting motor power L2 and controlling power t.
- 4) AWG 14~18 is used for the wire diameter of the main power. AWG18 is used for the wire diameter of control power.

# ? CAUTION


- ➤ 'E0501 Open DCLink' alarm occurs if the motor is driven after supplying power only to controlling power.
- ➤ Power is not supplied to the main board if power is supplied only to the robot.



#### **■** MIDDLE

: It is separated into the robot power and control power, in support of 3-phase.

Connector on Controller Side	BR-1002C-11P (BEE-RYONG)
Connector on Cable Side	Spade Terminal



PIN No	Signal		
L1	Robot Power		
L2			
L3			
r	Control Power		
t			

PIN No	Signal	
Р	Regenerative resistor	
В		

PIN No	Signal
U	
V	Motor Power
W	

PIN No	Signal	
FG	Frame Ground	

- 1) When making a 3-phase connection, connect L1, L2, and L3 to main power and r, t to control power.
- 2) When making a 2-phase connection, connect L1 and L3 to main power and r, t to control power.
- 3) In using as a single power
  - Use after connecting motor power L1 and controlling power r.
  - Use after connecting motor power L3 and controlling power t.
- 4) AWG 14~18 is used for the wire diameter of the main power AWG 18 is used for the wire diameter of control power.




- > 'E0501 Open DCLink' alarm occurs if the motor is driven after supplying power only to controlling power.
- Power is not supplied to the main board if power is supplied only to the robot.



# 3.5 Servo Motor Encoder Output

: Encoder (A, B, Z phase) Output

Connector on Controller Side	PCB-01(G-Type), 4P, PHONE
Connector on Cable Side	RJ11-4C



PIN No	MPG Signal	Function
1	А	Produces encoder phase A signal
2	В	Produces encoder phase B signal
3	Z	Produces encoder phase Z signal
4	GND	Connects GND


- Applicable only when using a 9-wire or 15-wire incremental encoder.
- Encoder output signal is Low output : 0V / High output : 5V.
- The signal is an uninsulated output so use caution not to make mis-wiring when connecting signals.



#### 3.6 Serial Interface

: This interface is for serial connection.

Connector on Controller Side	HIF3H-10PB-2.54DSA (HRS)
Connector on Cable Side	DSUB SOLD 15S



PIN	Teach	Serial	
No.	Pendant	Communication	Description
	Connection	Connection	
1	+12V	-	+12V control power output
2	RxD	RxD	COM1 Port RxD signal input
3	TxD	TxD	COM1 Port TxD signal output
4	-12V		- 12V control power output
5	GND	GND	Control power ground output
6	EMG	_	Emergency stop switch signal input
7	Deadman Key	-	Deadman switch signal input
8	-	-	Not used
9	-	RxD2	COM2 Port RxD signal input
10	-	TxD2	COM2 Port TxD signal output
11	FG	FG	Connect main power ground
12	-	RS-422 RX+	RS-422 communication port
13	-	RS-422 RX-	RS-422 communication port
14	-	RS-422 TX+	RS-422 communication port
15	-	RS-422 TX-	RS-422 communication port

- Teaching Pendant communicates with COM1 using RxD and TxD signals.
- Communicates with COM2 using RxD2 and Txd2.
- It is possible to communicate simultaneously using COM1 and COM2.
- It is possible to connect to the online using COM1 and COM2.
- The robot can be operated automatically with a host computer and serial(RS-232C) communication.


(Refer to 'Uni-host user's manual' for more detail.)



# 3.7 I/O Interface

:This interface is for I/O connection.

Connector on Controller Side	N10250-52E2PC (3M)
Connector on Cable Side	HIF3BA-50D-2.54 R(HRS)



USER INPUT: B000 ~ B022
 USER OUTPUT: B030 ~ B047

3) EMG INPUT: EMG+, EMG-

4) Brake OUTPUT (Relay connection): BRAKE+, BRAKE-

Pin	Signal		Description
1	GND(5V)		MPG signal input ground
2	/APH OUT		MPG /Input phase A
3	/BPH	_OUT	MPG /Input phase B
4	В0	35	User output
5	В0	32	User output
6	В0	31	User output
7	В0	41	User output
8	В0	40	User output
9	В0	45	User output
10	В0	44	User output
11	В0	47	User output
12	NPN type	GND(24V)	Output port control power (- )
12	PNP type	24V	Output port control power (+)
13	В0	04	User input
14	В0	05	User input
15	В0	06	User input
16	В0	07	User input
17	NPN type	24V	Input port control power (+)
	PNP type	GND(24V)	Input port control power (-)
18	В0	14	User input
19	B012		User input
20	B016		User input
21	B010		User input
22	B020		User input
23	B021		User input
24	EMG-		Emergency stop switch input(-)
25	EMG+		Emergency stop switch input (+)


Pin	Signal Name		Description	
26	APH_OUT		MPG input phase A	
27	BPH_OUT		MPG input phase B	
28	B037		User output	
29	B036		User output	
30	B034		User output	
31	B030		User output	
32	NPN type	GND(24V)	Output port control power (-)	
	PNP type	24V	Output port control power (+)	
33	B033		USER Output	
34	B042		USER Output	
35	B043		USER Output	
36	B046		USER Output	
37	FG		FG ground terminal(Shield)	
38	B003		User input	
39	B002		User input	
40	B001		User input	
41	B000		User input	
42	B013		User input	
43	B015		User input	
44	B011		User input	
45	B017		User input	
46	NPN type	24V	Input port control power (+)	
	PNP type	GND(24V)	Input port control power (-)	
47	B022		User input	
48	NPN type	24V	Input port control power (+)	
	PNP type	GND(24V)	Input port control power (-)	
49	BRAKE+		Motor brake output(+)	
50	BRAKE-		Motor brake output (-)	



#### 3.8 Encoder Interface

:This interface is for encoder connection.

Connector on Controller Side	N10220-52B2VC (3M)	
Connector on Cable Side	10320-52AO-008 (3M)	



PIN	15 signal	9 signal	Serial		
No.	type	type	type		
1	W	-	SD+		
2	/W	-	SD-		
3	V	-	-		
4	/V	-	-		
5	U	-	=		
6	/U	-	=		
7	-	-	-		
8	-	-	-		
9	GND(5V)	GND(5V)	GND(5V)		
10	-	EP5V	-		
11	/Z	/Z	-		
12	-	=	=		
13	/B	/B	-		
14	Z	Z	-		
15	/A	/A	-		
16	В	В	-		
17	-	-	-		
18	А	А	-		
19	P5V	-	P5V		
20	-	-	-		


- 15 signal type encoder, 9 signal type encoder
- The encoder signal being the electric signal of motors, the U, V, W of the motor are synchronized to this signal. When an error occurs in this signal, the motor does not rotate.
- 2) Used to detect the position of the motor and its rotation number.
- 3) Z: Used to search the origin.
- 4) P5V: Provides Vcc power to the encoder.
- Serial encoder
- 1) SD+, SD-: This is a serial response signal of 4 wire type serial encoder.
- 2) Used for position rpm detection for the motor using serial data.
- 3) It is possible to receive alarm information if the motor encoder has any problem.
- 4) P5V: Provides Vcc power to the encoder.
- 5) GND(5V): Basic electric potential for +5V and EP +5V.

3-10




#### 3.9 MPG and Brake Connection


#### 1) Standard MPG connection diagram



2) ) Brake Connection for DC 24V



#### 3) Brake Unit and Brake Connection for DC 90V






#### 3.10 I/O Relay Terminal Block and Relay Cable

3.10.1 I/O Relay Terminal Bloack (NPN Type)

■ For use of an I/O relay terminal block, a relay cable is needed.



#### ■ Contact description

- E+24V, EG24 Port:
   External power connection terminal.
- 2) +24V, G24:Terminal connecting controller's internal power.
- INPUT PCOM +24V,
   OUTPUT NCOM G24V terminal:
   External power connection
   terminal.
- Each terminal among names of relay terminal blocks is consistent with user's I/O signal name.




> The controller may be damaged when the external connection terminal and internal connection terminal are connected simultaneously.



3.10.2 I/O Relay Terminal Block (PNP Type)

■ For use of an I/O relay terminal block, a relay cable is needed.



#### **■** Contact description

- 1) Only external 24V power available for use.
- 2) Connect +24V power to PCOM1, PCOM2.
- 3) Connect G24V(GND) to NCOM1, 2, 3.
- 4) Each terminal among names of relay terminal blocks is consistent with user's I/O signal name.




The controller may be damaged when the external connection terminal and internal connection terminal are connected simultaneously.




#### 3.10.3 Wiring Method

- How to connect an I/O relay terminal block
  - 1) Contact configuration: User input B000 ~ B022, user output: B030 ~ B047
  - 2) In setting CW S/W to B020, connect sensor cable CW to where the terminal block B005 is.
  - 3) Connect +24V to PCOM1, PCOM2, and PCOM3.
  - 4) Connect GND to NCOM1, NCOM2.



■ Brake Connection for DC 24V






➤ EG24, E+24, G24, and +24V in the relay terminal block are not connected from the outside.




#### ■ Use of I/O relay terminal block

Input/output (I/O) connection can be divided into two types.

- 1. Use of an I/O relay terminal block
  - Connect PLC contacts to Input,
     Output of the relay terminal block
     and connect to the controller's I/O
     before use.



- 2. Non-use of an I/O relay terminal block
  - Connect PLC contacts directly to the controller's I/O before use.





## ch.4 How to Control Controller


## 4.1 MENU Configuration

Menu		Group	Detailed Group				
Name	Name	Description	Name		Descrip	tion	
ROBOT	PROG	Writes Robot Pro	gram				
	POS	Saving position variable and JOG					
	ORG	Origin return operation					
	RUN	Runs Robot Program					
	PROG	Writes PLC Program					
PLC	TEST	Contact check					
	RUN	Runs PLC Program.					
	SERVO	Sets servo-	AMP/MOT	Sets servo motor capacity and constant			
		related	GAIN	Sets controller gain			
		parameters	PROT	Sets safety-related constants			
	MECH	Sets mechanism-related parameters					
		Sets operation- related parameters	MODE	Sets acceleration/deceleration and ORIGIN method in			
	OPER			feeding power source			
			JOG	Sets JOG operation			
PARA			DEF	Sets basic movement conditions			
171101			SET	Sets communication and others	СОММ	Communication-related settings	
					ETC	Sets servo run conditions and TP	
	I/O	Sets contact- related parameters	INPUT	Sets system input contact			
			BRAKE	Brake ON/OFF signal			
			SVO	Servo ON / OFF signal			
			OUTPUT	Sets system output contact			
	ALARM	Disables Alarm	HISTORY	Checks out current and existing Alarms			
VIEW	SERVO	Check out motor run-related information, Option , current Vdc, firmware version and operational time					
ATEAA							
	INT	Saves Integer variables					



#### 4.2 PARA(PARAMETER)

- Changes default parameter values.
  - 4.2.1 Shift to Parameter Menu
- Shift to the parameter screen.






#### 4.2.2 Parameter Configuration and Value Change

■ Parameters that are set as valid values in changing a parameter with 'F1' or 'F2' key include AMP, MOTOR\_ID, ENC\_PLS, DATAMODE, USERMODE, and SENSOR.

(For further details, refer to '5.3 How to Set Parameters'.)






#### Step 3. Increase parameter value Press F1. AMP/MOT Parameter \*1 AMP F1 MOTOR ID 106 POWER B/D 100W Value increases. AMP/MOT Parameter Press F1. \*2 AMP F1 MOTOR ID 106 POWER B/D 200W Increased to a valid value. AMP/MOT Parameter \*4 AMP MOTOR ID 106 POWER B/D 400W Step 4. Decrease parameter value PRESS F2. AMP/MOT Parameter AMP F2 MOTOR ID 106 POWER B/D 400W Decreased to a valid value. AMP/MOT Parameter \*2 AMP F1 MOTOR ID 106 POWER B/D 200W




### 4.3 ORG(ORIGIN)

#### 4.3.1 ORIGIN Operation





4.3.2 Run ORIGIN and check out Z-phase (INC serial encoder)
(Set parameter ENC\_TYPE to '3'.)



#### ■ Teach Pendant screen following completion of origin return operation

- 1) The number of pulses is displayed from the origin sensor to encoder Z-phase detection.
  - When the encoder resolution is 2500 pulse (Quadrature)
    - $1 \le \text{Display range} \le 10000$
  - When an encoder resolution is 17Bit(131072pules)

4-6

- $1 \le \text{Display range} \le 131072$
- 2) The value for the number of Z-phase pulses varies within ±2000 pulse range (based on 4096 pulse) whenever origin return operation is performed.
- 3) When the range of fluctuation in pulse value following origin run, shifting an accurate point is not possible, so check out the sensor in robot mechanism and sensor dog.




#### 4.3.3 Run ABS Encoder ORIGIN


Set related parameters prior to performing origin operation.
 (For details about parameter settings, refer to 'Procedure 2 Parameter Settings'.)

#### Origin return operation of an absolute type encoder


- 1) Shift to the desired position by operation and reset the encoder for setting.
- 2) The value set by parameter ORG\_RULE is irrelevant to operation. (But, it is possible when ENC\_TYPE is set to '2'.)
















## **CAUTION**


- > Origin operation is done when it comes to an INC serial encoder (with ENC\_TYPE parameter value of 3).
- > Origin operation is not needed when it comes to an ABS serial encoder (with ENC\_TYPE parameter value of 2), and origin operation menu can be used to reset a multi-turn value in the desired location.




#### 4.3.4 ORIGIN Fail

How to stop the ongoing origin operation.

#### ■ Stop the ongoing ORIGIN operation



- if ORG\_RULE is set to '0', a warning screen comes up as shown in the screen below.
  - 1) In case origin operation fails, check out the LIMIT sensor or ORG\_RULE settings.





## 4.4 PROG (PROGRAM)

#### 4.4.1 Command

For further details, check out 'Ch.9 Description of Robot Command'.

4.4.1.1 Operating Command

Command	Detailed	Input Data	Description of Command
	Command		·
			Turns ON power to servo.
	ON	None	Turns OFF power to servo.
SERVO	OFF	None	ALARM sounds when the torque exceeds its
SERVO	TRQ	1 ~ 300	given ЦМІТ.
	TQS	1 ~ 300	The next line is implemented after arriving at
			the given torque.
ALARM	None	0 ~ 255	User ALARM sounds.
CDD	None	1 ~ 10000	Sets motor revolutions.
SPD (Speed)	IOSPD	None	Sets motor revolutions to a contact point.
(Speed)	I	0 ~ 255	Sets motor revolutions to integer variable.
ACC	None	1 ~ 500	Sets acceleration time.
(Acceleration)	I	0 ~ 255	Sets acceleration time.  Sets acceleration time to integer variable.
(Acceleration)	1	0 255	Sets deceleration time to integer variable.
DEC	None	1 ~ 500	Sets deceleration time.
(Decrement)	I	0 ~ 255	Sets deceleration time to integer variable.
	-		accommunity to integer random
	None	0 ~ 100	Program runs during movement command
FOS	I	0 ~ 255	(MOVx).
	_		
PCLR (Position Clear)	None	None	Sets reference coordinate (Current position value) to '0.000'.




### 4.4.1.2 Control Command

Command	Detailed Command	Input Data	Description of Command		
STOP	None	None	Stops robot program from making progress.		
	В	000 ~ 317	Processes conditions according to contact value (Bit).		
,,,	ВВ	00 ~ 31	Processes conditions according to contact value (Byte).		
IF	I	0 ~ 255	Processes conditions according to integer variable value.		
	Р	0 ~ 1023	Processes conditions according to position variable value.		
	В	000 ~ 317	Processes conditions according to contact point value (Bit) during operation.		
XIF	ВВ	00 ~ 31	Processes conditions according to contact point value (Byte) during operation.		
, AIF	I	0 ~ 255	Processes conditions according to integer variable value during operation.		
	Р	0 ~ 1023	Processes conditions according to position variable value during operation.		
	None	0 ~ 10000	Waits for the assigned time period.		
	В	000 ~ 317	Waits until the assigned contact point turns into the default		
WAIT	ВВ	00 ~ 31	value.		
	I	0 ~ 255	Waits until the default integer variable value is available.		
	Р	0 ~ 1023	Waits until the default position variable value is available.		
SBRT (Subroutine)	None	0 ~ 999	Displays the start of a subroutine.		
RET (Return)	None	None	Displays the end of a subroutine.		
CALL	None	0 ~ 999	Branches to the assigned subroutine.		
GOTO	None	0 ~ 999	Branches to the assigned label.		
LBL (Label)	None	0 ~ 999	Assigns the label.		
LOOP	None	0 ~ 999	Performs repeated run as much as the default value to the assigned ENDL.		
ENDL (End Loop)	None	0 ~ 999	Displays the end of the assigned LOOP.		
JPGM (Jump Program)	None	0 ~ 7	Branches to the assigned program.		
PEND (Program End)	None	None	Ends the program.		



#### 4.4.2 Write New Program





PROGRAM No. 2 4000

0# 1# <u>\*2</u> 3

4 5 6 7

EDIT COPY DEL

Shift to an unwritten program.



F1


Select EDIT.

1	PROGRAM	No. 2		4000
	0#	1#	<u>*2</u>	3
	4	5	6	7
	<u>EDIT</u>		COPY	DEL



#### 4.4.3 Edit Program

#### 4.4.3.1 View Written Program





#### 4.4.3.2 Insert Program

#### Step 1. Shift to MAIN screen

PROGRAM No. 0 S000\*SERVO ON S001 LBL 1

BLOCK JMP DEL

8

Shift to the position for addition.

9 : Page up (Shift 2 or 4 lines upward)

8: Up (Shift 1 line upward)

2 : Down (Shift 1 line dowward)

3 : Page Down (Shift 2 or 4 lines downward)

From the selected position, press ENT key.

EN

DEL

ENT

S009 GOTO 1

S009 GOTO 1

S011 LBL 1 BLOCK

S010\*SERVO ON

S010\*\_

S011 SERVO ON

SERVO STOP MOVA MOVI

JMP

F1 F2

F3

F4

ESC

Use the mode selection key to select a command.

(For example, press 'F2' key to add a command STOP.)

Press ESC key when there is no further addition.

S010 STOP

S011\*\_

S012 SERVO ON

SERVO STOP MOVA MOVI

S010 STOP


S011\*SERVO ON

S012 LBL 1

BLOCK JMP DEL




### 4.4.4 Save Program





#### 4.4.5 Copy Program



EDIT



#### 4.4.6 Delete Program

#### Step 1

#### **Delete Job Program**



Use the arrow key to move a cursor to the number to be deleted and select DEL.

Program No. 7

Delete ?

YES NO

Select YES. (ex: No.7)

F4

F1

PROGRAM No. 7 3985

0# 1# 2 3

4 5 6 \*7

EDIT COPY DEL

Job Program in the corresponding number has been deleted.



- 4.4.7 How to Set and Save Program Block
- Ex. 1: Program with a repeated use of MOVI command

Step	Command	Description		
S000	SERVO ON	Turns ON SERVO.		
S001	LBL 1	Assigns LABEL to 1.		
S002	SPD 1000	Sets speed at 10% of parameter LMT_PRM.		
S003	MOVI 100	Moves from the current position as far as 100 in user coordinate.		
S004	MOVI 200	Moves from the current position as far as 200 in user coordinate.		
S005	MOVI 300	Moves from the current position as far as 300 in user coordinate.		
S006	MOVI 400	Moves from the current position as far as 400 in user coordinate.		
S007	SPD 3000	Sets speed at 30% of parameter LMT_PRM.		
S008	MOVA P0	Moves from P0 to the assigned position.		
S009	GOTO 1	Program run is transferred to LBL1.		
	<end file="" of=""></end>			

4.4.7.1 Copying Multi-row Command (Copying the entire Job from line S000 to last line S009)

# Step 1. Shift to BLOCK configuration screen

PROGRAM No. 0

S000\*SERVO ON

S001 LBL 1

BLOCK JMP DEL

Select BLOCK.

PROGRAM No. 0

S000\*SERVO ON

S001 LBL 1

START END COPY

BLOCK related command is displayed at the bottom of the screen.

.

F1

DEL



#### Setting Commands BLOCK, COPY Step 2.

PROGRAM No. 0 S000\*SERVO ON S001 LBL 1

START END COPY DEL Select START.

F1

S000[SERVO ON S001\*LBL 1 S002 SPD 1000

START END COPY DEL The square bracket opens up while being displayed between S000 and SERVO ON.

S008>MOVA P0 S009\*GOTO 1 S010 <end of file> START END COPY DEL Move to the step(S009) for COPY.



F2

F3

S009]GOTO 1 S010\*<end of file> S011 START END COPY Select END to close the square bracket and the COPY range is set.

DEL

Put the cursor on the step (S010) to be pasted on and select COPY.

S009]GOTO 1 S010\*<end of file> S011 START END COPY DEL

> The commands from COPY appears from S010 in order.

S009]GOTO 1 S010\*SERVO ON S011 LBL 1 START END COPY DEL



4.4.7.2 Copying Single-row Command (Adding command MOVI 100 in line S003 to line S007 coming after S006)

DEL

#### Step 1. Shift to BLOCK configuration screen

PROGRAM No. 0 S000\*SERVO ON S001 LBL 1 BLOCK JMP Select BLOCK.

F1

PROGRAM No. 0

S000\*SERVO ON

S001 LBL 1

START END COPY DEL

BLOCK related commands are displayed at the bottom of the screen.

#### Step 2. Set Commands BLOCK, COPY

PROGRAM No. 0

S000\*SERVO ON

S001 LBL 1

START END COPY

Handle an arrow key to move to S003.



S002 SPD 1000 S003\*MOVI 100 S004 MOVI 200 START END COPY DEL The cursor (\*) is placed on S003.

S002 SPD 1000 S003\*MOVI 100 S004 MOVI 200 START END COPY DEL Select START.

F1



\$003[MOVI 100 \$004\*MOVI 200 \$005 MOVI 300 \$TART END COPY DEL The square bracket opens up while being displayed between S003 and MOVI 100.

\$002 SPD 1000 \$003[MOVI 100 \$004 MOVI 200 \$TART END COPY DEL Move to S003 for single-row COPY.

\$003\$MOVI 100 \$004\*MOVI 200 \$005 MOVI 300 \$TART <u>END</u> COPY DEL Select END and the dollar mark(\$) appears.

S006 MOVI 400 S007\*SPD 3000

Move to the step(S007) to paste.

START END COPY DEL

S008 MOVA P0

S006 MOVI 400 S007\*MOVI 100 S008 SPD 3000 START END COPY DEL Select COPY to paste the copied command.

F3

F2



4.4.7.3 Copying Job using READ, WRITE (Copying the entire Job from line S000 to last line S009)

#### Step 1. Shift to BLOCK configuration screen

PROGRAM No. 0 S000 \*SERVO ON S001 LBL 1

BLOCK JMP DEL

Select BLOCK.

F1

PROGRAM No. 0

S000 \*SERVO ON

S001 LBL 1

START END COPY DEL

BLOCK related commands are displayed at the bottom of the screen.

#### Step 2. Set command BLOCK

PROGRAM No. 0 S000 \*SERVO ON S001 LBL 1

START END COPY DEL

Select START.

F1

S000[SERVO ON
S001\*LBL 1
S002 SPD 1000
START END COPY DEL

The square bracket opens up while being displayed between S000 and SERVO ON.

S008>MOVA P0
S009\*GOTO 1
S010 <end of file>
START END COPY DEL

Move by handling an arrow key toward the step(S009) to copy.





S009**]**GOTO 1
S010\*<end of file>
S011
START <u>END</u> COPY DEL

Select END and the square bracket is closed and the range to copy is set.

Step 3.

#### Use READ, WRITE

S009]GOTO 1 S010\*<end of file> S011 READ WRITE JMP Press ENT and the menu at the bottom of the screen is changed.

S009]GOTO 1

S010\*<end of file>

S011

READ WRITE JMP

Select READ to save the written program to the memory.

F1

F2

F2

ENT

S009]GOTO 1

S010\*<end of file>

S011

READ WRITE JMP

Move to the step(S010) to paste and select WRITE.

S009]GOTO 1

S010\*SERVO ON

S011 LBL 1

READ WRITE JMP

Copied programs are pasted from S010 in order.



#### 4.4.7.4 Copying Job using JMP

(Copying commands from line S003 to S004 to line S007 coming after S006)

#### Step 1.

#### Shift to BLOCK configuration screen

PROGRAM No. 0 S000 \*SERVO ON S001 LBL 1

BLOCK JMP DEL

Select BLOCK.

F1

PROGRAM No. 0 S000 \*SERVO ON S001 LBL 1

START END COPY DEL

BLOCK related commands are displayed at the bottom of the screen

#### Step 2.

#### **Set command BLOCK**

PROGRAM No. 0
S000 \*SERVO ON
S001 LBL 1
START END COPY DEL

Handle an arrow key to move the cursor (\*) to S003.



S002 SPD 1000

S003\*MOVI 100

S004 MOVI 200

START END COPY DEL

The cursor (\*) is placed on S003.

S002 SPD 1000

S003\*MOVI 100

S004 MOVI 200

START END COPY DEL

F1

Select START.



The square bracket opens up while S003[MOVI 100 being displayed between S003 and S004\*MOVI 200 MOVI 100. F1 S005 MOVI 300 START END COPY DEL Move to the step(S004) to COPY. S003[MOVI 100 S004\*MOVI 200 S005 MOVI 300 START END COPY DEL Select END and the square bracket is S004]MOVI 200 closed and the range to copy is set. S005\*MOVI 300 F2 S006 MOVI 400 START END COPY DEL Press ENT and the menu at the bottom S004]MOVI 200 of the screen is changed. S005\*MOVI 300 ENT S006 MOVI 400 READ WRITE JMP Select READ to save Program to the S004]MOVI 200 memory. S005\*MOVI 300 F1 S006 MOVI 400 READ WRITE JMP



#### Step 3. JMP Use and COPY

S004]MOVI 200

S005\*MOVI 300 S006 MOVI 400

READ WRITE

JMP

Select JMP to skip the step.

Jump to S

Last line is S009

Number input for the line to jump and the last step of Program are viewed.

Jump to S007

Last line is S009

0 0

7

F3

Enter the step number to jump.

S006 MOVI 400

S007\*SPD 3000

S008 MOVA P0

READ WRITE JMP

ENT

Press ENT and the cursor (\*) is placed on S007.

S006 MOVI 400

S007\*SPD 3000

S008 MOVA P0

READ WRITE JMP

F2

Select WRITE to paste Block data saved to the memory.

S006 MOVI 400

S007\*MOVI 100


S008 MOVI 200

READ WRITE JMP

The assigned step is copied to S007.



# 4.4.7.5 Deleting Command from Job Program (Deleting MOVI 100 in line S003 from Job Program in Example 1)





4.4.7.6 How to Move within Written Job Program

#### Step 1. Shift 1 line at a time.

PROGRAM No. 0 S000\*SERVO ON S001 LBL 1 BLOCK JMP DEL



- 8: Raises 1 step at a time.
- 2: Lowers 1 step at a time.

S000 SERVO ON
S001\*LBL 1
S002 SPD 1000
BLOCK JMP DEL

The cursor(\*) is taken 1 step down, from S000 to S001.

#### Step 2. Page Up, Page Down

PROGRAM No. 0 S000\*SERVO ON S001 LBL 1 BLOCK JMP DEL

\$003\*MOVI 100.000 \$004 MOVI 200.000 \$005 MOVI 300.000 BLOCK JMP DEL 9

3

9: Page UP

- (Moves 4 or 8 respective steps upward)
- 3: Page Down
  (Moves 4 or 8 respective steps downward)

The cursor(\*) is taken 4 steps down, from S000 to S003.


3



#### 4.4.7.7 How to Save Written Program

#### Step 1.

## **Save written Program**



ESC

F1

When there are any changes made, press ESC to move to Program save & check menu.

PROGRAM No. 0
Changed. Save?

YES NO

Select YES to save the written program.




#### 4.5 **POSITION Teaching**


- Capable of displaying on the screen the position variables used in the program or modifying their values.
- Applicable position variables are 1024 (P0 ~ P1023) units in number.
- Ranges for each variable are -99999.999 ~ 99999.999.
- There are 3 ways to set position variables.
  - 1) Manual data input (MDI) 2) JOG input 3) Incremental JOG input
- Position values P1020~P1023 come with the functions below.

Number of Position Value	Description
P1020	Correction value for the current position when using command GOTO following XIF.
P1021	Position value corrected to the 1020 value.
P1022	Reference coordinate value for command REF.
P1023	Current position value.


#### 4.5.1 Manual Data Input (MDI) Teaching

#### ■ Ex) P0 Teaching






#### Step 2. Shift to POS screen







## **CAUTION**


- > Save is not completed when turning power OFF without moving to SAV or to the previous screen after entering the position value.
- screen after entering the position value.

  > When a value is given to P1021 and command GOTO is used following command XIF, it turns into a correction value.
- Even though a value is given to P1022, it turns into the coordinate value used in command RFF
- The value in P1023 is a current position value, ignoring the input on F1 key or ENT key.




#### 4.5.2 JOG Teaching

#### ■ Setting Step (Ex: P0001 Teaching )







## **■** Command description

POSITION DATA

P0000\*0.10

P0001 0.000

MDI TCH SAV JMP

JM

\*: Position value in ongoing Teaching MDI: Manual data input method TCH: JOG Teaching method SAV: Saves position data

JMP: Moves to position variable (P) number

P0000 0.123 P0001\*0.123 P0002 0.000 JOG+ JOG- spd0 IJOG JOG+: Moves in plus(+) direction JOG-: Moves in minus(-) direction

IJOG: Moves as much as movement amount of

the predetermined position

spd0: Changes JOG movement speed

(Change in order of spd0→spd1→spd2→spd3)



P0000 0.123

P0001\*0.123

P0002 0.000

JOG+ JOG- RES0 JOG JOG+: Moves in plus(+) direction

JOG-: Moves in minus(-) direction

JOG: Moves at predetermined speed (RPM)

RES0: Changes movement amount of JOG

position

(Change in order of RES0→RES1→RES2→RES3)

#### Change speed in JOG movement

P0000 5.678

P0001 5.678

P0002\*5.678

JOG+ JOGspd1 IJOG Movement speed is changed. (spd1->spd2)

F3

P0000 5.678

P0001 5.678

P0002\*5.678

JOG+ JOGspd2 IJOG Movement speed is changed. (spd2->spd3)

F3

F3

P0000 5.678

P0001 5.678

P0002\*5.678

JOG+ JOG-IJOG spd3

Movement speed is changed. (spd3-

>spd0)

P0000 5.678


P0001 5.678

P0002\*5.678

JOG+ JOGspd0 IJOG Movement speed has been changed.



#### **■** Change JOG mode






- ➤ When JOG key is pressed and the motor fails to run and a warning message 'Press Deadman Key' comes up on T/P screen, instead, disable the Deadman function parameter or press the Deadman key at the right side of T/P to get Teaching going.
- Deadman-related parameters are set in 'OPER->ETC->JOG\_DMAN'.



#### 4.5.3 Inching Jog Teaching

- Inching Jog shows a function of moving as much as movement amount for the predetermined position.
- Move as much as the fixed position by Jog, enabling detailed movement with the use of Inching Jog.
- Press F3 key to change JOG movement amount (res0 ~ res3) and F4 key to change JOG mode.
- Whenever pressing F1, F2 keys once at a time, movement is made as much as the fixed movement amount.
- Press F1(JOG+) or F2(JOG-) key to move to the desired position and press ENT key, and the value of a position value is changed. The screen at this time turns to the staus where the next variable value can be entered.
- The next screen shows Inching Jog operation in res0 = 1.000.





POSITION DATA

P0000\* 1.123 P0001 0.000

JOG+ JOG- res0 IJOG

The value of line P000 increases by 1 to hold a value of 1.123.

POSITION DATA

P0000\* 1.123

P0001 0.000

JOG+ JOG- res0 IJOG

Select JOG+ to move +1mm.

F1

POSITION DATA

P0000\* 2.123

P0001 0.000

JOG+ JOG- res0 IJOG

Value for line P000 increases by 1 to hold a value of 2.123.

P0000 2.123

P0001\* 2.123

P0002 0.000

JOG+ JOG- res0 IJOG

Press ENT to save the current position value to P000.


ENT



#### **Change JOG movement amount**

- 1) In IJOG mode, press F3 and JOG movement amount is changed from res0 to res3 in order.
- 2) For setting movement amount, refer to 'Ch.3 Parameter Setting'.

#### Step 1.



#### Reference


When completing JOG and exit JOG mode by ESC, the user can set SERVO ON/OFF status by following parameter (OPER  $\rightarrow$  ETC  $\rightarrow$  JOG\_SV) settings.



#### 4.5.4 Forward(FWRD) Teaching

- It is possible to confirm the value by entering a position value and moving the robot.
  - 1) Moves to the assigned position in the absolute coordinate system based on the origin.
- Available for use by changing FWRD speed SPD(0 ~ 3).
- For the user to set FWRD speed SPD(0 ~ 3),
  - 1) Use by changing the speed of parameter  $JOG\_SPD(0 \sim 3)$ .
  - 2) JOG speed and FWRD speed are identiacl.
- To speed during FWRD, be sure to select STOP and make a stop prior to changing.

#### ■ Setting step






Go FWD at speed of SPD0. P0000 300.000 P0001\*0.000 P0002 0.000 FWRD STOP SPD0 Select STOP. P0000 300.000 (Unable to changing speed during P0001\*0.000 FRWD movement.) F2 P0002 0.000 SPD0 FWRD STOP Select SPD0. P0000 300.000 P0001\*0.000 F4 P0002 0.000 FWRD STOP SPD0 Speed has changed to SPD1. P0000 300.000 P0001\*0.000 P0002 0.000 FWRD STOP SPD1 Select FWRD. P0000 300.000 P0001\*0.000 F1 P0002 0.000 SPD1 FWRD STOP Implement command FWRD at speed P0000 300.000 of SPD1. P0001\*0.000 P0002 0.000 FWRD STOP SPD1



## 4.6 RUN (Robot program)

Turn into SERVO ON status when running the program.

4.6.1 How to Select Robot Program to Run





#### Step 3.

#### **Set robot Program**

ETC. Setting

FLO\_ERR \*2000

INPOS 0.050

1, 100000

Refers to default screen for ETC setting.

INPOS 0.050 ROB\_PGM \*0 PLC\_PGM Handle an arrow key to move to ROB\_PGM.

INPOS 0.050 ROB\_PGM \*5 PLC\_PGM 0, 8 (Twice)

ENT

0, 8


Select ENT and enter Program number  $(0 \sim 8)$ .



- > To set ROB\_PGM to '8', select a program by coding values for contact points PGM\_SEL2 ~ 0 from the outside.
  - (For example, program NO.1 is selected in PGM\_SEL( $2 \sim 0$ ) = 001.) Turn ON contact point PGM\_SEL to apply the selected program number.
- When ROB\_PGM is set to a value between 0 and 7, the program for the set number runs.



#### 4.6.2 How to Implement AUTO RUN





- Description : Select a program to run before running the program.
  - 1) If the selected program is empty or program writing does not meet rules, an error occurs.
  - 2) Then, either select a program again or edit the program properly prior to running.
  - 3) Error types likely to occur while the program is running are included below.
    - When origin return operation is not completed

Not Find Origin ?

• When the selected program is empty


Empty JOB
ECODE: 11.00
HISTORY RESET

 When a break-in point corresponding to an executable statement is not assigned

Warning !
No match LBL
PGM No.0 STEP 003



#### 4.6.3 How to Implement STEP RUN





S002 SPD 1000

S003\*MOVI 100.000

S004 MOVI 200.000

STOP No. 0

12.159

12.159 indicates the current position of the robot in motion.

S003 MOVI 100.000

S004\*MOVI 200.000

S005 GOTO 1

RUN RESET STEP SKIP

Select STEP to perform MOVI 200.000 operation.

F3

S003 MOVI 100.000

S004\*MOVI 200.000

S005 GOTO 1

STOP No. 0

171.164

171.164 indicates the current position of the robot in motion.

To continue STEP RUN, select STEP.

S004 MOVI 200.000

S005\*GOTO 1

S006 <end of file>

RUN RESET <u>STEP</u> SKIP

F3



4.6.4 How to Convert STEP RUN to AUTO RUN (Perform Step 1, Step 2 for how to perform step run in the same way before performing Step 4.)

#### Step 1. How to convert to AUTO RUN

PROGRAM No. 0 S000\*SERVO ON S001 LBL1 RUN RESET STEP SKIP Refers to the default screen for setting Step run.

\$002 SPD 1000 \$003\*MOVI 100.000 \$004 MOVI 200.000 <u>RUN</u> RESET STEP SKIP Select RUN and operation is done in auto run.

F1

S003 MOVI 100.000 S004\*MOVI 200.000 S005 GOTO 1 STOP No. 0 159.177 Operates is done in auto run.



4.6.5 Initialize Robot Program Step (Implemented following '4.6.2 How to Implement AUTO RUN'.)

#### Step 1. How to initialize program step

S003 MOVI 100.000 S004\*MOVI 200.000 S005 GOTO 1 STOP No. 0 7859.177 Select STOP.

F1

Select RESET.

S003 MOVI 100.000 S004\*MOVI 200.000 S005 GOTO 1 RUN <u>RESET</u> STEP SKIP

F2

SKIP

Move to the default screen in setting Step run.

PROGRAM No. 0


S000\*SERVO ON

S001 LBL1

RUN RESET STEP




- 4.6.6 Run from Stopped Step
- 1) If the robot program that has been previously running does not end, a screen that asks if it continues to run from the stopped step comes up.
- 2) STOP, Alarm or previous STEP of power OFF, and Servo On status are maintained. (Beginning to run from the stopped step in step run or auto run.)





#### 4.7 PLC

#### 4.7.1 Select PLC Program



ETC.

F4

OPER. Parameter

MODE JOG DFT

Select ETC.



#### Step 3.

#### **How to set PLC Program**

ETC. Setting

FLO\_ERR \*2000

INPOS 0.050

1, 100000

Refers to default screen for ETC setting.

ROB\_PGM 0
PLC\_PGM \*0
INI\_TRQ 0
0, 3

(3회)

ENT

Handle an arrow key to move to PLC\_PGM.

ROB\_PGM 0
PLC\_PGM \*3
INI\_TRQ 0
0, 3

Select ENT and enter Program number  $(0 \sim 3)$ .



#### 4.7.2 Run PLC Program

- Description : Select a PLC program to run before running the program.
  - 1) If the selected program is empty or program writing does not meet rules, an error occurs.
  - 2) Then, either select a program again or edit the program properly prior to running.
  - 3) Error types likely to occur while the program is running are included below.
    - When the selected program is empty

Empty PLC

ECODE: 11..50

**HISTORY** 

**RESET** 

• When no saved contact point information is present in logic operation (Syntax Error occurs)

Warning!

Needs more 1 block

PLC No. 0 STEP 000

#### Setting Step

## Step 1. SI

Shift to MAIN screen

TPS-9000T Ver1.3

F1: Teach Pendant

F2: RS-422 Multipoint

F3: Data up/Down Load

Turn ON power to controller and select Teach Pendant.

F1

**ENT** 

Press ENTER.

RoboStar RCS-8000C

Servo Controller

**PARA V00.22** 

PRESS ENT KEY



Step 2. **Implement PLC Run** Select PLC. Servo Controller **ROBOT** PLC PARA **VIEW** F2 Select RUN. PLC Control PROG TEST RUN F4 Select RUN. PGM No.0 is Ready. F4 RUN Step 3. **Stop PLC RUN** Refers to default screen of PLC Control. PLC Control Select RUN again. **PROG** TEST RUN F4 Select STOP and PLC Program comes PGM No.0 is Running to a stop. **STOP** F1




#### 4.7.4 Check out I/O Connection

First of all, select an I/O contact point to use and perform the connection job.

4.7.4.1 Check out Input/Output Contact Status and TEST Method

Setting Step

#### Step 1. Shift to PLC TEST screen



Step 2

**PORT** 01234567 **STATE** B00 \*00000000 Ι B01 00000000 Ι **JMP** 

#### <PORT Movement>



: Moves upper PORT



: Moves lower PORT

<BIT Movement>



: Moves lower BIT

: Moves upper BIT

- PORT: B00 ~ B41
- BIT Input/Output: 0(OFF), 1(ON)
- STATE:
  - I: User Input
  - O: User Output
  - **USER: Internal Contact**
  - SYS I: System Input
  - SYS O: System Output



#### **4.8 VIEW**

#### 4.8.1 How to Check out Alarm Message

When the robot is in abnormal operation conditions, an error code comes up on the display in front of the controller, displaying alarm details on Teach Pendant screen.

#### ■ Display Alarm Message




Alarm message:

Displays details about the generated alarm.

Alarm code:

Displays the code number of the generated alarm.

#### **■** Example of Alarm Message Output



In case T/P EMG alarm occurs.

SYS I/O Emergency

ECODE: 12.01


HISTORY RESET

In case System I/O EMG alarm occurs.




## 4.8.2 Alarm History

To identify information about the controller alarm generated before, it can be confirmed through alarm history menu and the maximum number of alarm histories that can be saved is 100.










#### 4.8.3 INT(INTEGER) Variable

Referred to as an integer variable which is used for arithmetic operation and storing temporary input/output DATA. This variable stores 256 variables between 0 and 65535.





## ch.5 Parameter settings

- Parameter settings are an important part and more than half of the errors generated while operating the robot are due to incorrect settings.
- For basic parameter setting values, refer to labels attached to the robot.
- Parameters are basically factory default settings. There may be situations, while installing or running the robot in the field, where parameter values should inevitably be modified according to surrounding environments. In this case, contact our customer care team.

#### 5.1 Overview

- Refers to the mode that sets robot type and operating environment.
- Prior to running the robot (Mechanism+ Contoller), be sure to check out the default value and reset it when necessary.
  - 1) Data related to mechanical, electrical robot specifications
  - 2) Basic robot operation methods such as home return method and specific functions
  - 3) Computer and data communication protocols
- Basic parameters are basically factory-default settings when shipping out the robot (Mechanism+Controller).
- Upon completion of settings, be sure to record or back up the data on the computer in preparation for change to default value due to error in use.



# 5.2 Parameter Types

	Group	Detailed Group							
Name	Description	Name	Description						
	Sets servo-	AMP/MOT	Sets servo motor capacity and constant						
SERVO	related	GAIN	Sets controller gain	Sets controller gain					
	parameters	PROT	Sets safety-related const	ant					
MECH	Sets mechanism-re	elated parame	ters						
		MODE	Sets acceleration/decele	ration and	ORIGIN methods in feeding				
			power supply						
	Sets operation-	JOG	Sets JOG operation						
OPER	related	DEF	Sets basic movement co						
	parameters		Sets communication	COMM	Communication-related settings				
		SET	and others	ETC	Sets servo run conditions and				
			and others	EIC	TP				
	Sets contact-	INPUT	Sets system input contact						
I/O	related	BRAKE	Brake ON/OFF signal						
1,0		SVO	Servo ON / OFF signal						
	parameters	OUTPUT	Sets system output contact						



#### **5.3** How to Set Parameters

#### 5.3.1 How to Set SERVO-related Parameters

(Servo parameters are the mode that sets the capacity of a servo driver, the capacity of the servo motor, encoder type, controller gain and brake operation conditions of the motor.)

5.3.1.1 AMP / MOT

#### ■ Setting Servo Motor Capacity & Constant

Detailed Group	Name	Description	Setting Range	Default Value
	AMP	Sets built-in servo driver capacity	1~15	2
	MOTOR ID	Sets motor capacity and motor type	0 ~ 9999	206
	ENC TYPE	Selects encoder types INC, ABS	0 ~ 3	3
	ENC PLS	Sets encoder pulse	1000 ~ 9999999	131072
	MOT_TYPE	Sets rotary, linear	0 ~ 1 (ROT/LIN)	0
	ENC_DIR	Sets encoder direction ( + / - )	0, 1 (CW/CCW)	0
	R	Phase resistor	0 ~ 999.99 (Ω)	0.300
	L	Phase inductance	0 ~ 999.99 (mH)	7.600
	R_I	Rated current	0 ~ 999.999 (A)	1.600
	MAX_I	Maximum current	0 ~ 999.999 (A)	4.880
AMP/	BACK_EMF	Counter electromotive force	0 ~ 10 (10 <sup>-3</sup> V/min <sup>-1</sup> )	17.550
МОТ	Jm	Inertia moment	0 ~ 99.99 (10 <sup>-4</sup> kg*m^2)	0.140
	Kt	Torque constant	0 ~ 999.99 (N*m/A)	0.410
	MAX_RPM	Maximum speed of revolution	1 ~ 10000 (RPM)	5000
	Кср	Proportional gain of current control loop	0 ~ 999.990	42.990
	Kci	Integral gain of current control loop	0 ~ 999.990	2.870
	POLE	Number of motor poles	1 ~ 99 (POLE)	8
	Z_OFFSET	Z-phase initialization	0 ~ 360 (THETA)	30
	H_OFFSET	Hall initialization	0 ~ 360 (THETA)	0
	ELC_PIT	Distance between poles	1 ~ 1000 (0.1mm)	1



## Built-in SERVO DRIVER Capacity Setting

Set Position		SERVO	⇒ AMP/I	MOT ⇒ <b>AMP</b>	·	·			
Parameter	Set	range	Default value		Description				
				Sets the capacity	of the built-in	power amplifi	er(AMP).		
				Controller	Capacity	Set Value			
AMP				RCS8001	100W	1			
			2		RCS8002	200W	2		
	0	~20		RCS8004	400W	4			
				RCS8008	800W	8			
				RCS8010	1000W	10			
				RCS8015	1500W	15			

#### Reference

1. This value is determined by the capacity of a single-axis controller.



#### Caution

- ▶ When MOTOR TYPE and MOTOR ID are incorrectly entered, the motor may be damaged so use caution.
- Incorrect capacity setting (AMP) may cause the controller and the motor may be damaged so use caution.



Motor Capacity Setting																			
Set poisition SERVO ⇒ AMP/MO					T ⇒ <b>M</b> (	OTOR ID													
Parameter	Set	range	Default value		Description														
				Мо	otor cap	acity and i	motor type	setting											
				N	/IOTOR	MOTOR	MOTOR	MOTOR	MOTOR	MOTOR ID									
	0~9999				TYPE	ID	TYPE	ID	TYPE	WOTOKID									
MOTOR			0~999		0~9999			0~9999	0~9999	0~9999		М	ISMR01	106	MSME01	108	MSMZ01	103	
							0~				206	М	ISMR02	206	MSME02	208	MSMZ02	203	
											М	ISMR04	406	MSME02	408	MSMZ04	403		
										М	ISMR08	756	MSME02	758	MSMZ05	753			
					М	ISMA10	1006	MHMD10	1008	MDMA10	1007								
						-	-	MSMA15	1508	MDMA15	1507								

#### Reference

- 1. Values for ENC\_PLS, R, L, R\_I, MAX\_I, BACK\_EMF, jm, kt, MAX\_RPM, Kcp, Kci, and POLE are set in line with Sped by set values for MOTOR ID.
- 2. When the set value is 0, a value can be set arbitrarily. (Refer to MOT\_TYPE parameter.)



#### Caution

- ➤ When using MDMA series, LMT\_RPM parameter value is set to the rated speed of 2000rpm. When the setting is not made and the system runs, error "13.00 Over Speed" sounds.
- > Incorrect parameter setting may damage the controller or the device, and may cause a malfunction.



ENCODER Constant Setting										
Set position	on	SERVO	⇒ AMP/I	MC	OT ⇒ ENC_TYI	T ⇒ ENC_TYPE, ENC_PLS, ENC_DIR				
Parameter	Set	range	Default value			Description				
				S	ets an encoder	type to use.				
					Set value	Туре				
ENC	0~3	1~3	3		0	9 wire Quadrature Encoder type				
TYPE		,,,,	3		1	Reserved				
					2	Absolute Encoder type				
					3	Incremental Encoder type				
	Sets the number of pulses per revolution to use.									
ENC	13	1072	131072		Set value	Туре				
PLS	(P	ulse)			131072	Serial Type Encoder				
					2500	Quadrature Type Encoder				
ENC			0	•						
DIR		)~1	0	S	Sets encoder direction ( + / - ).					

#### Reference

- 1. Sets an encoder type to use.
- A 9 wire Quadrature motor can run when setting ENC\_TYPE value to 0.
   Absolute Encoder type when setting ENC\_TYPE to 2.
   When setting ENC\_TYPE value to 3, the encoder uses communication lines SD+, SD- pin other than power-relatred signals.
- 3. ABS(Absolute) 4 wire serial encoder sets 'ENC\_TYPE' to '2', whereas an INC(Incremental) 4 wire serial encoder sets 'ENC\_TYPE' to '3'. (Absolute one should get a separate battery installed.)
- 4. MOTOR ID value gets ENC\_PLS value to change automatically.
- 5. Once the encoder type has been changed, be sure to cut off the power and re-apply it before use.



> Incorrect parameter setting may damage the controller or the device and may cause a malfunction.



MOT TYPE (Motor Type Setting							
Set position SERVO ⇒ AMP/MO				MOT	⇒ MOT	_TYPE	
Parameter	Set	range	Default value		Description		
				Sets	s types (R	otary, Linear Motor)	of a servo motor.
мот				Se	et value	Description	
TYPE	0~1	0~1 0	0		0	Rotary Motor	
					1	Reserved	
						·	

SERVO Motor Capacity, Constant			
Decision			
Set	SERVO ⇒ AMP/MOT ⇒	R, L, R_I,	MAX_I, BACK_EMF, Jm, Kt, MAX_RPM, Kcp, Kci, POLE
position		Z_OFFSET	r, H_OFFSET, ELC_PIT
Parameter	Set range	Default	Description
Farannetti	Set range	value	Description
R	0 ~ 999.99 (Ω)	3	Phase resistor
L	0 ~ 999.99 (mH)	7.6	Phase inductance
R_I	0 ~ 999.999 (A)	1.6	Rated current
MAX_I	0 ~ 999.999	1.91	Maximum current
BACK_EMF	0 ~ 10[Vrms/rpm]	10	Counter electromotive force
Jm	0 ~ 999.999 (gfcms2)	1.6	Inertia moment
Kt	0 ~ 999.99 (kgfcm/A)	0	Torque integer
MAX_RPM	1 ~ 10000 (RPM)	5000	Maximum speed of revolution
Кср	0 ~ 50.000	47.75	Proportional gain of current control loop
Kci	0 ~ 20.00	15.1	Integral gain of current control loop
POLE	1 ~ 99 (POLE)	8	Number of motor poles
Z_OFFSET	0 ~ 360[THETA]	30	Z-phase initialization
H_OFFSET	0 ~ 360[THETA]	0	Hall initialization
ELC_PIT	1 ~ 1000[0.1mm]	1	Distance between poles
Reference	ce		

1. R  $\sim$  POLE values are automatically set when setting MOTOR\_ID value, and to edit them individually, set MOTOR\_ID to '0'.



# Caution



#### 5.3.1.2 GAIN

Controller Gain Setting				
Set position SERVO ⇒ GAIN ⇒			GAIN $\Rightarrow$ P	OS_P, SDP_P, SPD_I
Parameter	S	et range	Default value	Description
POS_P	15 ~	15 ~ 300 (1/s)		Proportional gain of position control loop (Position Proportion)
SPD_P	2 ~ 500		40	Proportional gain of speed control loop (Speed Proportion)
SPD_I	10 ~ 150		25	Integral gain of speed control loop (Speed Integral)
Deferen				

#### Reference

- 1. POS\_P(Position Proportion): Proportional gain of position control loop
  - (1) Determines the responsiveness of the position control system.
  - (2) If the position loop gain is set at high level, positioning time can be shortened.
  - (3) But, if set too high, it may cause an oscillation, therefore use caution.
  - (4) When the inertia ratio is set correctly, POS\_P set unit is hertz(Hz).
- 2. SPD\_P(Speed Proportion): Proportional gain of speed control loop
  - (1) Determines the responsiveness of the speed loop. To improve responsiveness of the whole servo system by raising POS\_P, it is necessary to set SPD\_P at high level.
  - (2) But, if it is too high, it may cause an oscillation, therefore use caution.
- 3. SPD\_I(Speed Integral): Integral gain of speed control loop
  - (1) Sets the integral time constant of the speed loop.
  - (2) As the set value is smaller, the deviation at stop gets faster to 0.
  - (3) If set to '999', integral is maintained.
  - (4) If set to '1000', integral effects disappear.



#### Caution



Controller Gain Setting				
Set position SERVO ⇒ GAIN ⇒ <b>IF</b>			⇒ GAIN	⇒ IR, SPD_FF, SPD_FL, TCMD_FL
Parameter	Parameter   Set range		Default	Description
rarameter	361	range	value	Description
IR	0 ~ 2000 300 Ine		300	Inertia Ratio
SPD_FF	0 ~ 2000 0 Sp		0	Speed Feed Forward
SPD_FL	D_FL		200	Time constant of feed forward filter (Speed Filter)
TCMD_FL	D_FL 50 ~ 3000 300 Tim		300	Time constant of the 1st torque filter (Torque Command Filter)

## 1. IR

- (1) Sets the ratio of the load inertia to the inertia of a rotor. (Load inertia /Motor inertia)×100[%]
- (2) When the inertia ratio is set correctly, SPD\_P set range is hertz (Hz). If the inertia ratio is larger than the actual level, SPD\_P set unit gets larger, whereas when the inertia ratio is smaller than the actual level, SPD\_P set range gets smaller.

## 2. SPD\_FF

- (1) Sets the amount of speed feed forward in position control.
- (2) If set at high level, the position deviation gets smaller to improve responsiveness but allow over-shoot to form easily, so use caution.

# 3. SPD\_FL

- (1) Sets the time constant of the delay filter inserted in the speed feed forward unit.
- (2) When speed feed forward is set at high level to generate over-shoot or sound gets bigger at time of operation, set a filter and the issued problem occasionally improves.

## 4. TCMD\_FL

- (1) Sets the time constant of the delay filter inserted in the torque command unit.
- (2) Shows an occasional effect of restraining oscillation by torsional resonance.



## **Caution**



## 5.3.1.3 PROT

Safety-related Constant Setting				
Set position		SERVO ⇒ PROT ⇒ <b>O</b> Y		S, OVT, OVL
Parameter		Set range	Default	Description
rarameter		set runge	value	Description
OVS	0	0 ~ 5500[PRM] 5000		Maximum allowable speed of the motor in mechanism
OVT	1	~ 1000[100ms] 25		Allowable load duration in mechanism
OVL 100 ~ 130[%] 110		110	Torque value of allowing load in mechanism	

#### Reference

- 1. OVS(Over Speed): Maximum allowable speed of the motor in mechanism
  - (1) Sets a speed limit.
- 2. OVT(Overload Time): Allowable load duration in mechanism
  - (1) Used to limit maximum motor torque in the controller (Servo) by means of parameter settings.
  - (2) General specifications allow about 3 times more in instant torque than rated torque, but when a fear may arise in regard to motor load(Machine) intensity with 3 times more in torque, this parameter is used to limit the maximum torque.
- 3. OVL(Overload Torque): Torque value of allowing load in mechanism
  - (1) When determined as excess deviation by function 「Excess protection of position deviation」, the detection level is set to the number of deviation counters.




## **Caution**




Safety-related Constant Setting			
Set position	SERVO ⇒ PRO	T ⇒ BRK	_S, BRK_R
Parameter	Set range	Default value	Description
BRK_S	0 ~ 2000[1ms]	200	With SERVO OFF while the motor stops, this refers to time taken from when brake release signal is OFF to the moment of non current carrying (SERVO FREE)
BRK_R	0 ~ 2000[1ms]	200	With SERVO OFF while the motor is rotating, this refers to time taken from when the motor is free from current carrying until the moment brake release signal is OFF.

- 1. BRK\_S(Brake Time Stop)
  - (1) To prevent the motor from making minute movement/fall due to operation delay time(tb), sequence(SQ) ≥ operation delay time (tb) of brake is arranged when turning off the primary power supply.
  - (2) Sequence (SQ) unit when turning off the primary power supply: (Set value) x 8ms



# 2. BRK\_R

- (1) Sets to prevent the brake from being deteriorated due to motor rotation.
- (2) With the servo off while the motor is rotating, time tb in the figure below becomes a shorter time of the times taken until SQ set time and motor rotation speed reach below about 30r/min.





## Safety-related Constant Setting

Set position SERVO ⇒ PROT ⇒ MAIN_PWR, ALM_SEQ, SVO_SEQ, OPEN_CHK		IN_PWR, ALM_SEQ, SVO_SEQ, OPEN_CHK	
Parameter	Set range	Default value	Description
MAIN_PWR	0 ~ 3[SEQ]	0	Operating conditions for the dynamic brake when the power to motor is cut off
ALM_SEQ	0 ~ 3[SEQ]	0	Operating conditions for the dynamic brake in the event of an alarm
SVO_SEQ	0 ~ 3[SEQ]	0	Runs the dynamic brake in SERVO OFF
OPEN_CHK	0 ~ 1[ON/OFF]	0	Sets whether to check for short circuit when using the regenerative resistor. Set value 0: Open Check used, 1: Open Check not used

## Reference

■ For setting MAIN\_PWR, ALM\_SEQ, SVO\_SEQ parameters refer to the table below.

Set	Operating (	Conditions	Description of
Value	Decelerating	After stop	deviation counter
0	DB	DB	CLEAR
1	FREE RUN	DB	CLEAR
2	DB	FREE	CLEAR
3	FREE RUN	FREE	CLEAR

- 1. MAIN\_PWR(Main Power Sequence)
  - (1) After primary power is cut off
    - Operating conditions during deceleration or after stop
    - Sets clear handling of the description of deviation counter
- 2. ALM\_SEQ(Alarm Sequence)
  - (1) Sets operating conditions for deceleration or stop by the operation of Controller(Servo) protection functions in the event of an alarm.
  - (2) Relationship between set value, operating conditions and deviation counter handling is identical to the description of MAIN\_PWR.
- 3. SVO\_SEQ(Servo Off Sequence)
  - (1) After SERVO OFF
  - (2) Operating conditions during deceleration or after stop.
  - (3) Relationship between set value, operating conditions and deviation counter handling is identical to the description of MAIN\_PWR.
- 4. OPEN\_CHK(Register Open Check)
  - (1) Sets whether to check for short circuit when using a regenerative resistor in Controller(Servo).
  - (2) When the set value is '0', a check mark is used in the short circuit for regenerative resistor.
  - (3) A check mark is not used in the short circuit for regenerative resistor.





Incorrect parameter settings may damage the controller or the device, and may cause a malfunction.

## 5.3.2 How to Set Mechanism (MECH) related Parameters

Operating Area Setting			
Set position	MECH => MIN_LMT, MAX	_LMT	
Parameter	Set range	Default value	Description
MIN_LMT	-99999.999 ~ 99999.999	-99999.999	Minimum coordinate value for operating area
MAX_LMT	-99999.999 ~ 99999.999	99999.999	Minimum coordinate value for operating area
Reference			

- 1. In the event of the position command going beyond MIN\_LMT, MAX\_LMT range during robot operation, it is handled as an alarm.
- 2. Values MIN\_LMT, MAX\_LMT are ignored when doing Jog operation and Origin operation, and user coordinate values and the common area calculable in the number of encoder pulses are used as a limit value.

(-99999.999 <= User coordinate value <= 99999.999,

- -99999.999 <= Number of encoder pulses <= 99999.999)
- When converting MIN\_LMT and MAX\_LMT values to the number of encoder pulses (After quadrature),
- 4. To operate in unlimited orbit, the position value should be changed to '0' by using 'PCLR' command at an appropriate position when writing a program.

  (Used only in an INC serial encoder)



## **Caution**



Operation	Limit	Setting
-----------	-------	---------

Set position	MECH => LMT_RPM, LMT_TRQ				
Parameter	Set range	Default value	Description		
LMT_RPM	MT_RPM 1 ~ 10000 (RPM) 3000		Sets maximum value of operating speed		
LMT_TRQ	0 ~ 300 (%)	300	Limit torque value during operation		

LMT\_RPM value works as a basis in speed set for robot program.
 Ex) When setting LMT\_RPM to '3000' and running SPD1000 in the program, the operating speed becomes 300[RPM](10% of LMT\_RPM).



## **Caution**

- ➤ When the maximum speed of the motor is lower than the preset LMT\_RPM, alarm 'Over Speed' sounds.
- ➤ When using MDMA series, set the value for LMT\_RPM parameter to a rated speed of 2000rpm. If the setting is not done and the system operates, alarm "13.00 Over Speed" sounds.

## User Coordinate System Setting

Set position	MECH => ORG_OFS, ABS_C	MECH => ORG_OFS, ABS_OFS, CAL_POS, END_POS			
Danamatan	Cot range	Default	Description		
Parameter	Set range	value	Description		
ORG_OFS	-99999.999 ~ 99999.999	0	Coordinate value for origin position in user		
OKG_OF3	-99999.999 ~ 99999.999	U	coordinate system		
ABS OFS	-99999,999 ~ 99999,999	0	Position value for origin setting when using an		
ABS_OFS	-99999.999 ~ 99999.999	U	absolute encoder		
CAL DOC	AL_POS -99999.999 ~ 99999.999	0	Position value for calibration setting when using an		
CAL_POS			absolute encoder		
END DOC	00000 000 00000 000	0	Value for end position when using an absolute		
END_POS	-99999.999 ~ 99999.999		encoder		

## Reference

- 1. ORG\_OFS enters coordinate values for the origin position based on the coordinate system desired by the user.
- 2. The position used when feeding power supply is used as an ORG\_OFS coordinate until the origin is found out.
- 3. When using the machine without an origin, ORG\_OFS value is set to '0'.



## Caution



User Coordin	ate System Setting		
Set position	MECH => MOV_MOT, MOV	_MECH, M	OV_POL
Parameter	Set range	Default value	Description
MOV_MOT	1 ~ 10000	1	Revolutions of motor
MOV_MECH	1 ~ 10000	10	Movement amount of mechanism
MOV_POL	0 ~ 1 (0: Motor rotating forward + movement) (1: Motor rotating forward - movement)	1	Sign setting on user coordinate system

- 1. MOV\_MOT, MOV\_MECH sets a conversion rate between movement amount on user coordinate system and the number of corresponding encoder pulses.
  - 예1) To use the coordinate system by [mm] for the machine running 10.000[mm] per revolution of motor, set MOV\_MOT to '1' and MOV\_MECH to '10', respectively.
  - 예2) To use the coordinate system by [°] for the machine running 360.000[°] per 50 revolutions of motor, set MOV\_MOT to '50' and MOV\_MECH to '360', respectively
- 2. The range applicable as the coordinate value on user coordinate system is  $-99999.999 \sim 99999.999$ .
- 4. Even a position value allowed in the user coordinate system issues an alarm when the number of pulses for the position goes beyond the set range.



## **Caution**



Special Movem	ent Condition Setting						
Set position	MECH => MPG_PL	SO, MPG_PI	LS1, MPG_MOV0, MPG_MOV1, T_CYCLE				
Parameter	Set range	Default value	Description				
MPG_PLS0	1 ~ 10000	1	The number of entered MPG pulses				
MPG_PLS1	1 ~ 10000	1	The number of entered wird pulses				
MPG_MOV0	0.001 ~ 500.000	0.001	Movement amount of mechanism for the number of				
MPG_MOV1	0.001 ~ 300.000	0.001	entered mpg pulses				
			User corresponding to a single cycle of machine				
T_CYCLE	0 ~ 10000.000	0	Position value on coordinate system (Used in MOVT				
			command)				

- 1. When using MOVT while giving commands to robot, assigned position value allows one of P0  $\sim$  P15 depending on contact values IO\_POS(3  $\sim$  0), and when contact point MOVT\_ST is '1', movement begins.
- 2. When shifted to coordinate '360.000' in machinery structure, it returns to the start point.
- 3. To move from the current position '359.000' to '0.000', as much as '359.000' is needed for movement. But, when any direction will do, '0.000' and '360.000' are identical therefore movement from '359.000' to '1.000' is simply made, it is possible to reach the desired point. In this case, when T\_CYCLE value is set to '360.000', movement is made automatically in a closer direction when MOVT command is delivered. This function is available for use only in an incremental encoder.
- 4. When T\_CYCLE function is used with pneumatic pipes or wires in the load, wires may be tangled so avoid using.
- 5. This function is not used when setting T\_CYCLE value to "0.000".



## **Caution**



Auto

5.3.3 How to Set Operation(OPER) related Parameters

Involved in setting parameters related to controller operations, such as executable program selection, origin run method.

#### 5.3.3.1 MODE

Setting in

Feeding

Power			
Set position	OPER ⇒ MODE ⇒ AUTO	_PLC, AUTO_	ORG
Parameter	Set range	Default value	Description
AUTO_PLC	0 ~ 1 (1:PLC Auto Run)	0	Auto PLC run in feeding power
AUTO_ORG	0 ~ 1 (1:ORG Auto Run)	0	Auto Origin run in feeding power

## Reference

Run

- 1. Set AUTO\_PLC value to '1', and the PLC program selected from PLC\_PGM parameter at the time of feeding power begins to run automatically. At this moment, an alarm sounds when the corresponding PLC program has not been written or there is any grammatical error.
- 2. Set AUTO\_ORG value to'1', automatic home return operation begins according to the method set in ORIGIN\_RULE parameter at the time of feeding power. (Comes under general incremental encoder)



## Caution



Smoothing Fil	ter Acceleration,	/Deceleration	Setting
---------------	-------------------	---------------	---------

Set position	OPER ⇒ MODE ⇒ <b>S_MC</b>	DE	
Parameter	Set range	Default value	Description
	0 : Filter not used		
	1 : 2 (msec)		
	2 : 5 (msec)		
S MODE	3 : 11 (msec)		Time constant for acceleration/deceleration filters
3_IVIODE	4 : 23 (msec)	3	Time constant for acceleration/deceleration litters
	5 : 47 (msec)		
	6 : 95 (msec)		
	7 : 191 (msec)		

1. An acceleration/deceleration calculator calculates acceleration/deceleration waveforms to the taget point according the set parameter.

A trapezoidal speed waveform has each of its corners generate step-type torque (acceleration/deceleration torque) and may generate vibrations due to the step-type torque depending on the machine.

To reduce this phenomenon, either set acceleration/deceleration time longer or adjust S\_MODE values.

- 2. The filter operated by S\_MODE is the 1st delay-type filter. There is a difference depending on acceleration/deceleration time settings, but when using S\_MODE, the time about 4 times (maximum 8 times) longer than the filter time constant is added to movement operation when compared to trapezoidal acceleration/deceleration.
- 3. When the delay by S\_MODE filter goes way too much, extend acceleration/deceleration time and use a short time constant filter, which can ultimately reduce operating time.
- 4. S\_MODE operation applies to all movement commands.





Home Retur	n Method Se	tting						
Set position	Parameter Set range Default value Description  Set value Description  Origin operation method  Set value Description  Origin operation not done  1, 2 CW switch  3, 4 CCW switch							
Dawanastan	Catuana	Default		Description				
Parameter	Set range	value		Description				
				Origin operation method				
			Set value	Description				
							0	Origin operation not done
	RG_RULE 0 ~ 16						1, 2	CW switch
ORG_RULE	0 ~ 16	0	5, 6	CW direction, ORG switch				
			7, 8	CCW direction, ORG switch				
			9, 10	CW→CCW direction, ORG switch				
			11, 12	CCW→CW direction, ORG switch				
			13, 14	CW Damper				
ı			15, 16	CCW Damper				

- 1. The final signal where the origin is determined is Z-phase of the encoder.
- 2. Forward direction in terms of the servo motor is when operating in order of U-phase→V-phase →W-phase. Installation should be made at the end of the forward rotation when using a CCW Limit switch. (CW is reverse direction)
- 3. Final origin positions vary depending on how to perform odd number(1  $\sim$  15), even numbers(2  $\sim$  16).
  - (1) Odd number:
    - Final point of arrival = Final Z-phase pulse position + ORG\_OFS parameter set value
    - Final coordinate value is '0.000.
  - (2) Even number:
    - Final point of arrival = Final Z-phase pulse position
    - Final coordinate value is " ORG\_OFS set value ".
- 4. Origin operation allows the use of DFT\_ACC and DFT\_DEC as acceleration/deceleration time.
- 5. Upon receipt of origin command signal, it switches to Servo ON status automatically even in Servo OFF status. ORG\_SV (OPER→ETC→ORG\_SV) parameter can be used to determine Servo ON/OFF when the origin operation is completed.



- ABS mode enables encoder value to reset by following ORIGIN setting > MTUN(Multi Turn Clear).
- ABS mode does not allow AUTO\_ORG function to be applied, enabling MTUN(Multi Turn Clear) or CAL(End Position Calibration) on T/P.
- > Incorrect parameter settings may damage the controller or the device, and may cause a malfunction.



1. ORG\_RULE Set Value 1

Moves in CW direction to detect CW sensor and search for Z-Phase. The search point is ORG\_OFS value and moves to 0.000 point from the position.

MOTOR	MSMR	ORG_RULE	1	OR	ORG_OFS 10.000 MOV_POL			1	
	Dia	gram			Step	Description			
ccw		RG (Move to CW sensor	cw		1	Move to CV (Move at sp	V sensor. need of ORG_SPD	0)	
	Z-phase search						Z-phase search (Move at speed of ORF_SPD1)		
							Complete Z-phase search. (Current position = ORG_OFS)		
					4	Move to 0.0 (Move at sp	000 peed of DEF_SPD)		
		0.000 ORG_OFS (10.000)			5	Complete o	rigin operation		

ORG\_RULE Set Value 2
 Moves in CW direction to detect CW sensor and search for Z-Phase. The search point is ORG\_OFS value.

MOTOR	l	MSI	MR	ORG_RULE		ORG_C	OFS	10.000	MOV_POL	1	
			Diagra	am		Step	Description				
CCW	CCW Current ORG CW						_	Move to CW sensor. (Move at speed of ORF_SPD0)			
	Move to CW sensor  z-phase					2		Z-phase search (Move at speed of ORF_SPD1)			
						3	Complete Z-phase search. (Current position = ORG_OFS)				
	10.000						Com	nplete origi	n operation.		



- According to parameter SENSOR value, it is possible to set NO or NC for ORIGIN and LIMIT(CW, CCW) sensor. (Refer to Servo Setting 4 in 5.2.3.4 ETC.)
- Acceleration/deceleration time when doing origin operation allows the use of DFT\_ACC and DFT\_DEC parameters.
- ORG\_SV parameter can be used to set whether to keep SERVO ON following the completion of origin operation using parameters.



3. ORG\_RULE Set Value 3

Moves in CCW direction to be placed in the sensor, assigning where Z-Phase is found to ORG\_OFS value. Moves to 0.000 point from the assigned point.

MOTOR	MSMR	ORG_RULE	3	OR	G_OFS	10.000 MOV_POL 1				
	Dia	gram			Step	Description				
¦ DAMPER	CCW	! Current O	! I	,	1	Move to CC (Move at sp	CW sensor. need of ORG_SPD	0)		
	z-phase search Offset value (-10.000)						Z-phase search (Move at speed of ORG_SPD1)			
							Complete Z-phase search (Current position = ORG_OFS)			
	ORG_OFS	0.000		_	4	Move to 0.0 (Move at sp	000. Deed of DEF_SPD)			
	(10.000)				5	Complete o	rigin operation.			

ORG\_RULE Set Value 4
 Moves in CCW direction to be placed in the sensor, assigning where Z-Phase is found to ORG\_OFS value.

MOTOR	MSMR	ORG_R	ULE	4	ORG_C	)FS	FS 10.000 MOV_POL		1	
	Diagra	am			Step	Description				
ccw							ve to CCW ve at speed	sensor. d of ORG_SPD0	))	
Move	Move to CCW						Z-phase search (Move at speed of ORG_SPD1)			
z-phase search	z-phase search				3	Complete Z-phase search (Current position = ORG_OFS)			)	
10.000	·	:	<del></del>		4	Con	nplete origi	in operation.		



- According to parameter SENSOR value, it is possible to set NO or NC for ORIGIN and LIMIT(CW, CCW) sensor. (Refer to Servo Setting 4 in 5.2.3.4 ETC.)
- Acceleration/deceleration time when doing origin operation allows the use of DFT\_ACC and DFT\_DEC parameters.
- ORG\_SV parameter can be used to set whether to keep SERVO ON following the completion of origin operation using parameters.



ORG\_RULE Set Value 5
 Search for ORG sensor in CW direction. The sensed position is assigned to ORG\_OFS value.
 Move to 0.000 poistion from the assigned position to complete the origin operation.

MOTOR	MSMR	ORG_F	RULE	5	ORG_C	RG_OFS 10.000 MOV_POL		1		
	Diag	ram			Step	Description				
ccw	! Current	cw		1	dire	ction.	sensor in CW d of ORG_SPD0	)		
	Move to ORG sensor in  Offset value(-10.000)						Complete movement of ORG sensor (Current position = ORG_OFS)			
		3	Move to 0.000. (Move at speed of DEF_SPD)							
	0.000 ORG_OFS (10.000)						Complete origin operation.			

ORG\_RULE Set Value 6
 Search for ORG sensor in CW direction. The sensed position is assigned to ORG\_OFS value.

MOTOF	₹	MSMR	ORG_F	RULE	6	ORG_OFS		10.000	MOV_POL	1
		Diagra	ım			Step	Description			
ccw	CCW Current ORG CW						Move to ORG SENSOR in CW direction. (Move at speed of ORG_SPD0)			
	Move to CW sensor						Complete movement of ORG sensor. (Current position = ORG_OFS)			
			10.000			3	Con	nplete orig	jin operation.	



- LIMIT(CW, CCW) Alarm occurs when moving ORG sensor in the reverse direction in ORG\_RULE 5, 6.
- According to parameter SENSOR value, it is possible to set NO or NC for ORIGIN and LIMIT(CW, CCW) sensor. (Refer to Servo Setting 4 in 5.2.3.4 ETC.)
- Acceleration/deceleration time when doing origin operation allows the use of DFT\_ACC and DFT\_DEC parameters.
- ORG\_SV parameter can be used to set whether to keep SERVO ON following the completion of origin operation using parameters.



ORG\_RULE Set Value 7
 Search for ORG sensor in CCW direction. The sensed position is assigned to ORG\_OFS value.
 Move to 0.000 position from the assigned position to complete the origin operation.

MOTOR	MSMR	ORG_RULE	7	ORG_	OFS	10.000	MOV_POL	1
	Diagra	am		Step		Des	cription	
ccw	ORG	Current CW	_	1	direct	tion.	ensor in CCW of ORF_SPD0)	
Offset value(-1		in CCW direction 이동		2			ment of ORG ser n = ORG_OFS)	isor
			_	3		e to 0.000 e at speed	of DEF_SPD)	
	RG_OFS L0.000)			4	Comp	olete origin	operation.	

ORG\_RULE Set Value 8
 Sear for ORG sensor in CCW direction. The sensed position is assigned to ORG\_OFS value.

MOTOR	MSMR	ORG_RULE	8		OR	G_OFS	10.000	MOV_POL	1
	Diagran	n		Ste	ер		Desci	ription	
ccw c	PRG Move to CW Ser	Current CW		1	l	directio	n	sor in CCW f ORF_SPD0)	
	0.000	isor		2	2			ent of ORG se = ORG_OFS)	nsor
1	0.000			3	3	Comple	te origin c	peration.	



- Alarm occurs as shown below when moving in the reverse direction of ORG sensor in ORG\_RULE 7,8.
- According to parameter SENSOR value, it is possible to set NO or NC for ORIGIN and LIMIT(CW, CCW) sensor. (Refer to Servo Setting 4 in 5.2.3.4 ETC.)
- Acceleration/deceleration time when doing origin operation allows the use of DFT\_ACC and DFT\_DEC parameters.
- ORG\_SV parameter can be used to set whether to keep SERVO ON following the completion of origin operation using parameters.



9. ORG\_RULE Set Value 9

Search for CW sensor in CW direction. Search for ORG sensor after being sensed. The position where ORG sensor is sensed is assigned to ORG\_OFS value. Move to 0.000 position from the assigned position to complete the origin operation.

MOTOR	MSMR	ORG_RULE	9	ORG_0	OFS	10.000	MOV_POL	1
	Diagra	am		Step		Des	cription	
CCW	! ! ORG Current	·		1		e in CW dire e at speed	ection. of ORF_SPD0)	
	N	Nove to CW Sensor	_	2		e ORG senso e at speed	or. of ORF_SPD0)	
	Search	for ORG sensor		3			ment of ORG ser ı = ORG_OFS)	nsor.
Offset value(-	10.000)			4	_	e to 0.000 e at speed	of DEF_SPD)	
0.000 O	: ! RG_OFS	!	_	5	Comp	olete origin	operation.	

10. ORG\_RULE Set Value 10

Search for CW sensor in CW direction. Search for ORG sensor after being sensed.

The position where ORG sensor is sensed is assigned to ORG\_OFS value.

MOTOR	MSMR	ORG_RULE	10	ORG_C	DFS	10.000	MOV_POL	1
	Diagr	am		Step		De	scription	
	!!!	1		1		ve in CW o	direction. ed of ORF_SPD	00)
CCW 0	RG Current	CW Nove to CW Sensor		2		VE ORG S ove at spee	ENSOR ed of ORF_SPD	00)
	Search f	or ORG sensor		3	sen	sor	vement of ORG	
10	.000	·		4	Cor	mplete orig	gin operation.	



- According to parameter SENSOR value, it is possible to set NO or NC for ORIGIN and LIMIT(CW, CCW) sensor. (Refer to Servo Setting 4 in 5.2.3.4 ETC.)
- Acceleration/deceleration time when doing origin operation allows the use of DFT\_ACC and DFT\_DEC parameters.
- ORG\_SV parameter can be used to set whether to keep SERVO ON following the completion of origin operation using parameters.



## 11. ORG\_RULE Set Value 11

Search for CCW sensor in CCW direction. Search for ORG sensor after being sensed.

The position where ORG sensor is sensed is assigned to ORG\_OFS value.

Move to 0.000 position from the assigned position to complete the origin operation.

	MOTOR	MSMR	ORG_RULE	11	ORG_	OFS	10.000	MOV_POL	1
		Diagra	am		Step		Des	cription	
	, ccw	Cu	rrent ORG CW		1		e in CW dire e at ORF_SI	ection. PD0 speed)	
•	<del></del>	e to CW Sensor	THERE SING EW	_	2		e to ORG se e at ORF_SI		
	Se	Search for ORG sensor				Complete movement of ORG ser (Current position = ORG_OFS)			
			Offset value(-10.000)		4		e to 0.000. e at speed	of DEF_SPD.)	
-			0.000 ORG_OFS	_	5	Comp	olete origin	operation.	

## 12. ORG\_RULE Set Value 12

Search for CCW sensor in CCW direction. Search for ORG sensor after being sensed. The position where ORG sensor is sensed is assigned to ORG\_OFS value

MOTOR	MSMR	ORG_RULE	12	ORG_0	OFS	10.000	MOV_POL	1
	Diagra	ım		Step		De	scription	
, ccw	, ORG	' ' Current CW		1	_	ve in CW d ve at ORF_	irection. SPD0 speed.)	
<del></del>	ove to CW Sensor			2	_	ve to ORG ve at ORF_	sensor. SPD0 speed.)	
Search fo	or ORG sensor			3	sens	or.	rement of ORG on = ORG_OFS	)
		10.000		4	Con	plete orig	in operation.	



- According to parameter SENSOR value, it is possible to set NO or NC for ORIGIN and LIMIT(CW, CCW) sensor. (Refer to Servo Setting 4 in 5.2.3.4 ETC.)
- Acceleration/deceleration time when doing origin operation allows the use of DFT\_ACC and DFT\_DEC parameters.
- ORG\_SV parameter can be used to set whether to keep SERVO ON following the completion of origin operation using parameters.



## 13. ORG\_RULE Set Value 13

Sear for Damper in CW direction. Search for Z-phase when the torque with ORG\_TRQ error occurs. The position where Z-phase is found is assigned to ORG\_OFS value.

Move to 0.000 position from the assigned position to complete the origin operation.

MOTOR	MSMR	ORG_RULE	13	ORG_C	)FS	10.000	MOV_POL	1
	Diag	ram		Step		Des	cription	
ccw	ORG Current	CW DAMPER	₹ <u> </u>	1	Dan	nper.	irection to d of ORG_SPD0	).)
		Z-phase Search		2		nase search ve at spee	n d of ORG_SPD1	.)
		<b>—</b>		3			nase search. on = ORG_OFS	)
		Offset value(-10.000)		4	_	ve to 0.000 ve at spee	d of DEF_SPD )	
		0.000 ORG_OFS (10.000)		5	Con	nplete orig	in operation.	

#### 14. ORG\_RULE Set Value 14

Sear for Damper in CW direction. Search for Z-phase when the torque above ORG\_TRQ occurs. The position where Z-phase is found is assigned to ORG\_OFS value

MOTOR	MSMR	ORG_RULE	14	ORG_0	OFS	10.000	MOV_POL	1
	Diagr	am		Step		Des	scription	
CCW	! ! ORG Current	r r CW DAMPER		1			lirection to dared of ORG_SPD	
	Move to	Damper in CW Direction	_	2		hase searc ve at spee	h ed of ORG_SPD	1)
		Z-phase Search		3			hase search. ion = ORG_OF:	S)
i	<del>'</del>	10.000	-	5	Con	nplete orig	in operation.	



- Over Current Alarm occurs depending on MOV\_POL value and ORG\_OFS directional conditions.
- According to parameter SENSOR value, it is possible to set NO or NC for ORIGIN and LIMIT(CW, CCW) sensor. (Refer to Servo Setting 4 in 5.2.3.4 ETC.)
- Acceleration/deceleration time when doing origin operation allows the use of DFT\_ACC and DFT\_DEC parameters.
- ORG\_SV parameter can be used to set whether to keep SERVO ON following the completion of origin operation using parameters
- When performing the origin using Damper with set values for ORG\_TRQ set to high, it may cause damage to controller and mechanism.



## 15. ORG\_RULE Set Value 15

Search for damper in CW direction. Search for Z-phase in the event of the torque above ORG\_TRQ. The sensed position is assigned to ORG\_OFS value.

Move to 0.000 position from the assigned position to complete the origin operation.

MOTOR	MSMR	ORG_RULE	15	ORG_C	OFS	10.000	MOV_POL	1
	Diagr	am		Step		Des	cription	
ccw	ORG Current	CW DAMPER	_	1			rection to dam d of ORG_SPD0.	
	Move to	Damper in CW Direction 2		2		nase search ve at speed	d of ORG_SPD1)	)
		Offset value(-10.000)		3			ase search on = ORG_OFS)	
		0.000 ORG_OFS	_	4		re to 0.000. ve at speed	d of DEF_SPD )	
		(10.000)		5	Com	ıplete origi	n operation.	

## 16. ORG\_RULE Set Value 16

Search for damper in CW direction. Search for Z-phase when the torque above ORG\_TRQ occurs. The sensed position is assigned to ORG\_OFS value.

MOTOR	MSMR	ORG_RULE	16	ORG_0	OFS	10.000	MOV_POL	1
	Diagra	am		Step		Des	scription	
DAMPER CCV		ent ORG CW	_	1			lirection to dared of ORG_SPD	
	oer in CW Direction			2		nase searc ve at spee	h d of ORG_SPD	1)
Z-phase Search			-	3			hase search. ion = ORG_OF	S)
10.000				4	Con	nplete orig	in operation.	



- Over Current Alarm occurs depending on MOV\_POL value and ORG\_OFS directional conditions.
- According to parameter SENSOR value, it is possible to set NO or NC for ORIGIN and LIMIT(CW, CCW) sensor. (Refer to Servo Setting 4 in 5.2.3.4 ETC.)
- Acceleration/deceleration time when doing origin operation allows the use of DFT\_ACC and DFT\_DEC parameters.
- ➤ ORG\_SV parameter can be used to set whether to keep SERVO ON following the completion of origin operation using parameters.
- When performing the origin using Damper with set values for ORG\_TRQ set to high, it may cause damage to controller and mechanism.



#### 5.3.3.2 JOG

JOG Operatio	n Setting		
Set position	OPER ⇒ JOG ⇒	JOG_SPI	DO, JOG_SPD1, JOG_SPD2, JOG_SPD3
		JOG_R	ESO, JOG_RES1, JOG_RES2, JOG_RES3
Daramatar	Cot range	Default	Description
Parameter	Set range	value	Description
JOG_SPD0		100	
JOG_SPD1	1 10000	500	IOC management around
JOG_SPD2	1 ~ 10000	1000	JOG movement speed
JOG_SPD3		3000	
JOG_RES0		0.250	
JOG_RES1	0 00000 000	0.500	One-time movement amount in inch JOG movement
JOG_RES2	0 ~ 99999.999	0.750	One-time movement amount in filth JOG movement
JOG_RES3		1.000	

#### Reference

- 4-stage JOG speed can be used in JOG operation.
   Movement speed value is set in JOG\_SPD(0 ~ 3).
- 2. When JOG\_SPD(0 ~ 3) set value is '10000', operation is made at assigned speed of LMT\_SPD(MECH). Speed is determined according to the rate when below '10000'. (ex: 50% when set to 5000)
- 3. Movement amount for one-time movement command is set in 4 stages in IJOG operation. Movement amount is entered with a user coordinate value.
- 4. JOG movement is stopped when facing CW(CCW) Limit switch while running JOG/JJOG.
- 5. In case of running by JOG/IJOG, DFT\_ACC and DFT\_DEC are used as acceleration/deceleration time.
- 6. Upon receipt of JOG/IJOG command, it switches automatically from servo Off to servo On. JOG\_SV(OPER→SET→ETC→JOG\_SV) can be used to turn the sero ON/OFF after JOG/IJOG operations are finished.



## Caution



#### 5.3.3.3 DFT

1 ~ 500 (10ms)

1 ~ 500 (10ms)

Basic Movem	ent Conditions Settir	ng							
Set position OPER ⇒ DFT ⇒ DFT_SPD, DFT_ACC, DFT_DEC									
Parameter	Set range	Default value	Description						
DFT_SPD 1 ~ 10000 1000		1000	Basic movement speed value						

## Reference

DFT\_ACC

DFT\_DEC

1. When operating the robot program, it operates on DFT\_SPD value through SPD command prior to setting speed. When pausing robot operation and restarting, it operates at the speed prior to pausing it, and it operates on DFT\_SPD set value when starting the operation from the beginning.

Basic acceleration time value

Basic deceleration time value

- 2. When the set value is '10000' at DFT\_SPD, it runs at the speed assigned in LMT\_RPM(MECH). Speed is determined according to the rate when below '10000'. (ex: 50% when set to '5000')
- 3. Application time of the acceleration time value set to DFT\_ACC.

20

20

- (1) Applies when putting the robot program to RUN from the beginning.
- (2) Applies when moving by JOG/IJOG.
- (3) Applies during Origin operation.
- 4. Application time of the deceleration time value set to DFT\_DEC.
  - (1) Applies when putting the robot program to RUN from the beginning.
  - (2) Applies when moving by JOG/IJOG.
  - (3) Applies during Origin operation.
- 5. DFT\_DEC value is time taken for decelerating from MAX\_RPM to stop.
  - Ex) When set to 10, speed is reduced by 0.10[sec].



## Caution



Origin Return Speed Setting					
Set position	OPER ⇒ DFT	OPER ⇒ DFT ⇒ <b>ORG_SPD0</b> , <b>ORG_SPD1</b>			
Parameter	Set range	Default value	Description		
ORG_SPD0	1 ~ 10000	1000	Operating speed until final contact is confirmed in origin operation		
ORG_SPD1	1 ~ 10000	500	Operating speed from final contact to Z-phase in origin operation.		

- 1. Moves at speed of ORG\_SPD0 to the origin in origin operation, moving at speed of ORG\_SPD1 to Z-phase point from the point.
- 2. When selecting ORG\_RULE(MODE) that moves to ORG\_OFS(MECH) set by the user, the range from Z-phase to the offset is operated by the value set in DFT\_SPD(DFT).
- 3. When  $ORG\_SPD(0 \sim 1)$  set value is '10000', it operates by LMT\_RPM(MECH) set value. Speed is determined according to the rate when below '10000'. (ex: 50% when set to '5000')
- 4. Acceleration and deceleration settings during origin operation are performed by DFT\_ACC, DFT\_DEC value.
- 5. Upon receipt of origin command, it switches automatically from servo OFF to servo ON. ORG\_SV(ETC) can be used to turn ON/OFF the servo after origin operation is finished.



- > Speed setting parameters regarding origin return (ORG\_SPD0, ORG\_SPD1) are only for an INC serial encoder.
- > Incorrect parameter settings may damage the controller or the device, and may cause a malfunction.



Operation Speed Setting by Contact
------------------------------------

Set position	OPER ⇒ DFT ⇒ IO_SPD0, IO_SPD1, IO_SPD2, IO_SPD3				
Daramatar	Set range	Default	Description		
Parameter		value	Description		
IO_SPD0		500			
IO_SPD1	1 ~ 10000	1000	Movement speed when setting the speed to SPD IOSPD while		
IO_SPD2		1500	running the robot program		
IO_SPD3		2000			

- 1. This function is used in connection with contact values IOSPD1, IOSPD0.
- 2. When SPD IOSPD command is used whiel the robot program is running, one of speed vales  $IO\_SPD(0 \sim 3)$  is selected and used according to contact values IOSPD1, IOSPD0.

IOSPD1	IOSPD0	Selected Speed Value	
OFF (0)	OFF (0)	IO_SPD0	
OFF (0)	ON (1)	IO_SPD1	
ON (1)	OFF (0)	IO_SPD2	
ON (1)	ON (1)	IO_SPD3	

3. When  $IO_SPD(0 \sim 3)$  is set to '10000', it operates at the speed set in LMT\_RPM (MECH) parameter. Speed is determined according to the rate when below '10000'. (ex: 50% when set to 5000)



# Caution



## 5.3.4 SET

## 5.3.4.1 COM

Set position	OPER => SET => ETC => BIT RATE1, BIT RATE2, BIT RATE3, DATA MODE, MY_ID				
Parameter	Set range	Default	Description		
Parameter	Set range	value	Description		
BIT RATE1	0 ~ 3 0 Sets COM1 communication speed		Sets COM1 communication speed		
BIT RATE2	0 ~ 3		Sets COM2 communication speed		
BIT RATE3	0 ~ 3 1 Sets COM3 communication speed		Sets COM3 communication speed		
DATA MODE	0 ~ 99	0	Determines DATA save option		
MY_ID	0 ~ 255	0	Assigns 422 multi-communication address		

## Reference

- 1. BITRATE(1  $\sim$  3)
  - (1) Set communication speeds COM1, 2, 3 by setting BITRATE 1, 2, 3.
  - (2) When setting a number other than the assigned value, select it to 9,600bps.

Set value	Speed value
0	9,600bps
1	19,200bps
2	38,400bps
3	115,200bps

## 2. DATA MODE

Set value	Description			
0	None.			
10	CC Link communication mode			
20 Profibus communication mode				
40	CC Link B/D RS-232C communication mode			
50 DeviceNet communication mode				

- 3. MY\_ID (Function expected to be implemented)
  - (1) When using 422 multi-communication, assign addresses to each controller.



5-33

# Caution



#### 5.3.4.2 ETC

Servo Operat	ion Condition Setting 1				
Set position	ion OPER => SET => ETC ⇒ FLO_ERR, INPOS, INI_TRQ				
Set range	Set range	Default value	Description		
FLO_ERR	0.001 ~ 10000.000	30.00	Criteria for error occurrence when movement error is in excess range		
INPOS	0.001 ~ 99999.999	0.05	Range of error where movement is judged as completed		
INI_TRQ	-300 ~ 300 (%)	0	Initial torque when servo is ON		

#### Reference

- 1. FLO\_ERR(Following Error)
  - (1) All movement operations make use of trapezoidal acceleration/deceleration movement.
  - (2) Servo control unit calculates trapezoidal acceleration/deceleration waveforms internally and controls the servo motor according to calculated position and speed.
  - (3) When controller gain is incorrectly set and wiring error takes place, a substantial difference arises between the calculated position and the actual servo position.
  - (4) In this case, use FLO\_ERR value as the error refernece value.

#### 2. IN POSITION

- (1) When the difference between the servo motor position and the target position enters into the values assigned to INPOS when it comes to each movement and operation commands, it recognizes as position arrival state (IN POSITION).
- (2) INPOS value is used also as the basis for determining the completion of movement operation when running the robot program.
- (3) INPOS value and FLO\_ERR value make use of user coordinate unit.
- 3. INI\_TRQ (Function expected to be implemented)
  - (1) This parameter is used to prevent initial drooping in gravity load when releasing a brake and switches to servo operation.
  - (2) When a negative number('-') is set, it operates by reverse torque.
  - (3) Possible setting range is -300 ~ 300[%] based on rated torque.



## **Caution**



## Servo Operation Condition Setting 2

Set position	OPER => SET => ETC => <b>JOG_SV, ORG_SV, ORG_TRQ,, BACKLASH</b>				
Parameter	Set range	Default value	Description		
JOG_SV	0 ~ 1	0	Selects servo ON/OFF following JOG / IJOG		
ORG_SV	0 ~ 1	0	Selects servo ON/OFF following Origin		
ORG_TRQ	50 ~ 200 (%)	50	Torque in Damper Origin		
BACKLASH	-99999.999 ~ 99999.999	0	BACKLASH compensation		

#### Reference

- 1. JOG\_SV
  - (1) When setting JOG\_SV to '1', Servo ON is kept after running JOG IJOG.
  - (2) When the value is set to '0', Servo OFF comes after the movement.
- 2. ORG\_SV
  - (1) When setting ORG\_SV to '1', Servo ON is kept after Origin operation.
  - (2) When the value is set to '0', Servo OFF comes after Origin operation.
- 3. ORG\_TRQ
  - (1) ORG\_TRQ determines whether the mechanism and Damper have had a collision in operating Damper Origin.
  - (2) When ORG\_TRQ vaue is 100[%] and a torque is rated during Damper Origin operation, it is judged as Damper collision and begins to rotate in reverse direction. (When ORG\_RULE is set to no.13 ~ 16 Damper Origin)
  - (3) Origin detection signal is encoder Z Pulse.
- 4. BACKLASH (Function expected to be implemented)
  - (1) Software compensation comes when mechanical BACKLASH occurs. (Compensated by entering as many as BACKLASH number.)



## Caution



## Servo Operation Condition Setting 3

Set position	OPER => SET => ETC => BCD_READ, USER MODE, SENSOR				
Parameter	Set range	Default Description			
BCD READ	0, 1				
HW_LIMIT	0, 1 0 Sets Limit mode				
USER MODE	0 ~ 999	0	Sets user mode		
SENSOR	0 ~ 99	0	Sets sensor type		

## Reference

## 1. BCD\_READ

Determines whether to use BCD DATA. (0: Use, 1: Not use)

## 2. HW\_LIMIT

Sets operating conditions for LIMIT sensor according to MODE.

MODE	Direction	Limit Para		
WIODE	Direction	ON	OFF	
IDLE	forward	Alarm	Don't care	
IDLE	reverse	Alarm	Don't care	
JOG	forward	Stop	Stop	
(FWRD included)	reverse	Alarm	Don't care	
ORG	forward	Org	Org	
OKG	reverse	Alarm	Don't care	
RUN	forward	Alarm	Alarm	
KON	reverse	Alarm	Don't care	

# 3. USER MODE

Sets the following to 7-Segment : status display, I/O input/output and release System Emergency status. For further detail, refer to 'Ch.17 Front 7-Segment Display'.

Set value	Description					
911	Release SYSTEN EMERGENCY					
200	Input contact display on Front 7 Segment					
201	Output contact display on Front 7 Segment					
202	DC Link voltage display on Front 7 Segment					

## 4. SENSOR.

LIMIT and ORGIN sensor type (NC/NO) setting.

Setting	LIMIT	ORIGIN
0	NC	NC
1	NC	NO
10	NO	NC
11	NO	NO



5-36

## **Caution**



Set position	OPER => SE	OPER => SET => ETC => ROB_PGM, PLC_PGM					
Parameter	Set range	Default value	Description				
ROB_PGM	0~8	0	Selects a robot program to run				
PLC_PGM	0~3	0	Selects a PC program to run				

# 1. ROB\_PGM

- (1) When ROB\_PGM is set to  $0 \sim 7$ , the robot operates on the corresponding program numbers.
- (2) When ROB\_PGM is set to 8, the robot operates on program number for I/O contact  $PGM\_SEL(2 \sim 0)$  values.

PGM_SEL2	PGM_SEL1	PGM_SEL0	Selected Robot Program
OFF (0)	OFF (0)	OFF (0)	NO. 0
OFF (0)	OFF (0)	ON (1)	NO. 1
OFF (0)	ON (1)	OFF (0)	NO. 2
OFF (0)	ON (1)	ON (1)	NO. 3
ON (1)	OFF (0)	OFF (0)	NO. 4
ON (1)	OFF (0)	ON (1)	NO. 5
ON (1)	ON (1)	OFF (0)	NO. 6
ON (1)	ON (1)	ON (1)	NO. 7

# 2. PLC\_PGM

(1) Program numbers run by PLC\_RUN command are determined by PLC\_PGM value.



## **Caution**



# **TP Operation Setting**

Set position	OPER => SE	OPER => SET => ETC => <b>TP_TYPE, TP_LINE, JOG_DMAN</b>				
Parameter	Set range	Default	Description			
		value	Description			
TP_TYPE	0, 1	0	Sets TP type( NC / NO )			
TP_LINE	0, 1	0	Sets the number of TP Lines			
JOG_DMAN	0, 1	0	Sets Deadman function			

## Reference

- 1. TP\_TYPE
  - (1) When setting'0', it is set to 'Normal Open(NO)'.
  - (2) When setting '1', it is set to 'Normal Close(NC)'.
- 2. TP\_LINE
  - (2) When setting '0', it applies to 4 line TP.
  - (3) When setting '1', it applies to 8 line TP.
- 3. JOG\_DMAN
  - (1) When making JOG operation, whether to use Deadman key function is determined. ('0': Used, '1': Not used)



# Caution



5.3.4.3 IP

IP Operation Setting					
Set position   OPER => SET => IP => I			PNETSIZE, IP_ADD1, IP_ADD2, IP_ADD3, IP_ADD4, G/W_ADD1,		
	G/W_ADD2,	G/W_ADD	3, G/W_ADD4		
Parameter	Set range	Default	Description		
rarameter	Set range	value	Description		
PNETSIZE	0, 1	1	Sets Data Map size of PROFINET among OPTIONs		
IP_ADD1	0, 255	192	Cata ID adduces		
IP_ADD2	0, 255	168	Sets IP address.		
IP_ADD3	0, 255	1	(IP_ADD1 . IP_ADD2 . IP_ADD3 . IP_ADD4) (Default value : 192 . 168 . 1 . 0)		
IP_ADD4	0, 255	0	(Default value : 192 : 100 : 1 : 0)		
G/W_ADD1	0, 255	192	Cata Catanian adduses		
G/W_ADD2	0, 255	168	Sets Gateway address.		
G/W_ADD3	0, 255	1	(G/W_ADD1 . G/W_ADD2 . G/W_ADD3 . G/W_ADD4) (Default value : 192 . 168 . 1 . 4)		
G/W_ADD4	0, 255	4	(Delauit value : 192 : 100 : 1 : 4)		

- 1. PNETSIZE
  - (1) For '0' setting, INPUT: 8, OUTPUT: 8 are taken as setting.
  - (2) For '1' setting, INPUT: 32, OUTPUT: 32 are taken as setting.
- 2. IP\_ADD1~4
  - (1) Sets IP address.
- 3. G/W\_ADD\_1~4
  - (1) Sets Gateway address.



- Change PNETSIZE, IP, Gateway and turn power OFF/ON.
- When PROFINET options are not set and IP is saved, select 'F4, SAVE' to save to DPRAM in Option Board.
- Incorrect parameter settings may damage the controller or the device, and may cause a malfunction.



## 5.3.5 How to Set Input/Output(I/O) related Parameters

## 5.3.5.1 How to Set System Input Contact

## Common Things for System Input Setting

- 1. System input is installed in B350 ~ B387 of S/W contact.
- 2. Contact address between B000 and B317 is selected among contact areas, the corresponding value is copied by system input and the system function operates.
  - Besides,  $B000 \sim B022$  are input contacts and can also be used as system contact in setting parameters.
  - Non-use contacts in the process of system input is set as 'Not Used'.
- 3. Error occurs when different signals use one identical contact..
- 4. When PLC program produces operation results with a desired contact from system input contact area (B350 ~ B357), system operation by PLC program is also enabled. In this case, the parameter for the contact should be set to 'Not'...
- 5. Parameter is set at 'I/O  $\rightarrow$  INPUT  $\rightarrow$  Contact'.
- 6. Values for all contacts except for contacts CW S/W, CCW S/W, and ORG S/W are changed to new values in every 3[msec].
- 7. For CW S/W, CCW S/W, ORG S/W contact values, their changed values are recognized within 1[msec after input is stabilized.

# Types of Contact

Contact Address	Number of Bytes	Contact Property	Use or Non-use of Input/Output		
B000 ~ B022	3	Input contact	Used as system and user input contacts.		
B030 ~ B047	2	Output contact	Used as system and user output contacts.		
B050 ~ B317	27	Internal contact	Used as user internal contacts.		
B320 ~ B337	3	Reserved	Reserved		
B340 ~ B347	3	Reserved			
B350 ~ B387	4	System input	Used as internal system input contacts.		
D330 ~ D367	4	contact	osed as internal system input contacts.		
B390 ~ B417	3	System output	Used as internal system output contacts.		
D330 19 D417	3	contact	Osed as internal system output contacts.		



## **Caution**



System Input	Setting		
Set position	I/O ⇒ INPI	JT	
Contact name	Bit position	Default value	Description
rob_run	B350	Not Use	<ul> <li>Robot program execution program command ('1')</li> <li>When starting the robot program first time, set parameter values DFT_SPD, DFT_ACC, DFT_DEC as movement conditions prior to beginning the robot program.</li> <li>In case of stopping the ongoing robot program, continue the robot program operation from the status before being stopped.</li> </ul>
PLC_RUN	B351	B000	◆ PLC program start command ('1')
STOP	B352	B001	• Robot program stop command ('1')
RESET	B353	B002	<ul><li>◆ Alarm Reset command ('1')</li><li>◆ Not valid if not in alarm.</li></ul>
SVON	B354	Not Use	◆ Servo ON command ('1')
SVOFF	B355	B003	<ul><li>◆ Servo OFF command ('1')</li><li>◆ Not valid when the robot program is running.</li></ul>
ORIGIN	B356	Not Use	<ul> <li>Origin implementation command('1')</li> <li>Not value when ORG_RULE set value is set to 0 (Origin not implemented).</li> </ul>
STEP_RUN	B357	Not Use	Robot program Step Run command ('1')
PGM_SEL	B360	Not Use	<ul> <li>Robot program reset command ('1')</li> <li>Valid only when the robot program is stopped from making progress.</li> <li>Resets all the progress of the current robot program.         When ROB_PGM is set to 0 ~ 7 range, get the corresponding program ready to be performed, whereas when ROBOT_PGM is set to 8, select the program number according to PGM_SEL(2 ~ 0) value.</li> <li>Reset the program number to run or the step to perform according to the corresponding contact.</li> </ul>
PGM_SEL0	B361	Not Use	
PGM_SEL1	B362	Not Use	Robot program selection code. Input signal
PGM_SEL2	B363	Not Use	♦ A total of 8 programs (0~7) are selectable.





System Input	Setting		]					
Set position I/O ⇒ INPUT			1					
Contact name	Bit position	Default value		Description				
JOG+	B364	Not Use	◆ JOG mov	ement comm	and ('1')			
		◆ When JOG_MODE contact value is 0, JOG operation is r and when 1, IJOG operation made.						
JOG-	B365	Not Use		•	eration, it kee	ns movina wh	nile this Rit is	
700	5505	1101 030			king IJOG ope			
				Bit becomes		ration, it mov	es office ederi	
JOG_SET0	B366	Not Use	◆ Selection	code for JOG	movement c	onditions		
			This contact v	value is used	only in JOG	operation by	JOG+, JOG-	
			contacts.					
			JOG_SET1	JOG_SET0	JOG Mode	IJOG Mode		
JOG_SET1	B367	Not Use	OFF(0)	OFF(0)	JOG_SPD0	JOG_RES0		
			OFF(0)	ON(1)	JOG_SPD1	JOG_RES1		
			ON(1)	OFF(0)	JOG_SPD2	JOG_RES2		
			ON(1)	ON(1)	JOG_SPD3	JOG_RES3		
JOG_MODE	B370	Not Use	<ul> <li>Selecting JOG movement method</li> <li>When JOG_MODE contact value is '0', JOG operation is made, and when '1', IJOG operation is made.</li> <li>This contact value is used only in JOG operation by JOG+, JOG- contacts.</li> </ul>					
IOPOS0	B371	Not Use	◆ Selection	code for mo	ovement posit	ion in MOVT	command of	
IOPOS1	B372	Not Use	the robo	t program				
IOPOS2	B373	Not Use	◆ Used in o	connection wi	th MOVT_ST c	ontact. (0: OFF	, 1: ON)	
IOPOS3	B374	Not Use	IOPO	S7~0	Movement			
IOPOS4	B375	Not Use			Position			
IOPOS5	B376	Not Use		0000	P0			
IOPOS6	B377	Not Use		0001	P1	_		
				0010	P2 :	_		
				1011	P251	_		
IOPOS7	B380	Not Use		1100	P251 P252			
				1101	P253			
			$\wedge$	Caution				





System Input	Setting							
Set position	I/O ⇒ INPI	JT						
Contact name	Bit position	Default value	Description					
IOSPD0	B381	Not Use	◆ Move	ment speed i	n command	SPD IOSPD of	robot program	
			Input sign	al of selected	codes	1	1	
				IOSPD1	IOSPD0	Movement Speed		
IOSPD1	B382	Not Use		OFF(0) OFF(0) ON(1)	OFF(0) ON(1) OFF(0)	IO_SPD0 IO_SPD1 IO_SPD2		
				ON(1)	ON(1)	IO_SPD3		
CW S/W	B383	Not Use	◆ Limit switch value NC(Normal Close)					
CCW S/W	B384	Not Use	<ul> <li>When meeting the switch during Jog operation, the motor does not rotate anymore.</li> <li>When meeting the switch while robot program is in progress, Hardware Limit Alarm occurs.</li> </ul>					
ORG S/W	B385	Not Use	◆ Origin switch value NC(Normal Close)					
MPG_RATE	B386	Not Use	◆ In 'MOVM' command, select the selection input signal for the rate between Movement pulse and feed.    MPG_RATE   Feed Rate Selection					
MOVT_ST	B387	Not Use	<ul> <li>◆ Command for starting movement for MOVT command ( '1' )</li> <li>◆ MOVT command starts to move only when it receives this command, determining a target position according to the contact values IOSPD(3 ~ 0) at the time of receiving this contact input.</li> </ul>					





## 5.3.5.2 How to Set System Output Contact

## Common Things in System Output Setting

- 1. System output is installed in B390 ~ B417 of S/W contact
- 2. System output can be used as an input in PLC program.
- 3. What is needed in the process of system output can be used by being delivered instantly from parameter to output contact before use. (Delivered every 3[msec])
- 4. Parameter is set at 'I/O → OUTPUT → Contact'.

#### Types of Contact

Contact Address	Number of Bytes	Contact Property	Use or Non-use of Input/Output	
B000 ~ B022	3	Input contact	Used as system and user input contacts.	
B030 ~ B047	2	Output contact	Used as system and user output contacts.	
B050 ~ B317	27	Internal contact	Used as user internal contacts.	
B320 ~ B337	2	Reserved	Reserved	
B340 ~ B347	1	Reserved	Reserved	
B350 ~ B387	4	System input contact	Used as internal system input contact.	
B390 ~ B417	3	System output contact	Used as internal system output contact.	



#### Caution

> Incorrect parameter settings may damage the controller or the device, and may cause a malfunction.



System Outpo	ut Setting					
Set position I/O ⇒ OUTPUT						
Contact name	Bit position	Default value			Description	
ALARM	B390	Not Use	<ul> <li>Set(1) is made in the event of an alarm.</li> <li>Comes out as output contacts ALARM(3~0) along with alarm code depending on an alarm type.</li> <li>The alarm being produced only sends the main alarm number and detailed alarm number and content can be identified through T/P. (Refer to Ch.17 Alarm.)</li> </ul>			e main alarm number,
READY	B391	Not Use	* *	completed with	when the power is applied no error found.  e in the alarm status.	and self-diagnosis is
ORIGIN	B392	Not Use	•	Set(1) is made u	ipon completion of Origin	operation.
IN_POS	B393	Not Use	•	<ul> <li>Set(1) is made when the difference between the target position and the current position is within INPOS(ETC) parameter value.</li> </ul>		
ALARM 0	B394	Not Use	Description of alarm codes in the event of alarm			
ALARM 1	B395	Not Use	•	♦ Valid when alarm contact is '1'.		
ALARM 2	B396	Not Use		ALARM 3~0	Description of Alarm Codes	
ALARM 3	B397	Not Use		0000 0001 0010 0011 0100 0101 0110 0111 1000 1001 1011 1110 1110 1111	Normal Condition Over Current (IPM Error) Over Load Over Voltage Over Heat Power Fail Data Back-up Error Encoder Error Hardware Limit Software Limit Following Error Program Error Emergency Stop Over Speed Parameter Error	
BRAKE	B400	Not Use	•		arting the brake of a servo	motor
PGMRUN	B401	Not Use	•	•	e robot program is being	
	1 2.01	1	<u> </u>		- 120t p. ogram to being	

- > In the event of Alarm, Output is unable to be identified due to initialization of B030~B217 area. Run internal PLC to prevent the above area from being initialized.(Refer to '6.1.1 Contact Point Configuration'.)
- Incorrect parameter settings may damage the controller or the device, and may cause a malfunction.

Caution



System Output	Setting						
Set position	I/O ⇒ OUT	PUT					
Contact name	Bit position	Default value		Description			
PGM_NUM0	B402	Not Use	•	Outputs the curren	ntly-set JOB number	to PGM_NUM0 ~ 2	
PGM_NUM1	B403	Not Use		contact.			
				PGM_NUM 2~0	JOB Number		
				000	No.0		
				001	No.1		
				010	No.2		
				011	No.3		
				100	No.4		
PGM_NUM 2	B404	Not Use		101	No.5		
				110	No.6		
				111	No.7		
SVON OUT WARN	B405 B406	Not Use	* *	Set(1) is made prior	n the current Servo ON r to alarm occurrence. to output contacts W	,	
WARN0	B407	Not Use					
WARN1	B410	Not Use	1	WARN 2~0	System warning	1	
				000	Normal		
				001	ABS Low Battery		
				010	Overload		
				:	Reserved		
			1. A	ABS Low Battery :		_	
WARN2	B411	Not Use	C	Occurs when ENC_TYF	PE is set to ABS(2) and	Battery connection is	
VV/ III VZ	WARINZ D411			ot made in normal c		•	
				OverLoad : Occurs when Load fig	ure is over 85%.		
	1	1		<u> </u>			



## Caution

- ➤ In the event of an alarm, Output contact is unable to be identified due to initialization of B030~B217 area. Run internal PLC to prevent the above area from being initialized. (Refer to '6.1.1 Contact Point Configuration'.)
- > Incorrect parameter settings may damage the controller or the device, and may cause a malfunction.



# ch.6 INPUT/OUTPUT(I/O) Connection

# 6.1 I/O Description

#### 6.1.1 Port Structure

- 1) The scope of I/O data consists of 42 ports from B00 to B41, each port consists of 8 bits.
- 2) Each port consists of 8 bits.
- 3) The system contact points are from B350 to B417. Reserved from B320 to B347. Therefore, the available numbers of the contact point are 256 (32  $\times$  8).

Port		Bit Address							
B00	B000	B001	B002	B003	B004	B005	B006	B007	User Input
B01	B010	B011	B012	B013	B014	B015	B016	B017	User Input
B02	B020	B021	B022	-	-	-	-	-	User Input
В03	В030	B031	B032	B033	B034	B035	B036	В037	User Input
B04	B040	B041	B042	B043	B044	B045	B046	B047	User Input
B05	B050	B051	B052	B053	B054	B055	B056	B057	Internal contact
•	•	:	:	:	:	:	:	:	:
B31	B310	B311	B312	B313	B314	B315	B316	B317	Internal contact
B32	B320	B321	B322	B323	B324	B325	B326	B327	
B33	B330	B331	B332	B333	B334	B335	B336	B337	Reserved
B34	B340	B341	B342	B343	B344	B345	B346	B347	
B35	B350	B351	B352	B353	B354	B355	B356	B357	System Input
B36	B360	B361	B362	B363	B364	B365	B366	B367	System Input
B37	B370	B371	B372	B373	B374	B375	B376	B377	System Input
B38	B380	B381	B382	B383	B384	B385	B386	B387	System Input
В39	B390	B391	B392	B393	B394	B395	B396	B397	System Output
B40	B400	B401	B402	B403	B404	B405	B406	B407	System Output
B41	B410	B411	B412	B413	B414	B415	B416	B417	System Output

# **CAUTION**

- ➤ B030~B217 bits will be cleared '0' when the controller is an alarm state, except for while PLC program is running.
- ▶ B220~B310 bits retain the previous state when the controller is in alarm state.
- All I/O bits will be cleared when the power off.



#### 6.1.2 Contact point description

#### 1) User input

The user input could be used as ordinary user input and system input,
 Set up it previously if you use as system input.

#### 2) User output

- The user output can be used as ordinary user output and system output. Set up it previously if you use as system output.
- 3) NPN Type is 2 of NCOM, 3 of PCOM, PNP Type is 3 of NCOM, 2 of PCOM.
- 4) User can treat user I/O directly by controller, outer wiring and PC.
- 5) The internal contact point can use parts of internal memory of controller as a contact point variable, it can be treated by the Program, T/P and PC.
- 6) The state of I/O contact point can confirm real-time by using T/P and PC.
- 7) I/O of system the value of contact point is copied into relating System input, if selecting contact point from B000 to B337 among the parts of contact point by user's setting up parameter necessary for system input, and the function of System operates in accordance with the value.
- 8) System I/O should not be revised freely by user.

## ■ Input contact point

Add.	Description	Add.	Description	Add.	Description
B350	ROB_RUN	B365	JOG-	B382	IOSPD1
B351	PLC_RUN	B366	JOG_SET0	B383	CW S/W
B352	STOP	B367	JOG_SET1	B384	CCW S/W
B353	RESET	B370	JOG_MODE	B385	ORIGIN S/W
B354	SVON	B371	IOPOS0	B387	MOVT_ST
B355	SVOFF	B372	IOPOS1	-	-
B356	ORIGIN	B373	IOPOS2	-	-
B357	STEP	B374	IOPOS3	-	-
B360	PRM_SEL	B375	IOPOS4	-	-
B361	PRM_SEL0	B376	IOPOS5	-	-
B362	PRM_SEL1	B377	IOPOS6	-	-
B363	PRM_SEL2	B380	IOPOS7	-	-
B364	JOG+	B381	IOSPD0	-	-



#### ■ Output contact point

Add.	Description	Add.	Description	Add.	Description
B390	ALARM	B400	BRAKE	B410	WARN1
B391	READY	B401	PGMRUN	B411	WARN2
B392	ORIGIN_OK	B402	PGM_NUM0		
B393	IN_POS	B403	PGM_NUM1		
B394	ALARM0	B404	PGM_NUM2	B402 ~	NOT LICED
B395	ALARM1	B405	SVON OUT	B417	NOT USED
В396	ALARM2	B406	WARN		
B397	ALARM3	B407	WARN0		

# **CAUTION**

- > Be careful that internal contact point and output contact point are not cleared after Alarm and EMG reset.
- ➤ In case of power-OFF, internal contact point and output contact point is cleared as "0.
- > Embedded PLC program keeps operation state after alarm or EMG reset, once it executed.
- > This may not be operated the desirable movement if the process time of embedded PLC program and Robot program contact point and processing time of outer signal not accord. This is no trouble but the case that outer signal is not accorded. Please check processing time of signal.
- > PLC If PLC program in on operation, it retains output and internal contact point even in ALAM state, while output and internal contact point is cleared as "0" if it not on operation.



6.1.3 Signal Format in Connecting Input/Output(I/O) Connectors

## ■ Connecting Input/Output(I/O) Connector

1) Select an input/output contact to use and set a parameter.

## **■** Types of Input-Output contacts

Contact Address	Number of Bytes	Contact Property	Use or Non-use of Input/Output
B000 ~ B022	3	Input contact	Used as system and user input contacts.
B030 ~ B047	2	Output contact	Used as system and user output contacts.
B050 ~ B317	27	Internal contact	Used as user internal contacts.
B320 ~ B337	2	Dagarad	Danamad
B340 ~ B347	1	Reserved	Reserved
B350 ~ B387	1	System input	Used as an internal system input contact.
2330 2307	•	contact	osed as an internal system input contact.
B390 ~ B417	3	System output	Used as an internal system output contact.
5550 · D417	5	contact	osea as an internal system output contact.

- 1) Selecting input/output contacts and setting input/output contacts
  - Inputs to use are assigned in B000 ~ B022 range.
  - Outputs to use are assigned in B030 ~ B047 range.



# ch.7 VIEW Setting

# 7.1 Overview

Capable of setting alarm history, status monitoring on the current motor, whether to use option card and INTEGER values.

Group		Detailed Group			
Name	Description	Name <pa< th=""><th>ge&gt;</th><th>Description</th></pa<>	ge>	Description	
ALARM	Refers to alarm history	HISTOR	Y	Detailed alarm history	
SERVO	Checks out current status	SPD CMD CUR SPD POS CMD CUR POS TORQUE MAXTRQ LOAD POSERR Multi_T SingleT EncTime EncPoll Vdc THERE IS NO OPTION Option1. Insta Option 2. Insta Option 4. DPR S/W	<1/8> <2/8> <3/8> <4/8> <5/8> <6/8>  Illed CC-Lalled PRC alled Dev	Target speed Current speed Target position Current position Current torque value Maximum torque value OverLoad value Position deviation value Multi turn value Single turn value The number of signals disconnected during encoder-controller communication The number of signals going incorrect during encoder-controller communication Current voltage When no option card is present Link : In case CC-Link card is installed OFIBUS : In case PROFIBUS card is installed	
		PARA W/T	<8/8>	Current parameter version  Operation time up to the present	
INT		0 ~ 255		Integer variable	



# 7.2 SERVO STATUS

# ■ Servo Motor Capacity & Constant Check

Detailed Group	Name	Page	Description
	SPD CMD	.1 /0 .	Target speed
	CUR SPD	<1/8>	Current speed
	POS CMD	<2/8>	Target position
	CUR POS	<2/0>	Current position
	TORQUE	, 2 /0 s	Current torque value
	MAXTRQ	<3/8>	Maximum torque value
	LOAD	<4/8>	OverLoad value
	POSERR	<4/0>	Position deviation value
	Multi_T	<5/8>	Multi turn value
	SingleT	<3/0>	Single turn value
	EncTime		The number of signals disconnected during
SERVO	LIICIIIIE	<6/8>	encoder-controller communication
	EncPoll		The number of signals going incorrect during
			encoder-controller communication
	Vdc	<7/8>	Current voltage
	THERE IS NO OPTION	\//\0>	In case no option cards are present
	Option1. Installed CC-Link Option 2. Installed PROFIBUS Option 3. Installed DeviceNet		: In case CC-Link card is installed
			: In case PROFIBUS card is installed
			: In case DeviceNet card is installed
	Option 4. DPRAM INIT	ERROR	: In case option cards are not normal
	S/W		Firmware version
	PARA	<8/8>	Parameter version
	WTIME		Operating time



# ch.8 Writing JOB Program

# 8.1 Overview of JOB Program Writing

- The number of robot programs that can be written is 8 (No.0 ~ No.7) in total.
- The maximum number of steps in each program is 1000 steps (4000 Word).
- Refer to the example below for easy writing.
- To write a program, first of all the user should decide 2 things.
  - 1) User I/O list to be used should be selected.
  - 2) The number of a point to work on should be assigned.



# 8.1.1 Robot Commands (Reference in Program Input)

# ■ Turn and selection key for commands by Job Program

Group	Turn	Selection Key	PROG
		F1	SERVO
	1	F2	STOP
	1	F3	MOVA
		F4	MOVI
		F1	MOVR
	2	F2	MOVM
	2	F3	MOVT
		F4	FOS
		F1	REF
	3	F2	PCLR
	3	F3	SPD
		F4	ACC
		F1	DEC
	4	F2	IF
		F3	XIF
Screen movement		F4	WAIT
BS <-> ENT	5	F1	GOTO
		F2	LBL
		F3	SBRT
		F4	RET
	6	F1	CALL
		F2	JPGM
	U	F3	LOOP
		F4	ENDL
		F1	ALARM
	7	F2	В
	7	F3	ВВ
		F4	I
		F1	Р
	8	F2	PEND
	O	F3	_
		F4	




# 8.2 Writing New Job Program Using Examples

#### 8.2.1 Description of Program Operation

## ■ Pick & Place Systems with palletizer function

#### 1) Operation simulation

Picks up the product on P0(Reference point) by sending the signal that operates a up/down movement cylinder and a finger cylinder once the start signal (B000) is entered, moving it to P1 and returns to the reference point.



## 2) Pick & Place System Job Program


Step	Command	Description				
S000	SERVO ON	: Turns SERVO ON.				
S001	SPD 1000	: Sets speed to 10% of parameter LMT_RPM.				
S002	LBL 1	: Sets LABEL to 1.				
S003	MOVA P0	: Moves from P0 to the assigned position.				
S004	B040 = 1	: Sends output contact B040(Arrival signal at reference point) to '1'.				
S005	WAIT B000 = 1	: Wait until input cotact B000 (Operation start contact) is '1'.				
S006	B040 = 0	: Outputs contact B040(Reference point arrival signal) to '0'.				
S007	B030 = 1	: Outputs B030(Up/down cylinder drive signal: Drive downward) to '1'.				
S008	B031 = 1	: Outputs B031(Finger cylinder drive signal: Grip) to '1'.				
S009	B030 = 0	: Outputs B030(Up/down cylinder drive signal: Drive upward) to '0'.				
S010	MOVA P1	: Moves from P1 to the assigned position.				
S011	B030 = 1	: Outputs B030(Up/down cylinder drive signal: Drive downward) to '1'.				
S012	B031 = 0	: Outputs B031(Finger cylinder drive signal: Release) to '0'.				
S013	B030 = 0	: Outputs B030(Up/down cylinder drive signal: Drive upward) to '0'.				
S014	GOTO 1	: Moves program execution to LBL.				
	<end file="" of=""></end>					



## 8.2.2 Job Program Writing

8.2.2.1 How to Handle Teach Pendant for Writing Job Program

# **Setting Procedure** Shift to MAIN screen Step 1. Turn ON power to controller and select TPS-9000T Ver1.3 Teach Pendant. F1: Teach Pendant F1 F2: RS-422 Multipoint F3: Data up/Down Load Press ENTER. RoboStar RCS-8000C Servo Controller ENT **PARA V00.22** PRESS ENT KEY Shift to Job Program screen Step 2. Select ROBOT. Servo Controller ROBOT PLC PARA VIEW F1



PROGRAM No. 0 3985


\*0# 1# 2 3

4 5 6 7

EDIT COPY DEL

The written program is displayed with #(Sharp).





Shift to an unwritten program.



 PROGRAM No. 2
 4000

 0#
 1#
 \*2
 3

 4
 5
 6
 7

 EDIT
 COPY
 DEL

Select EDIT.

F1

Step 3. Shift to command writing screen

PROGRAM No. 2

S000\*<end of file>

S001

BLOCK JMP DEL

Refers to initial screen of Program writing.

Step 4. Write S000 SERVO ON

PROGRAM No. 2 S000\* S001 <end of file> SERVO STOP MOVA MOVI Press ENT to search for a command to use.

ENT

Select SERVO.

PROGRAM No. 2
S000\*
S001 <end of file>
SERVO STOP MOVA MOVI




SERVO command is entered into S000. PROGRAM No. 2 S000\*SERVO S001 <end of file> OFF TRQ TQS Select ON. PROGRAM No. 2 S000\*SERVO F1 S001 <end of file> ON OFF TRQ TQS ON is entered after SERVO. PROGRAM No. 2 S000\*SERVO ON S001 <end of file> Step 5. Write S001 SPD 1000 Press ENT to move the cursor (\*) to S000 SERVO ON S001. S001\* ENT S002 <end of file> SERVO STOP MOVA MOVI Enter ENT twice to search for SPD. S000 SERVO ON S001\* ENT S002 <end of file> (Twice) REF PCLR SPD ACC



Step 6.

Select SPD. S000 SERVO ON S001\* F3 S002 <end of file> PCLR SPD ACC SPD is entered into S001. S000 SERVO ON S001\*SPD S002 <end of file> IOSPD I 1000 is entered after S001 SPD. 1 S000 SERVO ON S001\*SPD 1000 0 S002 <end of file> IOSPD I 0 0 Press ENT to move the cursor (\*) to S001 SPD 1000 S002. S002\* S003 <end of file> ENT REF PCLR SPD ACC Write S002 LBL 1 Enter ENT twice to search for LBL S001 SPD 1000 S002\* ENT S003 <end of file> (Twice) GOTO LBL SBRT RET







Select MOVA. S002 LBL 1 S003\* F3 S004 <end of file> SERVO STOP <u>MOVA</u> MOVI MOVA is entered into S003. S002 LBL 1 S003\*MOVA S004 <end of file> PΙ Select P. S002 LBL 1 S003\*MOVA F1 S004 <end of file> ΡI P is entered after S003 MOVA. S002 LBL 1 S003\*MOVA P S004 <end of file> 0 is entered after S003 MOVA P. S002 LBL 1 S003\*MOVA P0 0 S004 <end of file>



## Step 8.

#### Write S004 B040=1

S003 MOVA P0

S004\*

S005 <end of file>

SERVO STOP MOVA MOVI

Press ENT to move the cursor (\*) to the following S00.

ENT

ENT

S003 MOVA P0

S004\*

S005 <end of file>

ALARM B BB

Enter ENT 6 times to search for B.

S003 MOVA P0

S004\*

S005 <end of file>

ALARM B BB I

Select B.

F2

S003 MOVA P0

S004\*B

S005 <end of file>

Command B is entered into line S004.

S003 MOVA P0

S004\*B040

S005 <end of file>

= NOT

0

4

0

040 is entered after S004 B.



Select = (equal). S003 MOVA P0 S004\*B040 F1 S005 <end of file> NOT =(equal) is entered after line S004 S003 MOVA P0 B040. S004\*B040= S005 <end of file> 1 is entered after S004 B040=. S003 MOVA P0 S004\*B040=1 1 S005 <end of file> Step 9. Write S005 WAIT B000=1 Press ENT to move the cursor (\*) to S004 B040 = 1S005. S005\* ENT S006 <end of file> ALARM В ВВ Ι Enter ENT 5 times to search for WAIT. S004 B040 = 1S005\* ENT S006 <end of file> (5 times) ΙF DEC XIF WAIT



```
Select WAIT.
S004 B040 = 1
S005*
                                 F4
S006 <end of file>
DEC
      IF XIF
                      WAIT
                                        WAIT is entered into S005.
S004 B040 = 1
S005*WAIT
S006 <end of file>
       ВВ
               I
                        Р
                                        Select B.
S004 B040 = 1
S005*WAIT
                                 F1
S006 <end of file>
        BB I
                        Р
                                        B is entered into S005 WAIT.
S004 B040 = 1
S005*WAIT B
S006 <end of file>
                                        000 is entered after S005 WAIT.
                                  0
S004 B040 = 1
S005*WAIT B000
                                  0
S006 <end of file>
                                  0
```



Step 10.

Select = (equal). S004 B040 = 1S005\*WAIT B000 F1 S006 <end of file> =(equal) is entered after S005 WAIT S004 B040 = 1B000. S005\*WAIT B000= S006 <end of file> 1 is entered after S005 WAIT B000=. S004 B040 = 1S005\*WAIT B000=1 1 S006 <end of file> Press ENT to move the cursor(\*) to be S005 WAIT B000 = 1after S006. S006\* ENT S007 <end of file> Identical to Step 8. How to write S004 CS006 command, B040=0 B040=1 so refer to it. S007, S011 command, B030=1 S008 command, 'B031=1' S009, S013 command, B030=0 S012 command, B031=0



Step 11.

S010 command, MOVA P1 →

Identical to Step 7. How to write S003 MOVA P0 so refer to it.

Step 12.

Write S014 GOTO 1

S013 B030 = 0 S014\* S015 <end of file> GOTO LBL SBRT RET Write until S013 and press ENT to move the cursor(\*) to S014.

S013 B030 = 0 S014\* S015 <end of file> GOTO LBL SBRT RET Enter ENT consecutively to search for GOTO.

ENT

F1

ENT

S013 B030 = 0

S014\*

S015 <end of file>

GOTO LBL SBRT RET

Select GOTO.

S013 B030 = 0

S014\*GOTO

S015 <end of file>

GOTO is entered into S014.

S013 B030 = 0

S014\*GOTO 1

S015 <end of file>

1 is entered after S014 GOTO.

8-14

1



# ch.9 Description of Robot Commands

- A robot program command is a language for position control that is implemented in order and consists of
  - 1) Command for operating condition
  - 2) Operating command
  - 3) Variable processing command
  - 4) Input/output processing command
  - 5) Program control command

# 9.1 Commands for Operating Conditions

Command	Detailed command	Input Data	Description of command
SERVO	ON OFF TRQ TQS	None None 1 ~ 300 1 ~ 300	Turns ON power to servo.  Turns OFF power to servo.  Alarm occurs when exceeding the given torque limit.  Executes the following line after reaching the given torque.
ALARM	None	0 ~ 255	Generates user ALARM.
SPD (Speed)	None IOSPD I	1 ~ 10000 None 0 ~ 255	Sets motor rotation speed.  Sets motor rotation speed as a contact point.  Sets motor rotation speed as an integer variable.
ACC (Acceleration)	None I	1 ~ 500 0 ~ 255	Sets acceleration time. Sets acceleration time as an integer variable.
DEC (Decrement)	None I	1 ~ 500 0 ~ 255	Sets deceleration time. Sets deceleration time as an integer variable.
FOS	None I	0 ~ 100 0 ~ 255	The pgoram makes progress during operating command (MOVx).
PCLR (Position Clear)	None	None	Set the reference coordinate (Current position) to '0.000'.



#### 9.1.1 SERVO

**Function** Turns ON/OFF power to servo.

Alarm occurs in regard to torque value or the following line is implemented.

Form SERVO ON

SERVO OFF

SERVO TRQ <Torque value>
SERVO TQS < Torque value >

**Term** <Torque value> : Means torque values in 1~300% range.

## Description

Command	Description
SERVO ON	Turns ON power to servo.
SERVO OFF	Turns OFF power to servo.
SERVO TRQ <torque value=""></torque>	ALARM when beyond <torque value="">.</torque>
SERVO TQS < Torque value >	Executes the following line after reaching
SERVO IQS < lorque value >	<torque value="">.</torque>

- When connecting power to SERVO or cutting power, operation is made in connection with the start of a mechanical brake according to the value set in the parameter
- ➤ Opeartion is made at 300% when writing TRQ, TQS torque values at more than 300%.

Ex1

Servo	power ON.	
S000	SERVO ON	Turn ON power to servo
S001	MOVA 10.000	Move MOVA to 10.000
S002	SERVO OFF	Turn OFF power to servo

Ex2

Alarm occurs when beyond the preset torque value		
S000	SERVO ON	Turn ON power to servo
S001	SERVO TRQ 150	Alarm occurs if torque value is over 150%.
S002	MOVA 100.000	Move MOVA to100.000

Ex3

Execute the following step when beyond the preset torque value.		
S000	SERVO ON	Turn ON power to servo
S001	SERVO TQS 150	Execute S002 command if the torque value is over
S002	MOVA 100000	150%.
		Move MOVA to 100.000.



#### 9.1.2 ALARM

**Function** Generates user ALARM to stop the program from making progress.

Form ALARM <Alarm number>

**Term** < Alarm number > : Alarm number to generate

## Description

Command	Description
ALARM <alarm number=""></alarm>	Generate alarm <alarm number="">.</alarm>

- ➤ When a command is used, 'Software Alarm <Alarm number>' occurs.
- Alarm number available for use is 0 ~ 255. When the program is stopped by command ALARM, ALARM Bit is assigned to Set(1) among output contact, and T/P screen turns into ALARM and Software Alarm number is displayed.
- > To continue the program in ALARM, press RESET contact input or T/P RESET key to disable ALARM and RUN.

## Ex1

Softwa	Software alarm occurrence.	
S000	SERVO ON	Turn ON power to servo
S001	MOVA 10.000	Move MOVA to10.000
S002	ALARM 1	No.1 alarm ocurs
S003	SERVO OFF	Turn OFF power to servo



#### 9.1.3 SPD (SPEED)

**Function** Sets movement speed.

Form SPD <Set value>

SPD I<Number>

SPD IOSPD

**Term** <Set value> : Speed value for 1~10000

<Number>: INTEGER number from 0 to 255

## Description

Command	Description
SPD <set value=""></set>	Set to speed suited for <set value="">.</set>
SPD I <number></number>	Set to speed stored in INTEGER variable, that is, 'I < Number>'.
SPD IOSPD	Set at speed of parameter IO_SPD0~3 according to the value set to I/O contact IOSPD0, 1.

- > Set range for SPD value is 1 ~ 10000 and it unit is 1/100[%]. When set to 10000, movement is made at the speed set in parameter LMT\_RPM.
- ➤ When implementing the robot program the first time, the set value for parameter DFT\_SPD is applied to movement speed.
- ➤ When SPD value is set to 0, alarm 'E2023, Invalid SPD Value' occurs.

# **Ex.1** Setting by direction input.

	9 9	
S000	SERVO ON	Turn ON power to servo
S001	SPD 10000	Set speed at 100%
S002	MOVA 10.000	Move MOVA to 10.000

**Ex.2** Setting SPD value using an Integer variable.

	9 9 -	9
S000	SERVO ON	Turn ON power to servo
S001	SPD IO	Set to the value saved in INTEGER variable 0
		(IO set value 1000)
S002	MOVA 10.000	Move MOVA to 10.000

Ex.3

3	Setting SPD value using an IOSPD contact.		
	S000	SERVO ON	Turn ON power to servo
	S001	SPD IOSPD	Set speed at 20%
	S002	MOVA 10.000	(Contact IOSPD1 Set, IOSPD2 Set, parameter IO_SPD2 vlaue 2000)  Move MOVA to 10.000



#### 9.1.4 PCLR (POSITION CLEAR)

**Function** Involved in changing the current position on reference coordinate system to

0.000.

Form PCLR

#### Description

- ➤ When changing the coordinate system with PCLR command, the coordinate value following PCLR operation is 0.000.
- When the coordinate system is changed to PCLR in a state where the following command is supposed to be implemented before movement operation is finished by setting FOS configuration, a new coordinate system sets the position to 0.000 when performing the command and the stop position for the movement command keeps the position set in the previous coordinate system.
- > This command can be used only in the incremental encoder.

#### **Ex.1**

Reset t	Reset the current position.	
S000	SERVO ON	Turn ON power to servo
S001	SPD 10000	Set the speed at 100%
S002	MOVA 10.000	Move MOVA to 10.000
S003	<u>PCLR</u>	Change the current position on the coordinate
		system to 0.000.
S004	MOVA 15.000	Move to 15.000 (25.000 in the previous coordinate
		system) on the new coordinate system



#### 9.1.5 ACC (ACCELERATION), DEC (DECELERATION)

**Function** ACC : Acceleration time

DEC: Deceleration time

Form ACC <Set value>


ACC I<Number>
DEC <Set value>
DEC I<Number>

**Term** <Set value> : Speed value for 1~500

<Number>: INTEGER number from 0 to 255

#### Description

Command	Description
ACC <set value=""></set>	Set at <set value=""> speed.</set>
DEC <set value=""></set>	
ACC I <number></number>	Set at the speed in an INTEGER variable, 'I < Number>'.
DEC I <number></number>	



- ACC, DEC commands are set based on parameter MAX\_RPM.
- $\triangleright$  The set range for ACC, DEC values is 1 ~ 500, and set unit is 10[msec].
- ➤ The acceleration/deceleration times when performing the robot program first time are implemented by the values set respectively in parameter DFT\_ACC and DFT\_DEC.
- ➤ When changing acceleration/deceleration by commands ACC, DEC during movement by FOS command, the changed value is applied.



Ex.1

Set by direct input.		
S000	SERVO ON	Turn ON power to servo
S001	SPD 10000	Set speed at 100%
S002	ACC 20	Set acceleration time to 20 (Unit: 10ms) $\rightarrow$ 0.2 seconds
S003	DEC 50	Set acceleration time to 50 (Unit: 10ms) $\rightarrow$ 0.5 seconds
S004	MOVA 10.000	Move MOVA to 10.000

Ex.2

2	Set value using an integer variable.		
	S000	SERVO ON	Turn ON power to servo
	S001	SPD 10000	Set speed at 100%
	S002	ACC IO	Set acceleration time to the value saved in INTEGER 0
			(I0 set value :20)
	S003	DEC I1	Set deceleration time to the value saved in INTEGER 1
			(I1 set value 50)
	S004	MOVA 10.000	Move MOVA to 10.000



9.1.6 FOS

Function Involved in helping the following make progress before movement

command(MOVx) implementation is finished.

Form FOS <Set value>

FOS I<Number>

**Term** <Set value> : Speed value for 0~100%

<Number>: INTEGER number from 0 to 255

## Description

۱ [	Command	Description
		The following program is performed when it is placed
	FOS <set value=""></set>	in the rate for <set value=""> from start point to end</set>
		point while movement command is being
		implemented.
ĺ		The following program is performed when it is placed
	FOC I Mussele est	in the rate saved in INTEGER variable, 'I <number>'</number>
	FOS I <number></number>	from start point to end point while movement
		command is being implemented.

- FOS Set value is maintained to the following command FOS.
- Upon the receipt of a new command FOS while performing movement command using a command FOS, the previous movement command is performed and completed, which is then applied from the following movement command.
- ➤ When performing the robot program first time, FOS default value is set to 100.
- > FOS operation is the start point of movement.



Ex1

Value :	Value set by direct input		
S000	SERVO ON	Turn ON power to servo	
S001	SPD 10000	Set speed at 100%	
S002	MOVA 0.000	Move MOVA to 0.000	
S003	FOS 50	Set to make the program go when moving 50[%]	
S004	MOVA 1000.000	Perform S005 line in 500.000 due to 'S003 FOS 50'	
		while moving MOVA to 1000.000	
S005	PCLR	Perform S005 line in 500.000.	
S006	MOVA 10.000	Set the current position to 0.000	
		Move MOVA as much as 10.000	

Ex2

Set the value using an integer variable		
S000	SERVO ON	Turn ON power to servo
S001	SPD 10000	Set speed at 100%
S002	B050 = 0	Set contact B050 to '0'
S003	MOVA 0.000	Move MOVA to 0.000
S004	FOS IO	Set to make the program go when moving 50[%], the
		rate saved in INTEGER variable 0 (IO set value, 50)
S005	MOVA 10.000	Perform S006 line in 5.000 due to 'S004 FOS I0' while
		moving MOVA to 10.000
S006	B050 = 1	Set contact B050 to '1'
S007	MOVA 10.000	Perform S008 line in 5.000 due to 'S004 FOS I0' while
		moving MOVA to 10.000
S008	B050 = 1	Set contact B050 to '1'
S009	FOS I1	(I1 set value 100) Set to make the program go when
		moving 100[%], the rate saved in INTEGER variable 1
		(I1 set value, 100)



# 9.2 Operating Commands

■ When commands MOVA, MOVI, MOVR, and MOVT are implemented, Servo On comes up.

Command	Detailed Command	Input Data	Description of Command
	None	-99999.999 ~ 99999.999	Moves from the origin to the assigned place.
MOVA	Р	0 ~ 1023	Moves from the origin to where the
	PI	0 ~ 255	assigned position value is placed.
	None	-99999.999 ~ 99999.999	Moves from the current position to the assigned place.
MOVI	Р	0 ~ 1023	Moves from the current position to where
	PI	0 ~ 255	the assigned position value is placed.
	None	-99999.999 ~ 99999.999	Moves from the reference position to the assigned place.
MOVR	Р	0 ~ 1023	Moves from the reference position to
	PI	0 ~ 255	where the assigned position value is placed. The reference position is assigned by a REF command.
MOVT	None	IOPOS 0~7	Use contacts IOPOS(0~7) to select the assigned position value and makes a movement using a MOVT_ST contact.
	None	-99999.999 ~ 99999.999	Sets the value assigned in the position
REF	Р	0 ~ 1023	value as the reference position.
	PI	0 ~ 255	Assigns the reference position of MOVR.



#### 9.2.1 MOVA

**Function** Moves to the assigned position from the absolute coordinate system with the

origin as the basis.

Form MOVA <Set value>

MOVA P<Number>
MOVA PI<Number>

**Term** <Set value> : MIN\_LMT, MAX\_LMT range set in the parameter

<Number>: INTEGER number from 0 to 255


## Description

Command	Description
MOVA	Moves 0.000 on the absolute coordinate system to <set< td=""></set<>
<set value=""></set>	value>.
MOVA P	Moves to the position value saved in the position variable
<number></number>	'P <number>'.</number>
MOVA PI <number></number>	Moves from 0.000 on the absolute coordinate system as much as the value saved in the number 'P', the position value set to INTEGER variable 'I <number>'.</number>

➤ Before identifying the origin, the position at the time of feeding power supply is used as the origin.

(When using an incremental encoder)

Processed as an error when the target point for movement goes beyond the values sets in parameters MIN\_LMT, MAX\_LMT.



#### **Ex.1**

Move	Move to the assigned position.		
S000	SERVO ON	Turn ON power to servo	
S001	SPD 10000	Set movement speed at LMT_RPM의 100[%] of	
		LMT_RPM.	
S002	MOVA 45.000	Move MOVA to coordinate 45.000	
S003	MOVA P10	Move MOVA to the coordinate set to P10	
		(Suppose that P10 is 45.000.)	
S004	MOVA PI1	In I1 = 10, MOVA is moved to the coordinate set to	
		P10.	



#### 9.2.2 MOVI

Funct- Based on the current position, an incremental movement is made as much as the

**ion** assigned position value.

Form MOVI <Set value>

MOVI P<Number>
MOVI PI<Number>


Term <Set value> : MIN\_LMT, MAX\_LMT range set in the parameter

<Number>: INTEGER number from 0 to 255

# Description

Command	Description
MOVI <set value=""></set>	Moves from the current position to <set value="">.</set>
MOVI P <number></number>	Moves to the position value saved in the position variable 'P <number>'.</number>
MOVI PI <number></number>	Moves from current position as much as the value saved in the number 'P', the position value set to INTEGER variable 'I <number>'</number>

- Processed as an error when the target point for movement goes beyond the values sets in parameters MIN\_LMT, MAX\_LMT.
- > The position value delivered in the previous command is used for the position prior to movement.



(Suppose that the coordinate value (based on a command) before movement is 45.000.)

#### **Ex.1**

Move	Move to the assigned position.		
S000	SERVO ON	Turn ON power to servo	
S001	SPD 10000	Set movement speed at 100[%] of LMT_RPM.	
S002	MOVI -20.000	Make incremental movement as much as about -20.000	
		from the current position.	
S003	MOVI P10	Make incremental movement as much value as set in P10	
		from the current position.	
S004	MOVI PI1	In I1 = 10, MOVA is incrementally moved as much value	
		as set in P10.	



#### 9.2.3 REF, MOVR

**Function** REF command is used to set the reference position to move as much value as

set with the use of MOVR command.

Form REF <Set value>

REF P < Number>
REF PI < Number>

MOVR <Set value>
MOVR P <Number>
MOVR PI <Number>

Term <Set value> : MIN\_LMT, MAX\_LMT range set in the parameter


<Number>: INTEGER number from 0 to 255.

#### Description

Command	Description
REF <set value=""></set>	Set <coordinate value=""> as the reference position.</coordinate>
REF P <number></number>	Set the value assigned in the position variable as the reference position.
REF PI <number></number>	Set as the reference position the value saved in the number of the position variable 'P' set to INTEGER variable 'I <number>'</number>
MOVR <set value=""></set>	Move from the reference position as much as <set value="">.</set>
MOVR P < Number>	Move from the reference position as much as the position value saved to the position variable 'P <number>'.</number>
MOVR PI <number></number>	Move from the reference position as much as the value saved in the number for the position value 'P' set to INTEGER variable 'I <number>'.</number>

- Processed as an error when the target point for movement goes beyond the values sets in parameters MIN\_LMT, MAX\_LMT.
- ➤ The reference position set as a REF becomes the reference value and is saved to position variable P1022.
- A temporary reference position set as a REF is maintained until a REF command is used again or P1022 is changed with other methods.
- > Commands REF, MOVR also allow position values to be entered in the form of Pxxx or PIxx, as seen in MOVA or MOVI.





(The reference position is set by REF command. This position value is aved to P1022.)

Ex.1	Move from the reference position as much as the assigned position.				
	S000	SERVO ON	Turn ON power to servo		
	S001	SPD 10000	Set movement speed at 100[%] of LMT_RPM.		
	S002	REF 20.000	Set the reference position to coordinate 20.000.		
	S003	MOVR 25.000	Make incremental movement as much as 25.000 from the		
			reference position.		



9.2.4 MOVT

**Function** Moves to the coordinate value of the position variable assigned in value

IOPOS  $(0 \sim 7)$ .

Form MOVT

Description

Command	Description
MOVT	Select the position value assigned as contact IOPOS(0~7) and
MOVI	make a movement using contact MOVT_ST.

- Command MOVT begins to move only when contact value MOVT\_ST changes from '0' to '1'. Besides, IO\_POS contact values also utilize the value when MOVT\_ST contact changes from '0' to '1'.
- > How to move is identical to MOVA command.
- Position variable values assigned as contact values IOPOS3, IOPOS2, IOPOS1, and IOPOS0 are used as a movement position. (Refer to the table below.)

	P0	P1	P2	Р3	P4	P5	P6	P7	P8	P9	P10	P11	P12	P13	P14	P15
IOPOS0	OFF	ON														
IOPOS1	OFF	OFF	ON	ON												
IOPOS2	OFF	OFF	OFF	OFF	ON	ON	ON	ON	OFF	OFF	OFF	OFF	ON	ON	ON	ON
IOPOS3	OFF	ON														

Move	Move from IOPOS to the assigned position.						
S001	SERVO ON	Turn ON power to servo					
S002	SPD 10000	Set movement speed at 100[%] of LMT_RPM.					
S003	MOVT	IOPOS0	IOPOS1	IOPOS2	IOPOS3	P8	
		OFF	OFF	OFF	ON	(25.000)	
	Move MOVA as much as 25.000.						



## 9.3 Variable Processing Command

9.3.1 I, P

**Function** Sets values for integer variables (I) or position variables (P).

Form I <Integer variable number >

P < Position variable number >

**Term** < Integer variable number > : Integer variable number from 0 to 255

< Position variable number > : Position variable number from 0 to 1023

#### Description

ĺ	Command	Input Data	Description
ĺ	I (Integer)	0 ~ 255	Sets integer variable value.
ĺ	P (Position)	0 ~ 1023	Sets position variable value.

- $\triangleright$  The range of an integer variable is 0 ~ 65535.
- $\triangleright$  The range of a position variable is  $-99999.999 \sim 99999.999$ .
- Even though a value is entered into position variable P1021, this changes to the correction value when GOTO command is used following XIF command.
- ➤ Even though a value is entered into the position variable P1022, this changes to the coordinate value used in REF command.
- ➤ The value in position variable P1023 changes to the current position value.



## **Ex.1** Integer variable.

```
S000 I1 = 10
                                 Set integer variable I1 to 10.
S001 I1 = I2
                                 Set integer variable I1 to the value in integer variable
S002 I1 = II2
        (ex: I2 = 5, I5 = 10)
                                 Set to I1 = I(I2) \rightarrow I1 = I(5) \rightarrow I1 = 10.
S003 I1 += 10
S004 I1 += I2 (ex: I2 = 5)
                                 Set to I1 = I1+10.
S005 I1 += II2
                                 Set to I1 = I1+I2 \rightarrow I1 = I1+5.
        (ex: I2 = 5, I5 = 10)
                                 Set to I1 = I1+I(I2) \rightarrow I1 = I1+I(5) \rightarrow I1 = I1+10.
S006 I1 -= 10
                                 Set to I1 = I1-10.
S007 I1 -= I2 (ex: I2 = 5)
                                 Set to I1 = I1-I2 \rightarrow I1 = I1-5.
S008 I1 -= II2
                                 Set to I1 = I1-I(I2) \rightarrow I1 = I1-I(5) \rightarrow I1 = I1-10.
        (ex: I2 = 5, I5 = 10)
```

## **Ex.2** Position variable

Positio	ion variable.						
S000	P1 = 10.000	Set Position variable P1 to 10.000.					
S001	P1 = P2	Set Position variable P1 to the value in Position					
S002	P1 = PI2 (ex: I2 = 5)	variableP2.					
S003	P1 += 10	Set to P1 = $P(I2) \rightarrow P1 = P5$ .					
S004	P1 += P2	Set to P1 = P1+10.					
S005	P1 += PI2	Set to $P1 = P1+P2$ .					
	(ex: I2 = 5)	Set to P1 = P1+P(I2) $\rightarrow$ P1 = P1+P5.					
S006	P1 -= 10						
S007	P1 -= P2	Set to P1 = P1-10.					
S008	P1 -= PI2	Set to P1 = P1-P2.					
	(ex: I2 = 5)	Set to P1 = P1-P(I2) $\rightarrow$ P1 = P1-P5.					



## 9.4 Input/output Processing Command

9.4.1 B, BB

**Function** Sets a contact value.

**Form** B<Bit number>

BB < Byte number >

**Term** <Bit number> : Contact number for Bit unit

<Byte number> : Contact number for Byte unit

#### Description

Command	Description
В	Processes a contact in Bit unit.
ВВ	Processes a contact in Byte unit

- The value allocated from command BB is from Bit(LSB) 0.
- ➤ Command BB is unable to set an input contact (Base: B00 ~ B02). Now that contact points (Bxxx, BBxx) are commonly used with a PLC program, it is not possible to know which value comes up when the two programs (Robot and PLC program) set different values to the identical bit. Use caution when writing a program.
- ➤ In BB04 = 00..11.., the mark "." means 'don's care' that does not modify the previous value.

Chang	Change a contact value.				
S000	B030 = 0	Set contact B030 to '0'.			
S001	B031 = 1	Set contact B031 to '1'.			
S002	B032 NOT	Inverts the contact value for contact B032.			
	:	:			
S003	BB03 = 11000011	B030,B031,B036,B037 = 1; B032, B033, B034, B035			
S004	BB04 = 0011	= 0			
		B030,B031 = 0; B034, B035 = 1;			
		The rest bits maintain previous values.			



# 9.5 Program Control Command

Command	Detailed Command	Input Data	Description of Command
STOP	None	None	Stops robot program from making further progress.
	В	000 ~ 317	Processes conditions according to a contact value (Bit).
IF	ВВ	00 ~ 31	Processes conditions according to a contact value (Byte).
IF	I	0 ~ 255	Processes conditions according to an integer variable value.
	Р	0 ~ 1023	Processes conditions according to a position variable value.
	В	000 ~ 317	Processes conditions according to a contact value (Bit) during operation.
XIF	ВВ	00 ~ 31	Processes conditions according to a contact value (Byte) during operation.
All	I	0 ~ 255	Processes conditions according to an integer variable value during operation.
	Р	0 ~ 1023	Processes conditions according to a position variable value during operation.
	None	0 ~ 10000	Wait as much time as assigned.
	В	000 ~ 317	Wait until the assigned contact becomes the set value.
WAIT	ВВ	00 ~ 31	Wait until the assigned contact becomes the set value.
	I	0 ~ 255	Wait until the set integer variable value is seen.
	Р	0 ~ 1023	Wait until the set position variable value is seen.
SBRT (Subroutine)	None	0 ~ 999	Displays the start of subroutine.
RET (Return)	None	None	Displays the end of subroutine.
CALL	None	0 ~ 999	Branches to the assigned subroutine.
GOTO	None	0 ~ 999	Branches to the assigned label.
LBL (Label)	None	0 ~ 999	Assigns a label.
LOOP	None	0 ~ 999	Performs repeated run as much value as set to the assigned ENDL.
ENDL (End Loop)	None	0 ~ 999	Displays the end of assigned LOOP.
JPGM (Jump Program)	None	0 ~ 7	Displays on the assigned program.
PEND (Program End)	None	None	Displays the end of program.



9.5.1 STOP

**Function** Stops the program from making further progress.

Form STOP

## Description

Command	Description
STOP	Stops the ongoing program.

➤ When the program is stopped by command STOP, the program makes progress only by entering RUN contact.

Progra	am stop.	
S000	SERVO ON	Turn ON power to servo
S001	MOVA 100.000	Move MOVA to 10.000
S002	IF $B010 = 1$	When contact B010 is '1', the program is stopped
S003	<u>STOP</u>	from moving.



9.5.2 IF

Function When the status for contact values, Integer variable values, Position variable

values is consistent with conditions, the command for the following step is

implemented, whereas if not, it is not implemented.

(When inconsistent, run the command for the following step.)

Form IF I<Integer variable number>

IF P<Position variable number>

IF B<Bit number>

IF BB < Byte number >

**Term** <Integer variable number> : Integer variable number from 0 to 255.

<Position variable number> : Position variable number from 0 to 1023

#### Description

Command	Description
IF I <integer td="" variable<=""><td>Processes conditions according to integer variable</td></integer>	Processes conditions according to integer variable
number>	variables.
IF P <position td="" variable<=""><td>Processes conditions according to position variable</td></position>	Processes conditions according to position variable
number>	variables.
IF B <contact td="" value<=""><td>Processes conditions according to contact value (Bit).</td></contact>	Processes conditions according to contact value (Bit).
(Bit)>	Processes conditions according to contact value (bit).
IF BB <contact< td=""><td>Processes conditions according to contact value</td></contact<>	Processes conditions according to contact value
value(Byte)>	(Byte).

The following are conditions applicable in IF condition.

<Inspect contact value>

B010 = 1 : Inspect bit unit. B01 = 11..00. : Inspect byte unit.

(Bit represented as '.' is not inspected.)

<Inspect Integer

variable value>

 $\begin{array}{ll} \mbox{IF IO} > 10 & \mbox{If IO is greater than 10.} \\ \mbox{IF IO} < \mbox{I1} & \mbox{If IO is smaller than I1.} \\ \end{array}$ 

IF IO = II3 Precondition I3=1, if IO is equal to I1.

IF II2 != 10 Precondition I2=0, if I0 is different from 10. IF II2 > I1 Precondition I2=0, if I0 is greater than I1.

IF II2 < II3 Preconditions I2=**0**, I3=**1**, if I**0** is smaller than I**1** 



<Inspect position

variable value>

IF P0 = 10.000 If P0 is equal to 10.000. IF P0 != P1 If P0 is different from P1.

IF P0 > PI3 Precondition I3=1, if P0 is greater than P1. IF PI2 < 10.000 Precondition I2=0, If P0 is smaller than 10.000.

IF PI2 = P1 Precondition I2= $\mathbf{0}$ , If P0 is equal to P1.

IF PI2 != PI3 Precondition I2=**0**, I3=**1**, If P0 is smaller than P**1** 

(> Greater, < Smaller, = Equal, != Not equal)

- Integer variable can be used from I0 to I255 and integer variable values are from 0 to 65535.
- Position variable can be used from P0 to P1023 and position variable values are from -99999.999 to 99999.999.

Change movement position by a contact		
S000	SERVO ON	Turn ON power to servo
S001	SPD 10000	Set movement speed at 100[%] of LMT_RPM.
S002	$\underline{IF\;B010=1}$	When contact B010 is '1',
S003	MOVA 10.000	coordinate 1 moves to 0.000.
S004	$\underline{IF\;B010=0}$	When contact B010 is '0',
S005	MOVA -10.000	Coordinate -1 moves to 0.000.



9.5.3 XIF

Function Inspects conditions while performing time-consuming commands (MOVx,

WAIT).

Form XIF I<Integer variable number>

XIF P< Position variable number>

XIF B<Bit number>
XIF BB< Byte number>

**Term** <Integer variable number>: Integer variable number from 0 to 255

<Position variable number> : Position variable number from 0 to 1023

<Bit number> : Bit unit contact number <Byte number> : Byte unit contact number

#### Description

Command	Description
XIF I	Processes conditions according to integer
<integer number="" variable=""></integer>	variable values during operation.
XIF P	Processes conditions according to position
<position number="" variable=""></position>	variable values during operation.
XIF B	Processes conditions according to contact
< Bit number >	variable (Bit) values during operation.
XIF BB	Processes conditions according to contact
< Byte number >	variable (Byte) values during operation.

- > Conditions applicable in command XIF are identical to IF.
- Commands used after XIF are limited to SPD, ACC, DEC, and GOTO. When command GOTO comes after XIF, movement or WAIT operation are stopped as long as conditions are met, running the program in LBL position. (While the system is moving, this command instantly reduces speed to stop and saves the value for the stop point to position variable P1021253.)
- ➤ Enabled to use XIF conditions up to three and operating conditions in parallel with MOVx, WAIT.
- ➤ When XIF is used following the command other than MOVx, WAIT, it is processed identically to IF.

Chang	Change maximum speed according to the contact during movement		
S000	SERVO ON	Turn ON servo.	
S001	SPD 10000	Set movement speed at 100[%] of LMT_RPM.	
S002	MOVA 50.000	Move to coordinate 50.000.	
S003	XIF B001 = 1	When B001 becomes '1' during movement, set	
S004	SPD 5000	movement speed at 50[%] of LMT_RPM.	



9.5.4 WAIT

**Function** Used to stop the program from running for a certain period of time.

Form WAIT <Time>

WAIT I<Integer variable number>
WAIT P< Position variable number>

WAIT B<Bit number>
WAIT BB< Byte number >

**Term** <Time> : time in unit of 1/10 second

### Description

Command	Description
WAIT <time></time>	Wait as much time as assigned.
WAIT I <integer< td=""><td>Wait until the set integer variable value is seen.</td></integer<>	Wait until the set integer variable value is seen.
variable value>	wait until the set integer variable value is seen.
WAIT P < Position	Wait until the set position variable value is seen
variable value>	Wait until the set position variable value is seen.
WAIT B <contact< td=""><td>Wait until the assigned contact becomes the set</td></contact<>	Wait until the assigned contact becomes the set
value>	value.
WAIT BB <contact< td=""><td>Wait until the assigned contact becomes the set</td></contact<>	Wait until the assigned contact becomes the set
value>	value.

- $\triangleright$  Time range set by WAIT command is 0 ~ 10000, and time unit is 100[msec].
- Conditions applicable in command WAIT are identical to IF. (Contact value, integer/position variable value).

Wait l	oy contact status	
S000	SERVO ON	Turn ON servo.
S001	SPD 10000	Set movement speed at 100[%] of LMT_RPM.
S002	MOVA 100.000	Move to coordinate 100.000.
S003	WAIT 100	Wait for 10[Sec].
S004	MOVA 200.000	Move to coordinate 200.000.
S005	<u>WAIT B010 = 1</u>	Wait until contact B010 becomes '1'.



9.5.5 CALL, SBRT, RET

**Function** Runs a program written in the form of subroutines.

Form CALL < Number >

SBRT < Number>

**RET** 

**Term** < Number> : Subroutine number

### Description

Command	Description
CALL <number></number>	Branches into the assigned subroutine.
SBRT <number></number>	Displays the start of subroutine.
RET	Displays the end of subroutine.

- ➤ SBRT number assignable to CALL is 0 ~ 255.
- > An identical SBRT number can be used in different programs.
- When an identical SBRT number is discovered more than twice in the program or there is no assigned SBRT number to CALL, grammar check program processes it as an error.
- ➤ When there is no RET command in response to SBRT, grammar check program processes it as an error.
- Another SBRT in SBRT can be used by using command CALL prior to RET. But, it cannot be repeated more than 16times and if beyond, it is processed as an error during RUN.

Move	Movement using subroutines		
S000	SERVO ON	Turn ON servo.	
S001	SPD 1000	Set movement speed at 100[%] of LMT_RPM.	
S002	MOVA 10.000	Move to coordinate 10.000.	
S003	CALL 1	Run the program between SBRT 1 and RET.	
		(MOVA -10.000)	
S004	MOVA 30.000	Move to coordinate 30.000.	
	÷	::	
S005	SBRT 1	Start of subroutine 1.	
S006	MOVA -10.000	Move to coordinate -10.000.	
S007	RET	End of subroutine 1.	



9.5.6 GOTO, LBL

**Function** Used to move the progress point of the program.

Form GOTO < Number>

LBL < Number>

**Term** < Number> : Assigned label number

## Description

Command	Description
GOTO <number></number>	Branches into the assigned label.
LBL <number></number>	Assigns a label.

- ➤ LBL number assignable to GOTO is 0 ~ 255.
- An identical LBL number can be used in different programs.
- ➤ When an identical LBL number is discovered more than twice in the program or there is no assigned LBL number to CALL, grammar check program processes it as an error.

Unlim	Unlimited repeat movement		
S000	SERVO ON	Turn ON servo.	
S001	SPD 1000	Set movement speed at 100[%] of LMT_RPM.	
S002	LBL 1	Assigns LBL 1.	
S003	MOVA 100.000	Move MOVA to coordinate 100.000.	
S004	MOVA -100.000	Move MOVA to coordinate 100.000.	
S005	GOTO 1	Move the ongoing program to LBL 1.	



9.5.7 LOOP, ENDL

**Function** Used to repeat the program at a certain section.

Form LOOP < Number > L < Number of times >

ENDL < Number>

**Term** < Number> : LOOP number

<Number of times> : Times to repeat

### Description

1	Command	Description
	LOOP <number></number>	Performs repeated run as much as the default value to the
		assigned ENDL.
	ENDL <number></number>	Displays the end of the assigned LOOP.

- ➤ ENDL number assignable to LOOP is 0 ~ 255.
- > An identical ENDL number can be used in different programs.
- ➤ When an identical ENDL number is discovered more than twice in the program or there is no assigned ENDL number to LOOP, grammar check program processes it as an error.
- > Another LOOP in LOOP can be used. But, it cannot be repeated more than 16times and if beyond, it is processed as an error during RUN.

Move	Move by repeating as many time as desired		
S000	SERVO ON	Turn ON servo.	
S001	SPD 1000	Set movement speed at 100[%] of LMT_RPM.	
S002	MOVA 10.000	Move MOVA to coordinate 10.000.	
S003	LOOP 1 L 10	Repeat the program between LOOP 1 L 10 and	
		ENDL 1 10 times.	
S004	MOVA 20.000	Move MOVA to coordinate 20.000.	
S005	MOVA -20.000	Move MOVA to coordinate -20.000.	
S006	ENDL 1	Complete LOOP 1.	
S007	MOVA 10.000	Move MOVA to coordinate 10.000.	



9.5.8 JPGM

**Function** Used by calling another program.

Form JPGM <Number>

**Term** < Number> : Program number to run

## Description

Command	Description
JPGM <number></number>	Implements program <number>.</number>

- ➤ Unable to allow JPGM to assign the program number being currently written.
- > The program called by JPGM can call another program using JPGM again. But, it cannot be repeated more than 8 times and if beyond, it is processed as an error during RUN.

Move to another program.			
S000	SERVO ON	Turn ON SERVO.	
S001	SPD 10000	Set movement speed at 100[%] of LMT_RPM.	
S002	MOVA 10.000	Move MOVA to coordinate 10.000.	
S003	JPGM 1	Call program 1.	
		Proceed to PEND or <end file="" of=""> in program 1</end>	
S004	MOVA 20.000	Proceed from S004.	
		Move MOVA to coordinate 20.000.	



9.5.9 PEND

**Function** Indicates the end of the executable program.

Form PEND

## Description

1	Command	Description		
	PEND	Indicates the end of program.		


➤ Write a subroutine after PEND and make CALL, and the corresponding subroutine is implemented. (Refer to Ex.1.)

Indicates the end of program.		
S000	SERVO ON	Turn ON SERVO.
S001	SPD 10000	Set movement speed at 100[%].
S002	CALL 1	Run the program between SBRT 1 and RET.
S003	MOVA 10.000	Move to coordinate 10.
S004	PEND	The program following PEND is not implemented.
S005	MOVA 20.000	MOVA 20.000 is not implemented due to PEND.
S006	SBRT 1	Start of Subroutine 1.
S007	MOVA -10.000	Move to coordinate -10.000.
S008	RET	End of Subroutine 1.



## ch.10 Examples for Robot Program

## 10.1 Location Movement Program at Regular Intervals



### 1) Program with repeated use of MOVI command

SERVO ON	: Turn ON SERVO.
LBL 1	: Assign LABEL to 1.
SPD 1000	: Set speed at 10% of parameter LMT_RPM.
MOVI 100	: Move from current position(P0) as far as 100 in user coordinate.
MOVI 100	: Move from current position(P0+100) as far as 100 in user coordinate.
MOVI 100	: Move from current position(P0+200) as far as 100 in user coordinate.
MOVI 100	: Move from current position(P0+300) as far as 100 in user coordinate.
SPD 3000	: Set speed at 30% of parameter LMT_RPM.
MOVA P0	: Move from P0 to the assigned position.
GOTO 1	: Move the ongoing program to LBL 1.
<end file="" of=""></end>	

### 2) Program using a command LOOP

SERVO ON	: Turn ON SERVO.
LBL 1	: assign LABEL to 1.
SPD 1000	: set speed at 10% of parameter LMT_RPM.
LOOP 1L 4	: set a LOOP whose LABEL is 1 and repeat times are 4.
MOVI 100	: Move from current position as far as 100 in user coordinate.
ENDL 1	: Indicates the end of a LOOP whose LABEL is 1.
SPD 3000	: Set speed at 30% of LMT_RPM.
MOVA P0	: Move from P0 to the assigned position.
GOTO 1	: Move the ongoing program to LBL 1.
<end file="" of=""></end>	




### 3) Program using an integer variable as a counter

SERVO ON : Turn ON SERVO. LBL 1 : Set LABEL to 1. IO = 0: Set integer variable I0 to 0. SPD 1000 : Set speed at 10% of parameter LMT\_RPM. LBL 2 : Set LABEL to 2. **MOVI 100** : Move from current position as far as 100 in user coordinate. I0 += 1: Add 1 to integer variable I0. IF I0 = 4GOTO 3 : When integer variable I0 is 4, it moves to LBL 3, otherwise it GOTO 2 moves to LBL 2. LBL 3 : Set LABEL to 3. SPD 3000 : Set speed at 30% of parameter LMT\_RPM. MOVA P0 : Moves from P0 to the assigned position. GOTO 1 : Move the ongoing program to LBL 1. <end of file>



### 10.2 Location Movement Program using Contact

■ Description: After waiting until the assigned contact meet conditions, it moves to the assigned position. Produce the contact point assigned from the final position and wait for 1 second before returning to the original position.



#### 1) Example program

SERVO ON : Turn ON SERVO.
LBL 1 : Set LABEL to 1.

SPD 1000 : Set speed at 10% of parameter LMT\_RPM.

WAIT B020 = 1 : Wait until input contact B020 becomes '1'.

MOVA P1 : Move from P1 to the assigned position.

WAIT B021 = 0 : Wait until input contact B021 becomes '0'.

MOVA P2 : Move from P2 to the assigned position.

WAIT BB02 = ...01 : Wait until input contact B026 becomes '0' and B027 '1'.

MOVA P3 Move from P3 to the assigned position. B040 = 1 : Produce output contact B040 to '1'.

SPD 3000 : Set speed at 30% of parameter LMT\_RPM.

WAIT 10 : Wait for 1second.

MOVA P0 : Move from P0 to the assigned position.

GOTO 1 : Move the ongoing program to LBL 1.

<end of file>



## 10.3 Movement Program at Infinitely Constant Speed

■ Description: Moves unlimitedly at the speed set by the user and when the assigned input occurs during movement, it stops. (The command PCLR used in this program is applicable only to an incremental encoder.)

### 1) Example program


SERVO ON : Turn ON SERVO. SPD 1000 : Set speed at 10% of parameter LMT\_RPM. FOS 50 : Move to 50% of target position and implement the following LBL 1 program step. MOVA 100 : Set LABEL to 1.  $XIF B027 = 1^{-1}$ : Move to 100 in user coordinate. GOTO 2 **PCLR** : When input contact B027 is '1' during movement, it moves to LBL2, GOTO 1 otherwise it changes the reference coordinate system to the coordinate system with 0.000 as the current position. : Move the ongoing program to LBL 1. LBL 2 **STOP** : Assigns LABEL to 2. <end of file> : Stop the program from running.



## 10.4 Turret Run Program

■ Description: The system returns to the original position when moving the fixed coordinate value due to its unique structure and it can move the nearest path by using MOVT command when rotational direction does not have any relevance.

(But, be sure to set parameters T\_CYCLE as well as IOPOS(0 ~ 7), MOVT\_ST.)



T\_CYCLE = 360.000 P0 = 0.000 P1 = 70.000 P2 = 150.000 P3 = 230.000 P4 = 290.000

Set value

1) Example program

SERVO ON : Turn ON SERVO.

SPD 1000 : Set speed at 10% of parameter LMT\_RPM.

LBL 1 : Set LABEL to 1.


MOVT : When contact MOVT\_ST changes from '0' to '1', it moves to the

position coordinate value set in IOPOS(0 ~ 7).

GOTO 1 : Move the ongoing program to LBL 1.


<end of file>

#### 2) Program Operation Diagram





## 10.5 Multiple Run Program




#### 1) Example program

This program refers to X-axis and what is in the brackets shows modifications to Y-axis program.

SERVO ON : Turn ON SERVO. SPD 1000 : Set speed at 10% of parameter LMT\_RPM. LBL 1 : Set LABEL to 1. WAIT B000 = 1: Wait until input contact B000 (Contact at time of operation) CALL 10 becomes '1'. MOVA 100 : Call SBRT10. CALL 10 : Move to 100 in user coordinate. MOVA 1500 : Call SBRT10. CALL 10 : Move to 1500(100) in user coordinate. MOVA 0 : Call SBRT10. SBRT 10 : Move to 0 in user coordinate. B040 = 1: Start of SBRT10. WAIT B001 = 1: Produce output contact B040 to '1'. B040 = 0: Wait until input contact B001 becomes '1'. RET : Produce output contact B040 to '0'. <end of file> : End SBRT10 and return to be after command CALL.



## 10.6 Simple Pick & Place Systems with Palletizer Function



### 1) Example program

SERVO ON	: Turn ON SERVO.
SPD 1000	: Set speed at 10% of parameter LMT_RPM.
LBL 1	: Set LABEL to 1.
MOVA P0	: Move from P0 to the assigned position.
B040 = 1	: Produce output contact B040 (Reference point arrival signal) to '1'.
WAIT B000 = 1	: Wait until input point B000 (Operation start contact) becomes '1'.
B040 = 0	: Produce output contact B040(Reference point arrival signal) to '0'.
B030 = 1	: Output B030(Up/down cylinder start signal: Start downward) to '1'.
B031 = 1	: Output B031(Finger cylinder start signal: Grip) to '1'.
B030 = 0	: Output B030(Up/down cylinder start signal: Start upward) to '0'.
MOVA P1	: Move from P1 to the assigned position.
B030 = 1	: Output B030(Up/down cylinder start signal: Start downward) to '1'.
B031 = 0	: Output B031(Finger cylinder start signal: Release) to '0'.
B030 = 0	: Output B030(Up/down cylinder start signal: Start upward) to '0'.
GOTO 1	: Move the ongoing program to LBL 1.
<end file="" of=""></end>	



## ch.11 Running Robot Program and PLC Program

## 11.1 Use of I/O Contact

After running the robot program and PLC program, it checks out proper operation:
 Description:
 operation status using the teach pendant, enabling I/O contact to be performed in the outside.

- This short-cut controller operates also by I/O alone as shown below.
  - 1) JOG operation
  - 2) Origin operation
  - 3) Robot program implementation
  - 4) PLC program implementation
- Prior to I/O operation, related system contacts should be set in the parameter. (Refer to Ch.3)
  - 11.1.1 Operating Contact in JOG Operation
- JOG + , JOG -
  - 1) Rotates the motor in directions where position coordinates increase and decrease. (Rotates when '1' is fed).
  - 2) When JOG\_MODE contact value is '0', JOG operation is made, and when '1', IJOG operation is made.
  - 3) Continuous movement is made while this contact stays in '1' in JOG operation, whereas in one time movement at a time is made when this contact changes from '0' to '1' in IJOG operation.
- JOG\_MODE

Selects JOG operation and IJOG operation. ('0': JOG, '1': IJOG).


■ JOG\_SET(0 ~ 1)

Sets JOG movement speed and the amount of movement. (When JOG\_MODE is '0', movement speed is seen and when '1', the amount of movement is seen.)




## 11.1.1.1 Operation Timing Diagram in JOG Operation

## ■ JOG\_MODE = 0 (JOG Operating Mode)



### ■ JOG\_MODE = 1 (IJOG Operating Mode)





### 11.1.2 ORIGIN Operation Using External Contact (In using absolute value encoder)

### 11.1.2.1 Operating Contact in ORIGIN Operation

■ Description: **ORIGIN**: Origin operation begins as contact value changes from '0' to '1'


CW S/W, CCW S/W: Limit Switch

ORG S/W: Origin Switch

### 11.1.2.2 Operation Timing Diagram in ORIGIN Operation

<Parameter Set value>

ORG\_RULE 1
MOV\_POL 1
MOTOR MSMR
ORG\_OFS 10





### 11.1.3 Robot Program Operation Using External Contact

### 11.1.3.1 Operating Contact in Robot Program Operation

■ Description: **ROB\_RUN**: Run the robot program.

But, the robot program should be free from syntax error.

**STOP**: Stop the robot program from running.


**STEP**: Run the robot program one step at a time.

**PGM\_SEL(2 ~ 0)**: Select the robot program to run.

**PGM\_SEL**: When PGM\_SEL value is '1', the program assigned to PGM\_SEL(2


~ 0) is selected.

### 11.1.3.2 Operation Timing Diagram in Putting Program in AUTO RUN





## 11.1.3.3 Operation Timing Diagram in Putting Program in STEP RUN





# ch.12 Description of PLC Command

## ■ Robot PLC program commands consist of

- 1) Commands for logical operation
- 2) Commands for contact input/output
- 3) Relation commands

## 12.1 Logical Operation Command

Command	Detailed Command	Input Data	Description of Command
	None	Contact	Connects logical operations in series. (Contact
		Address	'a')
AND	NOT	Contact	Connects logical operations in series. (Contact
		Address	'b')
	LOAD	None	Connects two blocks in series.
	None	Contact	Connects logical operations in parallel.
		Address	(Contact 'a')
OR	NOT	Contact	Connects logical operations in parallel.
		Address	(Contact 'b')
	LOAD	None	Connects two blocks in parallel.
	None	Contact	When input condition rises, a pulse comes out
D		Address	during 1 scan.
	NOT	Contact	When input condition falls, a pulse comes out
		Address	during 1 scan.

## 12.2 Contact Input/Output Command

Command	Detailed Command	Input Data	Description of Command
SET	None	Contact	Sets the assigned contact to '1'.
JL1		Address	
RST	None	Contact	Clears the assigned contact to '0'.
K31		Address	
OUT	None	Contact	Outputs the assigned contact to '1'.
001		Address	




## 12.3 Relation Command

Command	Detailed Command	Input Data	Description of Command
LOAD	None	Contact Address	Start of a logical operation. (Contact 'a')
LOAD	NOT	Contact Address	Start of a logical operation. (Contact 'b')
NOT	None	Contact Address	Reverses operation results.
MCS	None	None	Sets common interlock.
MCSC	None	None	Clears common interlock set.
TMR	BXXX <d>Value</d>	Contact Address	Subtracted according to conditions to ouput when reaching '0'.
CTR	BXXX <d>Value</d>	0 ~ 10000	Subtracted according to conditions and input pulses to output when reaching '0'.



### **■** Example of Writing a PLC Program


- 1) AND, AND NOT
  - AND: Serial connection of logical operation. (Contact 'a')
  - AND NOT: Serial connection of logical operation. (Contact 'b')






#### 2) AND LOAD

• AND LOAD: Connect two blocks in series.






- 3) OR, OR NOT
  - OR: Parallel connection of logical operation. (Contact 'a')
  - OR NOT: Parallel connection of logical operation. (Contact 'b')






### 4) OR LOAD

• OR LOAD: Connects two blocks in parallel.






- 5) SET, RST
  - SET: Sets the assigned contact to '1'.
  - RST: Sets the assigned contact to '0'.






- 6) OUT
  - OUT: Outputs the assigned contact to '1'.






- 7) LOAD, LOAD NOT
  - LOAD: Start of logical operation. (Contact 'a')
  - LOAD NOT: Start of logical operation. (Contact 'b')






- 8) NOT
  - NOT : Reverses operation results.






- 9) MCS, MCSC
  - MCS: Sets common interlock.
  - MCSC: Sets and clears common interlock.





#### 10) TMR


TMR: Subtracts according to conditions to output when reaching '0'.





#### 11) CTR

• CTR: Subtracts according to conditions and input pulses to output when reaching '0'.





## ch.13 ALARM

#### 13.1 Alarm List

#### 13.1.1 Over Current (E01.00~E01.02)

Code	Alarm Name	Description
E01.00	OVER Current	The current of the alarmed axis motor exceeds the permissible maximum value.
E01.01	IPM FAULT	Failure in IPM of servo module
E01.02	Current Sensing Err	If ADC input voltage is over 1V during booting.

#### 13.1.2 Over Load (E02.00)

Code	Alarm Name	Description
E02.00	Over Load	Torque load rate exceeds the system parameter (OVL)

#### 13.1.3 Over Voltage (E03.00 ~ E03.01)

Code	Alarm Name	Description
E03.00	Over Voltage	DC link voltage of the servo module exceeds 400V.
E03.01	Open Regenerative	If a regenerative resistor not connected.

#### 13.1.4 Power Fail (E05.00 ~ E05.01)

Code	Alarm Name	Description
E05.00	Under Voltage DCLink	DC link voltage of the servo module is under 180V
E05.01	Open DCLink	If main power is turned off.

#### 13.1.5 Data Back-up Error (E06.00)

Code	Alarm Name	Description
E06.00	Back up RAM Data Error	If data stored in the Back up RAM is abnormal.



## 13.1.6 Encoder Error (E07.00 ~ E07.13)

Code	Alarm Name	Description
E07.00	Enc Time Out	There is no reply from a communicational encoder
E07.01	Enc Sys Down	The battery voltage of an absolute encoder is under 2.5V
E07.02	Enc Over Speed	Failure in multi-turn data detection in an absolute encoder
E07.03	Enc Status Err	Power source is applied when an absolute encoder rotates over 100 rpm
E07.04	Enc S-Turn Err	Failure in 1-turn data of an absolute encoder
E07.05	Enc Over Flow Err	Multi-turn data overflow of an absolute encoder
E07.06	Enc M-Turn Err	Failure in multi-turn counter of an absolute encoder
E07.07	Enc Type Miss	The setup value of the system parameter is different from the encoder type of the actual motor
E07.08	Enc ID Data Miss	If received data of the motor encoder is not correct.
E07.10	Enc Open Err	Disconnection of an encoder line when in use of a pulse encoder
E07.11	Enc Init Err	Failure in an encoder signal during initialization of a servo module
E07.12	Enc Hall Open	Failure in a Hall sensor signal of the encoder
E07.13	Enc Hall Init	Failure in a Hall sensor signal of the encoder during initialization of a servo module

## $13.1.7 \text{ H/W Limit (E08.00} \sim \text{E08.01)}$

Code	Alarm Name	Description
E08.00	H/W Limit -	H/W limit sensor signal is detected
E08.01	H/W Limit +	H/W limit sensor signal is detected

## 13.1.8 S/W Limit (E09.00 ~ E09.03)

Code	Alarm Name	Description
E09.00	S/W Limit -	Deviation from the operation range of the robot parameter
E09.01	S/W Limit +	Deviation from the operation range of the robot parameter
E09.02	TRQ Limit	If real torque value is higher than the setting value when TRQ command is used.
E09.03	TQS Limit	If real torque value is the setting value when TQS command is used.

## 13.1.9 Following Error (E10.00)

Code	Alarm Name	Description
E10.00	Following Error	Positional error value of a motor exceeds the setup value range of the system parameter



## 13.1.10 Program Error (E11.00 ~ E11.04, E11.50 ~ E11.51)

Code	Alarm Name	Description
E11.00	Empty JOB	If there is currently no JOB to perform.
E11.01	Compile Error	If performing JOB is abnormal when I/O(ROB_RUN) is performed.
E11.03	Not JPGM in SBRT	If JPGM is used by SBRT command.
E11.04	Not JPGGM in LOOP	If JPGM is used by LOOP command.
E11.50	Empty PLC	If there is no PLC JOB to perform.
E11.51	PLC Compile Error	If PLC JOB which is to be performed is abnormal.

## 13.1.11 Emergency Stop (E12.00 ~ E12.03)

Code	Alarm Name	Description
E12.00	T/P Emergency	In case of emergency stop by the emergency stop switch of the Teaching Pendant.
E12.01	System I/O Emergency	If I/O is not connected.
E12.02	Host Emergency	In case of emergency stop by emergency stop protocol at host mode.
E12.03	System PLC Emergency	If emergency occurs at CNET.

#### 13.1.12 Over Speed (E13.00 ~ E13.02)

Code	Alarm Name	Description
E13.00	Over Speed	The error which occurs if speed command is over the specified value.
E13.01	Servo On Fail	Occurs when SERVO ON fails.

## 13.1.13 Program Error (E14.00 ~ E14.04)

Code	Alarm Name	Description	
E14.00	Parameter Err	If the motor ID setting is wrong when power is ON.	
E14.01	Curr Pos Buf Err	If current position is over the specified value.	
E14.02	Speed Command Buf Err	If speed command is over the specified value.	
E14.03 Acc Command Buf Err		If acceleration command is over the specified value.	
E14.04	Dec Command Buf Err	If deceleration command is over the specified value.	

#### 13.1.14 Software Alarm (E15.00)

Code	Alarm Name	Description	
E15.00	Software Alarm	If ALARM command is performed.	
E15.01	Not found origin	If Origin is not completed.	



## 13.1.15 JOB (E20.00 ~ E20.19)

Code	Alarm Name	Description	
E20.00	Invalid JOB Command	If JOB command is abnormal.	
E20.01	No match Label	Branch point position corresponding to execute statement is not designated.	
E20.02	Same Label Number	If branch point position corresponding to execute statement exist more than 2 points.	
E20.03	RET Before SBRT	If 'subroutine end' command is used prior to 'subroutine start' command	
E20.04	No match SBRT	If designated command corresponding to call command of sub execute statement does not exist.	
E20.05	Same SBRT Number	If the same SBRT number is used more than twice in one program.	
E20.06	JPGM too many	If branches of the designated program is over 8 times.	
E20.07	JPGM to itself	If the user wants to branch to the designated program	
E20.08	JPGM to empty pgm	If non-existent program is selected.	
E20.09	No Match ENDL	If there is no command which indicates the end of the designated LOOP	
E20.10	Same ENDL number	If there are more than 2 commands which indicate the end of the designated LOOP.	
E20.11	LOOP too many nest	If repetitive statement is used more than 16 times.	
E20.12	No match LOOP	If there is no LOOP command corresponding to ENDL or if ENDL is incorrectly used.	
E20.13	Same LOOP Number	If there are more than 2 commands which indicate the start of designated LOOP.	
E20.14	ENDL before LOOP	If there is the command expressing repetitive statement end prior to that expressing start.	
E20.15	Not Output Port	If there is no designated port for output contact point.	
E20.16	Not pair SBRT, RET	If SBRT and RET do not match as a pair.	
E20.17	Not pair LOOP, ENDL	If LOOP and ENDL do not match as a pair.	
E20.18	Invalid XIF Command	If the command can not be operated.	
E20.19	Not mapping IOPOS	If coordinate value of position parameter IOPOS is not designated.	
E20.20	Too Many SBRT Call	If SBRT and CALL are repeated and used more than 16 times.	
E20.21	PNT Index Range Over	If the number of a point variable is incorrectly set.	
E20.22	INT Index Range Over	If the number of an integer variable is incorrectly ranged.	
E20.23	CONST Val Range Over	If the range of position value is incorrectly set.	
E20.24	Invalid SPD Value	If a SPD command value is 0.	



13.1.16 JOB Command (E20.50~20.99)

Code	Alarm Name	Description	
E20.50	Invalid SERVO Command	If detailed SERVO command are not normal.	
E20.51	Invalid MOVA Command	If detailed MOVA command are not normal.	
E20.52	Invalid MOVI Command	If detailed MOVI command are not normal.	
E20.53	Invalid MOVR Command	If detailed MOVR command are not normal.	
E20.54	Invalid MOVM Command	If detailed MOVM command are not normal.	
E20.55	Invalid FOS Command	If detailed FOS command are not normal.	
E20.56	Invalid REF Command	If detailed REF command are not normal.	
E20.57	Invalid SPD Command	If detailed SPD command are not normal.	
E20.58	Invalid ACC Command	If detailed ACC command are not normal.	
E20.59	Invalid DEC Command	If detailed DEC command are not normal.	
E20.60	Invalid IF Command	If detailed IF command are not normal.	
E20.61	Invalid WAIT Command	If detailed WAIT command are not normal.	
E20.62	Invalid BIT Command	If detailed BIT command are not normal.	
E20.63	Invalid BYTE Command	If detailed BYTE command are not normal.	
E20.64	Invalid INT Command	If detailed INT command are not normal.	
E20.65	Invalid POS Command	If detailed POS command are not normal.	
E20.66	Invalid GOTO Command	If detailed GOTO command are not normal.	

## 13.1.17 PLC (E21.00 ~ E21.13)

Code	Alarm Name	Description	
E21.00	Invalid PLC Command	If Back up RAM 's PLC program area is damaged.	
E21.01	Invalid bit addr	If contact point address which is set in the program is out of the corresponding range.	
E21.02	LOAD Command too many	If stored unnecessary logic calculus command exceeds 30.	
E21.03	LOAD Command expected	If contact point information which is stored at the start of logic calculus uses MCS, NOT command.	
E21.04	Needs more 2 blocks	If stored contact point information at LOAD command use is less than 2.	
E21.05	Not Output Port	If there is no designated port for output contact point.	
E21.06	D(CNT) Command too many	If D or D NOT command exceeds 288 times.	
E21.07	Needs more 1 block	If there is no stored contact point information at logic calculus.	
E21.08	MCS too many nest	If common interlock set (Clear) is duplicated over 30 times	
E21.09	MCS block not end	If all contact point information is not used at the start of logic calculus.	
E21.10	No MCS block	If Clear command is only used without common interlock set.	



E2	21.11	TMR Command too many	If TMR command usage exceeds 64 times.
<b>E</b> 2	21.13	Program Not END	If all contact point information is not used at the start of logic calculus.

#### 13.1.18 ETC (E22.00 ~ 22.20)

Code	Alarm Name	Description	
E22.00	Last code step	If input value for Jump function usage goes beyond last line.	
E22.01	Same Input port para	If input contact point setting is duplicated.	
E22.03	Not Change in	If parameter is changed for Servo ON state.	
E22.04	Pre Para Not Change	If MOTOR_ID value of CONTROLLER(SERVO) is different from that of Quadrature motor.	
E22.06	Not Edit in	If the program is edited while the robot program is performed.	
E22.07	Not Delete in	If the program is deleted while the robot program is performed.	
E22.08	is not empty	If another program is copied to already existing program.	
E22.09	is empty	If non-existence program is copied.	
E22.10	Not copy itself	If the same program is copied.	
E22.11	Invalid number	If the range is beyond the setting range when program is edited or parameter is set.	
E22.12	Step not enough.	If the specified step number and capacity is out of range for Block programming.	
E22.13	Not end block set	If block unit is edited when program is still running.	
E22.14	Clipboard Empty	If 'Write' is performed without storing to the memory after Block is programmed.	
E22.15	Too large block	The size of programmed Block is out of the setting range.	
E22.16	Robot is running	If Jog or Origin is tried to be performed during Robot Run performing.	
E22.17	Jog is running	If Robot Run or Origin is tried to be performed during Jog running.	
E22.18	Origin running  If Robot Run or Jog is tried to be performed during Origin running.		
E22.19	Not Origin Mode	If Origin is performed after setting ORG_RULE value as '0'.	
E22.20	Not Save in	If parameter is tried to be stored during Robot Run.	
E22.21	Not Input port	If output contact point is set to input contact point for parameter value setting.	
E22.22	Not Output port	Output port If input contact point is set to output contact point for parameter value setting.	

## 13.1.19 Alarm End Code (E99.98 ~ E99.99)

Code	Alarm Name	Description	
E99.98	Wrong Alarm code	If Alarm code exceeds front 2 digits.	
E99.99	UNDEF ERR CODE	If it does not exist at current Alarm code.	



# 13.2 Alarm Scene and Troubleshooting (Alarm Code Description)

13.2.1 Over Current (E01.00 ~ E01.02)

E01.00 OVER Current				
Alarm Description	The current of the alarmed axis motor exceeds the permissible maximum			
Alaini Description		\\	/alue.	
Disabling Alarm		<b>▼</b> RESET	POWER ON/OFF	
Alarm Classification		S	Servo	
Alarm Code		Е	01.00	
7		Ove	r Current	
Cause		Tr	roubleshooting	
<ul><li>Motor cable U, V, W sl circuited</li><li>Motor burnt out</li></ul>	nort	<ul><li>Check if controller's U·V</li><li>are in right order.</li><li>Accurately connect encoder.</li></ul>	Accurately connect encoders on each axis and U·V·W cables in pair.  Check the motor for insulation resistance and wire resistance and if	
■ Fusion of the relay for a dynamic brake due to frequent Servo On-Off		and replace the servo m	Check that the dynamic brake relay on the servo module is working and replace the servo module. (Do not turn servo ON/OFF when the dynamic brake relay shows an error.)	
■ Vibration or noise takes place due to poor gain adjustment		– Readjust GAIN.	Readjust GAIN.	
<ul> <li>Abnormal rating and excessive acceleration/deceleration setting</li> </ul>		•	Monitor maximum torque when starting the robot and in the event of 300% or over, change acceleration/deceleration settings and increase motor capacity.	



E01.01 IPM FAULT				
Alarm Description		Failure in IPM of servo module		
Disabling Alarm		☐ RESET	POWER ON/OFF	
Alarm Classification		Ser	vo	
Alarm Code		E01	.01	
T/P Display		IPM I	Fault	
Cause		Trou	ubleshooting	
■ U, V, W short-circuit of motor power cable	on	<ul> <li>Check motor U·V·W·FG cable for short circuit and connect correctly.</li> <li>Check if controller's U·V·W·FG and motor input terminal U·V·W·FG are in right order.</li> <li>Accurately connect encoders on each axis and U·V·W cables in pair.</li> </ul>		
Maximum allowable cu limit of IPM on each as exceeded.	rrent xis has	Monitor maximum torque and in the event of 300% or over, adjust the deceleration time of a parameter at long range.  Adjust GAIN.  Increase the capacities of the motor and servo.		
<ul> <li>Maximum allowable temperature limit for IF module has exceeded.</li> </ul>	temperature limit for IPM   - Check around the controller for ventilation.		for ventilation.	
■ IPM damaged		In the event of a persistent alarm, get an inspection from our authorized dealer and manufacturer.		

E01.02 Current Sensing Err				
Alarm Description	If ADC input voltage is over 1V during booting			
Disabling Alarm		☐ RESET	POWER ON/OFF	
Alarm Classification		Servo		
Alarm Code		E01.02		
T/P Display		Current Sen Err		
Cause		Troubleshooting		
■ Error in ADC circuit		Get an inspection from our authorized dealer and manufacture.		



## 13.2.2 Over Load (E02.00)

E02.00 Over Load				
Alarm Description		Torque load rate exceeds the system parameter (OVL)		
Disabling Alarm		<b>▼</b> RESET	POWER ON/OFF	
Alarm Classification		Ser	·vo	
Alarm Code		E02	2.00	
T/P Display		Over	Load	
Cause		Trou	ubleshooting	
Abnormal rating The motor runs for a ce time period when an ef torque over rated range exceeded the rated toro	fective e has	·	от поставот от о	
■ Vibration or noise takes due to poor gain adjust	•	– Readjust GAIN.		
<ul><li>Wrong wiring of motor or short circuit</li></ul>	cable	<ul> <li>Check if controller's U·V·W·</li> <li>are in right order.</li> </ul>	Check if controller's U·V·W·FG and motor's input terminals U·V·W·FG	
<ul> <li>Occurrence of mechanical external interference during operation implementation</li> </ul>		Check for mechanical extern	nal interference.	
Malfunction of the electron motor brake	tronic	- Check the brake terminal for wiring and operating condition.		
■ System parameter (OVL) value set to low		When the set value for syst it moderately.	When the set value for system parameter (OVL) is set to low, change it moderately.	



## 13.2.3 Over Voltage (E03.00 $\sim$ E03.01)

E03.00 Over Volta	ge		
Alarm Description		DC link voltage of the ser	rvo module exceeds 400V
Disabling Alarm		<b>▼</b> RESET	POWER ON/OFF
Alarm Classification		Sei	rvo
Alarm Code		E03	3.00
T/P Display		Over \	/oltage
Cause		Tro	ubleshooting
<ul> <li>Acceleration/decelerati too short compared to load</li> </ul>			on time of system parameter at long range.
■ Failure in regenerative resistor of servo module		<ul><li>Check if the regenerative re</li><li>Check out the resistance varesistor.</li></ul>	esistor is installed. Ilue and conditions for a regenerative
■ Input voltage in excess allowable voltage	of	<ul> <li>Check out the voltage in in</li> </ul>	put power and impress correct voltage.
■ Controller (SERVO) failure		In the event of a persistent authorized dealer and many	alarm, get an inspection from our ufacture.

E03.01 Open Regenerative			
Alarm Description	Regenerative resistor not connected.		
Disabling Alarm	▼ RESET		
Alarm Classification	Servo		
Alarm Code	E03.01		
T/P Display	Open Regenerative		
Cause	Troubleshooting		
■ Failure of the regenerative resistor on servo module	- Check out the resistance value and conditions for a regene		
■ Controller (SERVO) failure	In the event of a persistent alarm, get an inspection from our authorized dealer and manufacture.		



## 13.2.4 Power Fail (E05.00 ~ E05.01)

E05.00 Under Volt	tage DC	Link		
Alarm Description		DC link voltage of the servo module is under 180V		
Disabling Alarm		<b>▼</b> RESET	☐ POWER ON/OFF	
Alarm Classification			Servo	
Alarm Code			E05.00	
T/P Display		Ur	nder Voltage	
Cause	Troubleshooting		Troubleshooting	
<ul> <li>Acceleration/decelerati too short compared to load</li> </ul>			eration time of system parameter at long range	
■ Power voltage lower than allowable input voltage		– Check out the applied	power voltage and impress right voltage.	
Power relay failure in electric module		•	Check if the power relay on the electric module is working. Replace the electric module.	
■ Controller (SERVO) failure		In the event of a persi authorized dealer and	istent alarm, get an inspection from our manufacture.	

E05.01. Open DCLi	nk		
Alarm Description		If main powe	r is turned off
Disabling Alarm		☐ RESET	POWER ON/OFF
Alarm Classification		Sei	vo
Alarm Code		E05	5.01
T/P Display		Open	DCLink
Cause	Troubleshooting		ubleshooting
<ul> <li>Control power voltage than allowable input v</li> </ul>		Check out the applied cont voltage.	rol power voltage and impress right
■ Power relay failure in e	electric	<ul> <li>Check if the power relay on the electric module is working.</li> <li>Replace the electric module.</li> </ul>	
■ Controller (SERVO) failure		In the event of a persistent authorized dealer and man	alarm, get an inspection from our ufacture.



#### 13.2.5 Data Back-up Error (E06.00)

E06.00 Back up RAM Data Error					
Alarm Description		If data stored in the Bad	ck up RAM is abnormal		
Disabling Alarm		<b>▼</b> RESET	POWER ON/OFF		
Alarm Classification	Main				
Alarm Code	E06.00				
T/P Display	File System Err				
Cause	Troubleshooting		ubleshooting		
■ Damage to file memory	storage – Initialize the file system.				
■ Magnet in touch w up RAM	ith Back	k – Get an inspection from our authorized dealer and manufacture.			

## 13.2.6 Encoder Error (E07.00 ~ E07.13)

E07.00 Enc Time Out					
Alarm Description			There is no reply from a d	communicational encoder	
Disabling Alarm			<b>▼</b> RESET	POWER ON/OFF	
Alarm Classification			Enco	oder	
Alarm Code			E07	7.00	
T/P Display			Enc Tin	ne Out	
Cause			Trou	ubleshooting	
■ Loose contact of an er connector	ncoder	-	Check out the connection of the encoder connector at both ends of controller and motor.		
■ Encoder power voltage running low		-		ge (4.75 ~ 5.25V) on the motor encoder. e power on the robot cable or shorten the	
■ In the event of communication error due to external noise		-	Check out AC power, FG lines of motor U·V·W cable.  Install the ferrite core on the controller's output stage of U·V·W cable.		
· ·	(MOTOR) and the actual not		Check out the set value motor.	for the servo parameter and the actual	

# **CAUTION**

Upon the occurrence of the above alarm, a mechanical position error may occur, so an ORG completion signal is initialized.



E07.01 Enc Sys Do	wn		
Alarm Description		The battery voltage of an absolute encoder is under 2.5V	
Disabling Alarm		☐ RESET	
Alarm Classification	Encoder		
Alarm Code	E07.01		
T/P Display	Enc Sys Down		
Cause		Troubleshooting	
<ul> <li>Built-in condenser voltabelow the standard levent to turning off power to bit absolute encoder or power</li> </ul>	el due a 17-	<ul> <li>After replacing the battery, do multi–turn clear for an absolute encoder.</li> </ul>	

E07.02 Enc Over Speed				
Alarm Description		Failure in multi-turn data dete	ection in an absolute encoder	
Disabling Alarm		<b>▼</b> RESET	POWER ON/OFF	
Alarm Classification		Enco	oder	
Alarm Code		E07	.02	
T/P Display	Enc Over Speed			
Cause	Troubleshooting		ubleshooting	
■ Encoder power voltage running low			ge (4.75 ~ 5.25V) on the motor encoder. e power on the robot cable or shorten the	
Motor revolutions going beyond standard value when feeding battery power supply at time of power outage in a 17-bit absolute encoder.		<ul> <li>After connecting the power absolute encoder.</li> </ul>	er for battery, do multi–turn clear for an	



E07.03 Enc Status	Err		
Alarm Description	Power	source is applied when an absolute encoder rotates over 100 rpm	
Disabling Alarm		✓ RESET  ✓ POWER ON/OFF	
Alarm Classification	Encoder		
Alarm Code	E07.03		
T/P Display	Enc Status Err		
Cause		Troubleshooting	
<ul> <li>17-bit absolute encoder making rotations beyond standard value when feeding power supply</li> </ul>		Check the motor moves when feeding power and if any movement is detected, keep it from moving.	

E07.04 Enc S-Turn	Err		
Alarm Description		Failure in 1-turr	n data of an absolute encoder
Disabling Alarm			
Alarm Classification	Encoder		
Alarm Code	E07.04		
T/P Display	Enc S-Turn Err		
Cause			Troubleshooting
■ 17-bit absolute encode	r in		
detection of the error i	n the	<ul> <li>Replace the motor.</li> </ul>	
first-round counter			

E07.05 Enc Over Flow Err			
Alarm Description	Multi-turn data overflow of an absolute encoder		
Disabling Alarm		☐ RESET	<b>▼</b> POWER ON/OFF
Alarm Classification	Encoder		
Alarm Code	E07.05		
T/P Display	Enc Over Flow		
Cause	Troubleshooting		oubleshooting
■ 17-bit absolute encoder in			
detection of the error in a		<ul> <li>Replace the motor.</li> </ul>	
multi-round counter			



E07.06 Enc M-Turn Err			
Alarm Description	Failur	e in multi-turn coun	ter of an absolute encoder
Disabling Alarm	☐ RE	SET	POWER ON/OFF
Alarm Classification	Encoder		
Alarm Code	E07.06		
T/P Display	Enc M-Turn Err		
Cause			Troubleshooting
■ 17-bit absolute encoder in detection of the error in a multi-round counter		– Replace the mo	tor.

E07.07 Enc Type I	Viiss			
Alarm Description	The se	The setup value of the system parameter is different from the encoder type of the actual motor		
Disabling Alarm		<b>▼</b> RESET	POWER ON/OFF	
Alarm Classification	Encoder		oder	
Alarm Code	E07.07		7.07	
T/P Display	Enc Type Miss			
Cause		Troubleshooting		
<ul><li>Set values for system parameters</li><li>(ABS, ENC, WATT)and motor not consistent</li></ul>	actual	Check out the set value for system parameter (ABS, ENC, WATT) and the encoder type of an actual motor.  Ex) The motor with 2500 pulses per revolution of motor allows only INC to be supported in system parameter (ABS) and the above alarm occurs if so to ABS.		

E07.08 Enc ID Data Miss			
Alarm Description	If received data of the mo	otor encoder is not correct	
Disabling Alarm	<b>▼</b> RESET	POWER ON/OFF	
Alarm Classification	Enc	oder	
Alarm Code	EO:	7.08	
T/P Display	Enc ID Miss		
Cause	Troubleshooting		
<ul> <li>Loose contact of an encoder connector</li> </ul>	<ul> <li>Check out the connection of the encoder connector at both ends of controller and motor.</li> </ul>		
■ Encoder power voltage running low	<ul> <li>Check out the power voltage (4.75 ~ 5.25V) on the motor encoder.</li> <li>When below 4.75V, reinforce power on the robot cable or shorten the cable.</li> </ul>		
■ In the event of communication error due to external noise	Check out AC power, FG lines of mo     Install the ferrite core on the control		



E07.10 Enc Open Err			
Alarm Description	Di	sconnection of an encoder line	when in use of a pulse encoder
Disabling Alarm		<b>▼</b> RESET	POWER ON/OFF
Alarm Classification		Enco	oder
Alarm Code		E07	7.10
T/P Display		Enc (	Open
Cause		Troubleshooting	
■ Loose contact of an er connector	ncoder – Check out the connection of the encoder connector at both encoder controller and motor.		of the encoder connector at both ends of
■ Encoder power voltage	<ul> <li>Check out the power voltage (4.75 ~ 5.25V) on the motor encoder</li> <li>When below 4.75V, reinforce power on the robot cable or short cable.</li> </ul>		
■ Encoder cable disconn	ected	Check the encoder cable for replace it.	or disconnection and when error is found,

E07.11 Enc Init Err			
Alarm Description	Fai	lure in an encoder signal durin	g initialization of a servo module
Disabling Alarm		☐ RESET	POWER ON/OFF
Alarm Classification		Enco	oder
Alarm Code		E07	'.11
T/P Display	Enc INIT Err		
Cause	Troubleshooting		ubleshooting
■ Loose contact of an enconnector	ncoder – Check out the connection of the encoder connector at both end controller and motor.		of the encoder connector at both ends of
■ Encoder power voltage	<ul> <li>Check out the power voltage (4.75 ~ 5.25V) on the motor enc.</li> <li>When below 4.75V, reinforce power on the robot cable or sho cable.</li> </ul>		
■ Encoder cable disconn	- Check the encoder cable for disconnection and when error is replace it.		or disconnection and when error is found,



E07.12 Enc Hall Open			
Alarm Description		Failure in a Hall sensor	signal of the encoder
Disabling Alarm		☐ RESET	POWER ON/OFF
Alarm Classification		Enco	oder
Alarm Code		E07	.12
T/P Display	Enc Hall Open		l Open
Cause	Troubleshooting		ubleshooting
■ Loose contact of an enconnector	- Check out the connection of the encoder connector at controller and motor.		of the encoder connector at both ends of
■ Encoder power voltage	oder power voltage running		e (4.75 ~ 5.25V) on the motor encoder. e power on the robot cable or shorten the
■ Encoder cable disconn	ected	Check the encoder cable for replace it.	or disconnection and when error is found,

E07.13 Enc Hall Init		
Alarm Description	Failure in a Hall sensor signal of the encoder during initialization of a servo module	
Disabling Alarm		☐ RESET
Alarm Classification		Encoder
Alarm Code		E07.13
T/P Display	Enc Hall Init	
Cause	Troubleshooting	
■ Loose contact of an er connector	Check out the connection of the encoder connector at both encoder controller and motor.	
■ Encoder power voltage	- Check out the power voltage (4.75 ~ 5.25V) on the motor encode - When below 4.75V, reinforce power on the robot cable or shorten cable.	
■ Encoder cable disconn	ected	Check the encoder cable for disconnection and when error is found, replace it.



## 13.2.7 H/W Limit (E08.00 ~ E08.01)

E08.00 H/W Limit -		
Alarm Description	H/W limit s	ensor signal is detected
Disabling Alarm	<b>▼</b> RESET	POWER ON/OFF
Alarm Classification		Protection
Alarm Code		E08.00
T/P Display		H/W Limit -
Cause		Troubleshooting
■ Limit sensor recognication	– Check if the actual	reaching point.  robot specifications and robot parameter  ), OFFSET, Deceleration ratio) are consistent.
■ Error in recognition by a	– Inspect or replace the sensor and harness system.	
■ Error in limit sensor inp port	ut – Replace the servo	module.

E08.01 H/W Limit	; <b>+</b>		
Alarm Description		H/W limit sensor s	signal is detected
Disabling Alarm		<b>▼</b> RESET	POWER ON/OFF
Alarm Classification		Prote	ction
Alarm Code		E08.	.01
T/P Display		H/W Li	mit +
Cause		Troubleshooting	
■ Limit sensor red during robot operati	- Check and adjust teaching point Check if the actual robot specifications and robot parame (Arm length (LENG), OFFSET, Deceleration ratio) are consi		specifications and robot parameter
<ul><li>Error in recognition limit sensor</li></ul>	by a   - Inspect or replace the sensor and harness system.		nsor and harness system.
<ul><li>Error in limit sensor port</li></ul>	input	Replace the servo module	e.



## 13.2.8 S/W Limit (E09.00 ~ E09.03)

E09.00 S/W Limit	-		
Alarm Description		Deviation from the operation	range of the robot parameter
Disabling Alarm		<b>▼</b> RESET	POWER ON/OFF
Alarm Classification		Prote	ction
Alarm Code		E09	0.00
T/P Display	S/W Limit -		
Cause		Troubleshooting	
■ Error in setting the operange of system parame (Range)		<ul> <li>Change the value for operating range of system parameter to the value listed on the robot nameplate.</li> <li>Check and adjust work teaching point when an error occurs when working on origin operation or job implementation.</li> </ul>	
<ul> <li>Command LIMIT deviate from range during work progress</li> </ul>	3	Adjust the operating range where JOB program sets command LIMI	

E09.01 S/W Limit	+		
Alarm Description		Deviation from the operation	range of the robot parameter
Disabling Alarm		<b>▼</b> RESET	POWER ON/OFF
Alarm Classification		Prote	ction
Alarm Code		E09	0.01
T/P Display	S/W Limit +		imit +
Cause		Troubleshooting	
<ul> <li>Error in setting the operange of system parameter (Range)</li> </ul>		<ul> <li>Change the value for operating range of system parameter to the value listed on the robot nameplate.</li> <li>Check and adjust work teaching point when an error occurs when working on origin operation or job implementation.</li> </ul>	
<ul> <li>Command LIMIT deviation from range during work progress</li> </ul>	•	Adjust the operating range where JOB program sets command LIMI     Check if the teaching point is within the set range and adjust accordingly.	



E09.02 TRQ Limit			
Alarm Description	If real torque value is higher than the setting value when TRQ command is		
		us 	ed I
Disabling Alarm		<b>☑</b> RESET	POWER ON/OFF
Alarm Classification		Prote	ection
Alarm Code		E09	9.02
T/P Display	TRQ Limit		Limit
Cause	Troubleshooting		ubleshooting
<ul> <li>Set value for command TRQ set to low during the normal operation in progress</li> </ul>		Check out the maximum to raise the set value to a high	rque value on the configured axis and ner level.
<ul> <li>Occurrence of me external interference operation implementat</li> </ul>	echanical during ion		
■ Vibration or noise takes place due to poor gain adjustment		– Readjust GAIN.	

E09.03 TQS Limit			
Alarm Description	If re	al torque value is the setting v	alue when TQS command is used.
Disabling Alarm		<b>▼</b> RESET	POWER ON/OFF
Alarm Classification	Protection		ction
Alarm Code	E09.03		
T/P Display	TQS Limit		
Cause		Trou	ubleshooting
<ul> <li>Reaching the set value for command TQS during the normal operation in progress</li> </ul>		<ul> <li>No troubleshooting mea</li> <li>JOB.</li> </ul>	asures required Run the next line in



## 13.2.9 Following Error (E10.00)

E10.00 Following	Error		
Alarm Description	Positional error value of a motor exceeds the setup value range of the system parameter		
Disabling Alarm		<b>▼</b> RESET	POWER ON/OFF
Alarm Classification		Prote	ction
Alarm Code	E10.00		
T/P Display	Following Err		
Cause		Trou	ubleshooting
<ul> <li>Entering excessive speed command, beyond the range of robot specifications</li> </ul>		<ul><li>Set maximum RPM speed to</li><li>Set acceleration/deceleration</li></ul>	
<ul> <li>Occurrence of mechanical external interference during operation implementation</li> </ul>		Check for mechanical external interference.	
■ Vibration or noise takes place due to poor gain adjustment		– Readjust GAIN.	

## 13.2.10 Program Error (E11.00 ~ E11.04, E11.50 ~ E11.51)

E11.00 Empty JOE	3		
Alarm Description	If there is currently no JOB to perform.		
Disabling Alarm		<b>▼</b> RESET	POWER ON/OFF
Alarm Classification		J	ОВ
Alarm Code	E11.00		1.00
T/P Display	Empty JOB		
Cause	Troubl		publeshooting
■ JOB not found in the number set to parameter (ROB_PGM)		- Set a JOB number to run on parameter (ROB_PGM) again.	
■ Incorrectly-set JOB number to parameter (ROB_PGM)			



E11.01 Compile Error			
Alarm Description	If performing JOB is abnormal when I/O(ROB_RUN) is performed.		
Disabling Alarm	RESET □ POWER ON/OFF  □ POWER ON/OFF		
Alarm Classification	JOB		
Alarm Code	E11.01		
T/P Display	JOB Compile Err		
Cause	Troubleshooting		
■ JOB to run not in norm condition	Delete the abnormal JOB, rewrite and run it.		

E11.03 Not JPGM in SBRT				
Alarm Description		If JPGM is	used by SBRT command.	
Disabling Alarm	▼ RESET			
Alarm Classification	JOB			
Alarm Code	E11.03			
T/P Display	JPGM in SBRT			
Cause	Troubleshooting		Troubleshooting	
■ JPGM used in SBRT command		– Do not use JPGM co	ommand in SBRT command.	

E11.04 Not JPGM in LOOP			
Alarm Description		If JPGM is ι	used by LOOP command.
Disabling Alarm			
Alarm Classification	JOB		
Alarm Code	E11.04		
T/P Display	JPGM in LOOP		
Cause	Troubleshooting		Troubleshooting
■ JPGM used in LOOP command		– Do not use JPGM co	ommand in LOOP command.



E11.50 Empty PLC				
Alarm Description	If there is no PLC JOB to perform			
Disabling Alarm	▼ RESET			
Alarm Classification	JOB			
Alarm Code	E11.50			
T/P Display	Empty PLC			
Cause	Troubleshooting			
<ul><li>PLC JOB number incorrectly set to parameter (PLC_PGM)</li></ul>		- Set a PLC JOB number	to run on parameter (PLC_PGM) again	

E11.51 PLC Compile Error			
Alarm Description	If PLC JOB which is to be performed is abnormal		
Disabling Alarm	▼ RESET		
Alarm Classification	JOB		
Alarm Code	E11.51		
T/P Display	PLC Compile Err		
Cause	Troubleshooting		
■ PLC JOB to run, not in norm condition	Delete the abnormal PLC JOB, rewrite and run it.		

## 13.2.11 Emergency Stop (E12.00 ~ E12.03)

E12.00 T/P Emergency			
Alarm Description	In case of emergency stop by the emergency stop switch of the Teaching  Pendant.		
Disabling Alarm		▼ RESET	
Alarm Classification		Protection	
Alarm Code	E12.00		
T/P Display	T/P Emergency		
Cause		Troubleshooting	
Emergency stop switch on teaching pendant is pressed down.		<ul> <li>Turn off the emergency stop switch on teaching pendant and reset the controller alarm.</li> </ul>	
<ul> <li>Error in overall switch line of an emergency stop switch on teaching pendant</li> </ul>		– Repair or replace the teaching pendant.	



E12.01 System I/O Emergency			
Alarm Description	If I/O is not connected		
Disabling Alarm		<b>▼</b> RESET	POWER ON/OFF
Alarm Classification		Prote	ection
Alarm Code	E12.01		2.01
T/P Display	SYS I/O Emergency		mergency
Cause		Troubleshooting	
■ I/O cable not connected in normal conditions		- Check out I/O cable connection.	
■ I/O cable not present		– Disable the alarm by setting 911 in parameter (USER_MODE).	

E12.02 Host Emergency				
Alarm Description	In ca	ase of emergency stop by emergency stop protocol at host mode.		
Disabling Alarm		▼ RESET		
Alarm Classification	Protection			
Alarm Code	E12.02			
T/P Display	Host Emergency			
Cause	Troubleshooting			
■ Emergency stop status by				
emergency stop protoc	ol in	Clear out emergency stop situations and reset the controller.		
Host mode				

E12.03 System PLC Emergency				
Alarm Description	If emergency occurs at CNET.			
Disabling Alarm				
Alarm Classification	Protection			
Alarm Code	E12.03			
T/P Display	SYS PLC Emergency			
Cause	Troubleshooting			
■ Emergency stop status by				
emergency stop protoc	col in	- Clear out emergency stop situations and reset the control	oller	
Host mode				



## 13.2.12 Over Speed (E13.00 ~ E13.02)

E13.00 Over Spee	d		
Alarm Description	The	error which occurs if speed co	mmand is over the specified value.
Disabling Alarm		<b>▼</b> RESET	POWER ON/OFF
Alarm Classification		Prote	ection
Alarm Code		E13	3.00
T/P Display	Over Speed		
Cause	Troubleshooting		ubleshooting
■ Error in system parameter (OVS) setting		If the set value for parameter (OVS) is set to low, adjust the set value.	
■ Error in parameter setting		<ul> <li>Adjust the set values for parameters (LMT_RPM, DFT_SPD, DFT_ACC, DFT_DEC, JOG_SPD0~3).</li> </ul>	
■ Error in robot commands for operation		Check out MOVE command in JOB, operating conditions (FOS, ACC, DEC) and suitability for teaching point.	

E13.02 Servo on Fail				
Alarm Description		Occurs wher	n SERVO ON fails.	
Disabling Alarm		▼ RESET		
Alarm Classification		Protection		
Alarm Code	E13.02			
T/P Display		Servo on fail		
Cause		Troubleshooting		
Servo on occurs due to AMP error.		If this keeps occurring after disabling the alarm, get an inspection from our authorized dealer and manufacture.		



## 13.2.13 Parameter Error (E14.00 ~ E14.04)

E14.00 Parameter I	Err		
Alarm Description		If the motor ID setting is	wrong when power is ON
Disabling Alarm		☐ RESET	POWER ON/OFF
Alarm Classification		Prote	ction
Alarm Code	E14.00		
T/P Display	Default Motor ID Err		
Cause		Troubleshooting	
System encountered a problem	а	– Turn power OFF / ON.	
■ RAM encountered wit problem	h a	Get an inspection from our authorized dealer and manufactur	

E14.01 Curr Pos B	uf Err			
Alarm Description		If current position	n is over the specified value	
Disabling Alarm				
Alarm Classification		Main		
Alarm Code	E14.01			
T/P Display		CURR POS Buff Err		
Cause		Troubleshooting		
■ Error in robot comman	ds for	Check out MOVE command in JOB, operating conditions (SPD) and suitability for teaching point.		

E14.02 Speed Command Buf Err				
Alarm Description	If speed command is over the specified value			
Disabling Alarm	▼ RESET			
Alarm Classification	Protection			
Alarm Code	E14.02			
T/P Display	SPEED CMD Buff Err			
Cause		Troubleshooting		
■ Error in robot command operation			d in JOB, operating conditions (SPD) and at.	



E14.03 Acc Command Buf Err				
Alarm Description		If acceleration comm	and is over the specified value	
Disabling Alarm		▼ RESET		
Alarm Classification		Protection		
Alarm Code	E14.03			
T/P Display		ACC CMD Buff Err		
Cause		Troubleshooting		
■ Error in robot commands for operation		<ul> <li>Check out MOVE com</li> <li>DEC) and suitability fo</li> </ul>	mand in JOB, operating conditions (FOS, ACC, r teaching point.	

E14.04 Dec Command Buf Err				
Alarm Description		If deceleration com	mand is over the specified value.	
Disabling Alarm		▼ RESET		
Alarm Classification		Protection		
Alarm Code		E14.04		
T/P Display		DEC CMD Buff Err		
Cause		Troubleshooting		
<ul><li>Error in robot commands for operation</li></ul>		<ul> <li>Check out MOVE command in JOB, operating conditions (FOS, ACC,</li> <li>DEC) and suitability for teaching point.</li> </ul>		

## 13.2.14 Software Alarm (E15.00)

E15.00 Software Alarm				
Alarm Description	If ALARM command is performed.			
Disabling Alarm	▼ RESET			
Alarm Classification	Protection			
Alarm Code	E15.00			
T/P Display	Software Alarm			
Cause	Troubleshooting			
<ul><li>Generated by the use of ALARM command in JOB</li></ul>	- Reset the alarm.			



E15.01 Not found origin				
Alarm Description			Origin not	completed
Disabling Alarm		<b>▼</b> RESET		POWER ON/OFF
Alarm Classification		Protection		
Alarm Code		E15.01		
T/P Display		Not Found Origin		
Cause		Troubleshooting		
■ Occurs when the origi	n is not			
completed in activating	g the	<ul> <li>Activate the robot following origin implementation.</li> </ul>		
robot (Auto, Step) usir	ng IO.			

# 13.3 Warning Code Scene and Troubleshooting (Alarm Code Description)

13.3.1 JOB (E20.00 ~ E20.24)

E20.00 Invalid JOB Command				
Alarm Description		If JOB command is abnormal.		
Disabling Alarm		▼ RESET	F	
Alarm Classification	Main			
Alarm Code	E20.00			
T/P Display		Invalid number		
Cause		Troubleshooting		
■ Robot program area E	Back up	ир		
RAM damaged		Delete the corresponding program.		
■ Use of an invali command	d JOB -	<ul> <li>Double-check the commands used in JOB program.</li> </ul>		

E20.01 No match Label				
Alarm Description	Br	Branch point position corresponding to execute statement is not		
			designated.	
Disabling Alarm	▼ RESET			
Alarm Classification	Main			
Alarm Code	E20.01			
T/P Display	No match LBL			
Cause	Troubleshooting			
■ No LBL xxx corresponding to GOTO xxx is found.		– Insert LBL xxx.		



E20.02 Same Label Number				
Alarm Description	If branch point position corresponding to execute statement exist more than 2 points.			
Disabling Alarm		<b>▼</b> RESET	POWER ON/OFF	
Alarm Classification	Main			
Alarm Code	E20.02			
T/P Display		Same	e LBL number	
Cause	Troubleshooting			
More than 2 LBL xxx corresponding to GOTO present.	) xxx are			

E20.03 RET Before SBRT				
Alarm Description	If 'subı	routine end' command is used	prior to 'subroutine start' command.	
Disabling Alarm	▼ RESET			
Alarm Classification	Main			
Alarm Code	E20.03			
T/P Display	RET before SBRT			
Cause	Troubleshooting			
RET command used earlier than SBRT command		– Use RET command after SE	BRT.	

E20.04 No match SBRT			
Alarm Description	If designated command corresponding to call command of sub execute statement does not exist.		
Disabling Alarm	✓ RESET   ☐ POWER		POWER ON/OFF
Alarm Classification	Main		
Alarm Code	E20.04		
T/P Display	No match SBRT		
Cause		Troubleshooting	
■ There is no SBRT xxx corresponding to CALL xxx.		<ul><li>Write a SBRT corresponding to CALL to the program.</li><li>Delete CALL command.</li></ul>	



E20.05 Same SBRT Number			
Alarm Description	If the same SBRT number is used more than twice in one program.		
Disabling Alarm	<b>▼</b> RESET		POWER ON/OFF
Alarm Classification	Main		
Alarm Code	E20.05		
T/P Display	Same SBRT number		
Cause		Troubleshooting	
■ Use of SBRT with the same name more than twice		Write the number in different	nt ways.

E20.06 JPGM too many			
Alarm Description	If branches of the designated program is over 8 times.		
Disabling Alarm			
Alarm Classification	Main		
Alarm Code	E20.06		
T/P Display	JPGN	JPGM too many	
Cause	1	Troubleshooting	
■ JPGM command used more than 8 times		Limit the use of JPGM command to 8 times at maximum.	

E20.07 JPGM to itself			
Alarm Description	If the user wants to branch to the designated program.		
Disabling Alarm	<b>▼</b> RESET	POWER ON/OFF	
Alarm Classification	Main		
Alarm Code	E20.07		
T/P Display	JPGM to itself		
Cause		Troubleshooting	
JOB number to branch is current program.	the – Set the number to b	oranch.	



E20.08 JPGM to empty pgm			
Alarm Description	If non-existent program is selected		
Disabling Alarm	▼ RESET		POWER ON/OFF
Alarm Classification	Main		
Alarm Code	E20.08		
T/P Display	JPGM to empty pgm		
Cause	use Troubleshooting		Troubleshooting
<ul><li>Attempt to move to the unwritten program</li></ul>		<ul><li>Write a command to the corresponding program number.</li><li>From the parameter, select the program number where a command is written.</li></ul>	

E20.09 No Match ENDL			
Alarm Description	If there is no command which indicates the end of the designated LOOP.		
Disabling Alarm	<b>▼</b> RESET		POWER ON/OFF
Alarm Classification	Main		
Alarm Code	E20.09		
T/P Display	No match ENDL		
Cause		Troubleshooting	
■ There is no END xxx corresponding to LOOP xxx Lyy		– Delete LOOP xxx Lyy or inse	ert ENDL xxx.

E20.10 Same ENDL number			
Alarm Description	If there are more than 2 commands which indicate the end of the		
	designated LOOP.		
Disabling Alarm	<b>▼</b> RESET		POWER ON/OFF
Alarm Classification	Main		
Alarm Code	E20.10		
T/P Display	Same ENDL number		
Cause		Troubleshooting	
■ There are more than 2 END xxx		- Keep only 1 NDL xxx alive and delete the rest ENDL xxx.	
corresponding to LOOP xxx Lyy.			



E20.11 LOOP too many nest			
Alarm Description	If repetitive statement is used more than 16 times.		
Disabling Alarm	▼ RESET		POWER ON/OFF
Alarm Classification	Main		
Alarm Code	E20.11		
T/P Display	LOOP too many nest		
Cause	Troubleshooting		
■ LOOP is used more that times within LOOP.	n 16	– Limit LOOP repeat bet	ween LOOP and ENDL to less than 16 times.

E20.12 No match LOOP				
Alarm Description	If t	If there is no LOOP command corresponding to ENDL or if ENDL is		
Alaini Description		incorrectly used		
Disabling Alarm	▼ RESET  □ POWER ON/OFF		POWER ON/OFF	
Alarm Classification	Main			
Alarm Code	E20.12			
T/P Display	No match LOOP			
Cause	Troubleshooting			
■ There is no LOOP xxx Lyy corresponding to ENDL xxx.		– Delete ENDL xxx or inse	rt LOOP xxx Lyy.	

E20.13 Same LOOP Number			
Alarm Description	If there are more than 2 commands which indicate the start of designated		
Alaini Description		LO	OOP
Disabling Alarm	▼ RESET		POWER ON/OFF
Alarm Classification	Main		
Alarm Code	E20.13		
T/P Display	Same LOOP Number		
Cause	Troubleshooting		ubleshooting
■ There are more than 2	LOOP		
xxx Lyy corresponding	to ENDL	<ul> <li>Keep only 1 LOOP xxx Lxx a</li> </ul>	alive and delete the rest LOOP xxx Lxx.
XXX.			



E20.14 ENDL before LOOP				
Alarm Description	there	there is the command expressing repetitive statement end prior to that expressing start.		
Disabling Alarm				
Alarm Classification	Main			
Alarm Code	E20.14			
T/P Display	ENDL before LOOP			
Cause	Troubleshooting			
■ ENDL command used of than LOOP command.	earlier	LOOP command.	nands prior to ENDL command and after command and LOOP command.	

E20.15 Not Output Port			
Alarm Description		If there is no designated p	ort for output contact point.
Disabling Alarm	▼ RESET		
Alarm Classification	Main		
Alarm Code	E20.15		
T/P Display	Not Output port		
Cause	Troubleshooting		
■ The contact assigned t BBxx is the input port.	о Вххх,	<ul> <li>Assign a contact to output</li> </ul>	to an output port or an internal contact.

E20.16 Not Pair SBRT RET			
Alarm Description		SBRT and RET r	not in consistent as a pair.
Disabling Alarm	▼ RESET		
Alarm Classification	Main		
Alarm Code	E20.16		
T/P Display	Not pair SBRT, RET		
Cause	Troubleshooting		Troubleshooting
<ul> <li>JOB command SBRT and not consistent as a pair</li> </ul>	I RET	- Check out the number	r of SBRTs and RETs.



E20.17 Not Pair LOOP ENDL				
Alarm Description		LOOP and ENDL not consistent as a pair		
Disabling Alarm	✓ RESET POWER ON/OFF		POWER ON/OFF	
Alarm Classification	Main			
Alarm Code	E20.16			
T/P Display	Not pair LOOP, ENDL			
Cause	Troubleshooting			
■ JOB commands LOOP ENDL not consistent as		<ul> <li>Check out the number of LOC</li> </ul>	Ps and ENDLs.	

E20.18 Invalid XIF Command				
Alarm Description		If the command can not be operated.		
Disabling Alarm		▼ RESET		
Alarm Classification	Main			
Alarm Code	E20.18			
T/P Display	Invalid XIF command			
Cause	Troubleshooting			
■ Commands SPD, ACC, DEC, and GOTO do not come after XIF.		Limit commands coming after XIF to SPD, ACC, DEC, and GOTO.		

E20.19 Not mapp	ing IOP	os	
Alarm Description	If coordinate value of position parameter IOPOS is not designated.		
Disabling Alarm		<b>▼</b> RESET	POWER ON/OFF
Alarm Classification		Ma	ain
Alarm Code	E20.19		
T/P Display	Not mapping IOPOS		
Cause		Tro	ubleshooting
■ IOPOS(0 ~ 3) and MO' are not assigned as a when using a MOVAT command in the progr	contact	<ul> <li>Set a contact for IOPOS(0 ~ use.</li> </ul>	~ 3) and MOVT_ST in the parameter before



E20.20 Too Many SBRT CALL			
Alarm Description	SBRT and CALL repeated more than 16 times		
Disabling Alarm	▼ RESET		POWER ON/OFF
Alarm Classification	Main		
Alarm Code	E20.20		
T/P Display	Too Many SBRT Call		
Cause	Troubleshooting		
■ SBRT and CALL LOOP i more than 16 times.	s used	– Limit SBRT and CALL to	be repeated to less than 16 times.

E20.21 Point Rang	e Over		
Alarm Description		The number of Point	variable is incorrectly set.
Disabling Alarm	▼ RESET		
Alarm Classification	Main		
Alarm Code	E20.21		
T/P Display	PNT Index Range Over		
Cause	Troubleshooting		
■ The number of Point va beyond the range.	riable	Check if the number is in	0 ~ 1023 range.

E20.22 Integer Range Over			
Alarm Description	The number range for integer variable is incorrectly set.		
Disabling Alarm	▼ RESET		
Alarm Classification	Main		
Alarm Code	E20.22		
T/P Display	INT Index Range Over		
Cause	Troubleshooting		
■ The number of Integer v beyond the range	ariable	– Check if the number is in 0 ~ 255 range.	



E20.23 Const Value Range Over			
Alarm Description	The range of Position value is incorrectly set.		
Disabling Alarm	▼ RESET		
Alarm Classification	Main		
Alarm Code	E20.23		
T/P Display	CONST Val Range Over		
Cause		Troubleshooting	
<ul><li>Position variable beyon range</li></ul>	d the	- Check if the value is in -99	999.999 ~ 99999.999 range.

E20.24 Invalid SPD Value				
Alarm Description		SPD command value is not 0.		
Disabling Alarm		<b>▼</b> RESET	POWER ON/OFF	
Alarm Classification		Main		
Alarm Code		E20.24		
T/P Display		Invalid SPD Value		
Cause		Troubleshooting		
■ SPD command value is 0. –		– Change SPDSet value	to a value exceeding 0.	

# 13.3.2 JOB Command (E20.50~20.99)

E20.50 Invalid SERVO Command			
Alarm Description	Detailed SERVO command not in normal condition		
Disabling Alarm		▼ RESET	
Alarm Classification	Main		
Alarm Code	E20.50		
T/P Display		Invalid SERVO cmd	
Cause		Troubleshooting	
■ Detailed SERVO co	mmand		
not in normal condition		<ul> <li>Check out SERVO command</li> </ul>	ı agam.



E20.51 Invalid MOVA Command			
Alarm Description	Detailed MOVA command not in normal condition		
Disabling Alarm	▼ RESET		POWER ON/OFF
Alarm Classification	Main		
Alarm Code	E20.51		
T/P Display		Invalid MOVA command	
Cause		Troubleshooting	
■ Detailed MOVA cornot in normal condition		– Check out MOVA command again.	

E20.52 Invalid MOVI Command				
Alarm Description	Detailed MOVI comma	Detailed MOVI command not in normal condition		
Disabling Alarm				
Alarm Classification	Main			
Alarm Code	E20.52			
T/P Display	Invalid M	Invalid MOVI command		
Cause	Т	Troubleshooting		
■ Detailed MOVI comma		nd again		
not in normal condition	- Check out MOVI comma	Check out MOVI command again.		

E20.53 Invalid MOVR Command				
Alarm Description	Detailed MOVR command not in normal condition			
Disabling Alarm		▼ RESET		
Alarm Classification	Main			
Alarm Code	E20.53			
T/P Display		Invalid MOVI command		
Cause		Troubleshooting		
■ Detailed MOVR cor	mmand	Charle and MOVD assessed	Lamain	
not in normal condition	on	Check out MOVR command again.		



E20.54 Invalid MOVM Command			
Alarm Description	Detailed MOVM command not in normal condition		
Disabling Alarm	▼ RESET		
Alarm Classification	Main		
Alarm Code	E20.54		
T/P Display	Invalid MOVM command		
Cause		Troubleshooting	
■ Detailed MOVM co	mmand	Chask out MOVM common	d again
not in normal condition		<ul> <li>Check out MOVM comman</li> </ul>	u again.

E20.55 Invalid FOS Command			
Alarm Description	Detailed FOS command not in normal condition		
Disabling Alarm		<b>▼</b> RESET	POWER ON/OFF
Alarm Classification	Main		
Alarm Code	E20.55		
T/P Display	Invalid FOS command		
Cause	Troubleshooting		
■ Detailed FOS command not		Charle aut FOC gammand a	
in normal condition		Check out FOS command again.	

E20.56 Invalid REF Command			
Alarm Description		Detailed REF command not in normal condition	
Disabling Alarm			
Alarm Classification	Main		
Alarm Code	E20.56		
T/P Display	Invalid REF command		
Cause	Troubleshooting		
■ Detailed REF command not			
in normal condition		Check out REF command again.	



E20.57 Invalid SPD Command			
Alarm Description	Detailed SPD command not in normal condition		
Disabling Alarm		<b>▼</b> RESET	POWER ON/OFF
Alarm Classification	Main		ain
Alarm Code	E20.57		
T/P Display		Invalid SPD command	
Cause		Troubleshooting	
■ Detailed SPD command not in normal condition		- Check out SPD command a	gain.

E20.58 Invalid ACC Command				
Alarm Description	Detailed ACC command not in normal condition			
Disabling Alarm				
Alarm Classification	Main			
Alarm Code	E20.58			
T/P Display	Inval	Invalid ACC command		
Cause	Troubleshooting			
■ Detailed ACC command	d not   - Check out ACC com	mand again		
in normal condition	Check out nee com	muna agam.		

E20.59 Invalid DEC Command			
Alarm Description	Detailed DEC command not in normal condition		
Disabling Alarm		▼ RESET	
Alarm Classification	Main		
Alarm Code	E20.59		
T/P Display		Invalid DEC command	
Cause	Troubleshooting		
■ Detailed DEC command not		Charle out DEC command	again
in normal condition		<ul> <li>Check out DEC command again.</li> </ul>	



E20.60 Invalid IF Command			
Alarm Description	Detailed IF command not in normal condition		
Disabling Alarm	▼ RESET		POWER ON/OFF
Alarm Classification	Main		lain
Alarm Code	E20.60		0.60
T/P Display	Invalid IF command		command
Cause		Tro	publeshooting
■ Detailed IF command not in		- Check out IF command ag	ain
normal condition		<ul> <li>Check out IF command age</li> </ul>	aiii.

E20.61 Invalid WAIT Command			
Alarm Description		Detailed WAIT command	not in normal condition
Disabling Alarm		<b>▼</b> RESET	POWER ON/OFF
Alarm Classification	Main		ain
Alarm Code	E20.61		.61
T/P Display	Invalid WAIT command		Γ command
Cause		Trou	ubleshooting
■ Detailed WAIT condit		Check out WAIT command	again.

E20.62 Invalid BIT Command			
Alarm Description	Detailed BIT command not in normal condition		
Disabling Alarm	▼ RESET		POWER ON/OFF
Alarm Classification	Main		ain
Alarm Code	E20.62		0.62
T/P Display	Invalid BIT command		command
Cause		Tro	ubleshooting
■ Detailed BIT command not		Cl. I DIT	
in normal condition		<ul> <li>Check out BIT command ag</li> </ul>	gairi.



E20.63 Invalid BYTE Command			
Alarm Description	Detailed BYTE command not in normal condition		
Disabling Alarm	▼ RESET		
Alarm Classification	Main		
Alarm Code	E20.63		
T/P Display	Invalid BYTE command		
Cause	Troul	oleshooting	
■ Detailed BYTE command not in normal condition	Check out BYTE command ag	gain.	

E20.64 Invalid INT Command			
Alarm Description	Detailed INT command	not in normal condition	
Disabling Alarm	<b>▼</b> RESET	POWER ON/OFF	
Alarm Classification	Main		
Alarm Code	E20.64		
T/P Display	Invalid INT command		
Cause	Tro	oubleshooting	
■ Detailed INT command i		one in	
in normal condition	Check out INT command a	agam.	

E20.65 Invalid POS Command			
Alarm Description	Detailed POS command not in normal condition		
Disabling Alarm	✓ RESET  ✓ POWER ON/OFF		POWER ON/OFF
Alarm Classification	Main		1ain
Alarm Code	E20.65		20.65
T/P Display	Invalid POS command		S command
Cause		Tro	oubleshooting
■ Detailed POS command not in normal condition		Charle out DOS command	again
		Check out POS command again.	



E20.66 Invalid GOTO Command			
Alarm Description	Detailed GOTO command not in normal condition		
Disabling Alarm			POWER ON/OFF
Alarm Classification	Main		١
Alarm Code	E20.66		6
T/P Display	Invalid GOTO command		command
Cause		Troub	leshooting
■ Detailed GOTO co	mmand	- Check out GOTO command a	gain
not in normal condition	on	- Check out GOTO command again.	

## 13.3.3 PLC (E21.00 ~ E21.13)

E21.00 Invalid PLC Command				
Alarm Description			PLC program area in Back	up RAM is damaged
Disabling Alarm			<b>▼</b> RESET	POWER ON/OFF
Alarm Classification	Main		1	
Alarm Code	E21.00		0	
T/P Display	Invalid number		mber	
Cause			Troub	leshooting
■ Robot program area in Back		_	Delete the corresponding prog	gram.
up RAM is damaged.	ged.			
■ Use of invalid PLC comm	mand	ı	Double-check PLC command a	and rewrite it.

E21.01 Invalid bit addr			
Alarm Description	If	contact point address which	is set in the program is out of the
Alaini Description		correspo	nding range.
Disabling Alarm		<b>▼</b> RESET	POWER ON/OFF
Alarm Classification	Main		
Alarm Code	E21.01		21.01
T/P Display	Invalid bit addr		d bit addr
Cause		Tr	oubleshooting
■ The contact address set in the		- Check out signal specifica	ation in connecting the manual 2.2.3.5.
program goes beyond	program goes beyond the		nd change it to the contact address in the
range.		range.	



E21.02 LOAD Command too many			
Alarm Description		If stored unnecessary logic calculus command exceeds 30.	
Disabling Alarm		▼ RESET	
Alarm Classification		Main	
Alarm Code		E21.02	
T/P Display	LOAD too many		
Cause		Troubleshooting	
■ Contact information sav	ed with		
the use of LOAD(LOAD I	NOT)		
command is not used as		Delete LOAD(LOAD NOT) command which is not used as such	
commands D, OUT, while		command as D, OUT.	
saving more than 30 pieces of			
the information			

E21.03 LOAD Command expected			
Alama Danaistina	If contact point information which is stored at the start of logic calculus		
Alarm Description		uses MCS, NO	OT command.
Disabling Alarm		<b>▼</b> RESET	POWER ON/OFF
Alarm Classification	Main		ain
Alarm Code	E21.03		1.03
T/P Display	LOAD expected		expected
Cause		Tro	ubleshooting
■ Contact information sa	ved with		
the use of LOAD(LOAD NOT)		- Check out PLC IOB	
command uses MCS, N	TOI	CHECK OUT I LE JOB.	
commands.			

E21.04 Needs more 2 blocks			
Alarm Description	If stor	red contact point information at LOAD command use is less than 2	
Disabling Alarm		▼ RESET	
Alarm Classification	Main		
Alarm Code	E21.04		
T/P Display	Needs more 2 blocks		
Cause		Troubleshooting	
■ Contact information sa	ved with		
the use of LOAD(LOAD NOT)		- Use LOAD command to use 2 or more pieces of contact information.	
command is less than	2 pieces.		



E21.05 Not Output	ıt Port		
Alarm Description		If there is no designa	ted port for output contact point.
Disabling Alarm	▼ RESET		
Alarm Classification			Main
Alarm Code	E21.05		
T/P Display	Not Output port		
Cause	Troubleshooting		
A contact to output is input contact.	set to an  - Input contact is unable to be used in output contacts such as D, SET, OUT.		

E21.06 D(CNT) Command too many			
Alarm Description	If D or D NOT co	ommand exceeds 288 times.	
Disabling Alarm	▼ RESET		
Alarm Classification	Main		
Alarm Code	E21.06		
T/P Display	D(CNT) too many		
Cause	Troubleshooting		
■ Command D or D NOT is over 288 times.		and D or DNOT below 288 times.	

E21.07 Needs mor	e 1 blo	ck		
Alarm Description	If	f there is no stored contact point information at logic calculus.		
Disabling Alarm		✓ RESET  ✓ POWER ON/OFF		
Alarm Classification		Main		
Alarm Code		E21.07		
T/P Display		Needs more 1 block		
Cause	Troubleshooting		ubleshooting	
■ Command OUT is used	without			
contact information saved by		- Available to be used only when there is contact information saved by		
using LOAD(LOAD NOT)	)	using LOAD(LOAD NOT) command.		
command				



E21.08 MCS too many nest			
Alarm Description	If common interlock set (Clear) is duplicated over 30 times.		
Disabling Alarm	▼ RESET		
Alarm Classification	Main		
Alarm Code	E21.08		
T/P Display	MCS too many nest		
Cause	Troubleshooting		
■ MCS ~ MCSC Block is overlapping 30 times or more.		– Limit overlapping of MCS	5 ~ MCSC Block below 30 times.

E21.09 MCS block	not en	nd		
Alarm Description	If all	contact point information is not used at the start of logic calculus.		
Disabling Alarm		▼ RESET		
Alarm Classification	Main			
Alarm Code	E21.09			
T/P Display		MCS block not end		
Cause	Troubleshooting			
■ None of contact information saved by LOAD(LOAD NOT) between MCS and MCSC Block is used.		<ul> <li>Contact information saved by command LOAD(LOAD NOT) between MCS and MCSC Block should all be used with the use of commands OUT, D.</li> </ul>		

E21.10 No MCS b	lock			
Alarm Description	I	If Clear command is only used without common interlock set.		
Disabling Alarm		▼ RESET		
Alarm Classification		Main		
Alarm Code		E21.10		
T/P Display		No MCS block		
Cause		Troubleshooting		
■ MCSC command is use	ed			
without the use of MC	S	MCS command should be used with MCS in pair.		
command.				



E21.11 TMR Command too many				
Alarm Description	If TMR command usage exceeds 64 times.			
Disabling Alarm				
Alarm Classification	Main			
Alarm Code	E21.11			
T/P Display	TMR too many			
Cause		Troubleshooting		
■ TMR command is used more than 64 times.		– Put the use of TMR	command below 64 times.	

E21.13 Program N	ot END	)	
Alarm Description	If all o	contact point information is not used at the start of logic calculus.	
Disabling Alarm		▼ RESET	
Alarm Classification	Main		
Alarm Code	E21.13		
T/P Display	Program not end		
Cause	Troubleshooting		
<ul> <li>None of contact inform saved by LOAD(LOAD command is used.</li> </ul>	<ul> <li>Contact information saved by LOAD(LOAD NOT) command should</li> </ul>		

13.3.4 ETC (E22.00 ~ 22.20)

E22.00 Last code	step			
Alarm Description		if input value for Jump function	usage goes beyond last line.	
Disabling Alarm		<b>▼</b> RESET	POWER ON/OFF	
Alarm Classification	Main			
Alarm Code	E22.00			
T/P Display	Last step			
Cause	Troubleshooting			
■ The value beyond the	last line			
is entered when using	ng a Line – Enter the value suited to the range.		range.	
Jump function.				



E22.01 Same Input port para			
Alarm Description	If input contact point setting is duplicated.		
Disabling Alarm		<b>▼</b> RESET	POWER ON/OFF
Alarm Classification	Main		
Alarm Code	E22.01		
T/P Display	Same Input port		
Cause		Tro	ubleshooting
<ul> <li>Setting the same input contact to different function when setting an input contact parameter.</li> </ul>		<ul> <li>Set other contacts to each</li> </ul>	function.

E22.03 Not Change i	n			
Alarm Description	If parameter is o	changed for Servo ON state.		
Disabling Alarm	▼ RESET			
Alarm Classification	Main			
Alarm Code	E22.03			
T/P Display	N	Not Change in		
Cause		Troubleshooting		
Parameter is changed in S ON.	Servo – Change parameter va			

E22.06 Not Edit in	1		
Alarm Description	If	the program is edited while th	ne robot program is performed.
Disabling Alarm			
Alarm Classification	Main		
Alarm Code	E22.06		
T/P Display	Not Edit in		
Cause	Troubleshooting		
■ To edit the program while the robot program is running.		– Stop the robot program fro	m running and edit the program.



E22.07 Not Delete	in		
Alarm Description	If	the program is deleted	while the robot program is performed
Disabling Alarm		<b>▼</b> RESET	POWER ON/OFF
Alarm Classification	Main		Main
Alarm Code	E22.07		
T/P Display		Not Delete in	
Cause		Troubleshooting	
■ To delete the program the program is running		– Stop the robot prog	ram from running and edit the program.

E22.08 is not emp	ty			
Alarm Description		If another program is	copied <sup>.</sup>	to already existing program.
Disabling Alarm	▼ RESET		POWER ON/OFF	
Alarm Classification	Main			
Alarm Code		E22.08		
T/P Display		is not empty		
Cause		Troubleshooting		
■ To copy another prograte the saved program.	ım to	<ul><li>Delete the saved program and copy it again.</li><li>Copy to another empty program.</li></ul>		

E22.09 is empty			
Alarm Description	If no	on-existence program is copied	
Disabling Alarm	<b>▼</b> RESET	☐ POWER ON/OFF	
Alarm Classification	Main		
Alarm Code	E22.09		
T/P Display		is empty	
Cause		Troubleshooting	
■ To copy an empty progra	m. – Write and co	opy the program.	



E22.10 Not copy itself			
Alarm Description		If the sa	ame program is copied.
Disabling Alarm		<b>▼</b> RESET	POWER ON/OFF
Alarm Classification	Main		Main
Alarm Code	E22.10		
T/P Display		Not copy itself	
Cause		Troubleshooting	
■ To copy the same program.		– Copy is possible o	nly to other empty program.

E22.11 Invalid number			
Alarm Description		the range is beyond the setting range when program is edited or	
		para	ameter is set.
Disabling Alarm		<b>▼</b> RESET	POWER ON/OFF
Alarm Classification	Main		
Alarm Code	E22.11		
T/P Display	Invalid number		
Cause	Troubleshooting		
■ Going beyond the inpu	ıt range		
when program editing	or	<ul> <li>Enter a value suited to</li> </ul>	the range.
parameter setting			

E22.12 Step not enough.			
Alarm Description	If the specified step number and capacity is out of range for Block		
Alaini Description		pro	ogramming.
Disabling Alarm		<b>▼</b> RESET	POWER ON/OFF
Alarm Classification			Main
Alarm Code	E22.12		
T/P Display	Step not enough.		
Cause	Troubleshooting		Troubleshooting
■ Program exceeds 100 s	steps or		
400 words when copying or		Each program should be written in 1000 step or 4000 word range.	
writing the set program Block		Lacii program should b	e writter in 1000 step of 4000 word range.
to the program.			



E22.13 Not end b	lock set		
Alarm Description		If block unit is edited wh	hen program is still running.
Disabling Alarm		<b>▼</b> RESET	POWER ON/OFF
Alarm Classification	Main		
Alarm Code	E22.13		
T/P Display	Not end block set		
Cause		Troubleshooting	
■ To edit in block unit w	ithout		
completion of setting p	program – Complete program block setting and implement editing in block ur		
block			

E22.14 Clipboard Empty			
Alarm Description	If 'Write' is performed without storing to the memory after Block is programmed.		
Disabling Alarm		<b>▼</b> RESET	POWER ON/OFF
Alarm Classification	Main		
Alarm Code	E22.14		2.14
T/P Display	Clipboard Empty		d Empty
Cause	Troubleshooting		ubleshooting
■ Implementing block write by reading the set block and not saving it to the memory		Read the set block and save write.	e it to the memory before running block

E22.15 Too large block			
Alarm Description	The size of programmed Block is out of the setting range.		
Disabling Alarm	▼ RESET		
Alarm Classification	Main		
Alarm Code	E22.15		
T/P Display	Too large block		
Cause	Troubleshooting		
■ The set block goes bey 2500Byte.	nd – Block should be within 2500Byte.		



E22.16 Robot is running			
Alarm Description	If Jog	g or Origin is tried to be performed during Robot Run performing.	
Disabling Alarm		▼ RESET	
Alarm Classification	Main		
Alarm Code	E22.16		
T/P Display	Robot is running		
Cause	Troubleshooting		
■ To operate Jog or Origin while the robot program is running.		Stop the robot program from running and operate the Origin.	

E22.17 Jog is runr	ning		
Alarm Description	If Ro	obot Run or Origin is tried to	be performed during Jog running.
Disabling Alarm		<b>▼</b> RESET	POWER ON/OFF
Alarm Classification	Main		
Alarm Code	E22.17		
T/P Display	Jog is running		
Cause	Troubleshooting		
■ To operate robot program or Origin while Jog is running.		– Stop jog operation and op	erate robot program or origin.

E22.18 Origin running			
Alarm Description	If R	obot Run or Jog is tried to be	performed during Origin running.
Disabling Alarm		<b>▼</b> RESET	POWER ON/OFF
Alarm Classification	Main		ain
Alarm Code	E22.18		
T/P Display		Origin running	
Cause	Troubleshooting		
■ To operate robot program or Jog while Origin is running.		- Finish Origin operation and ru	n the robot program or Jog.



E22.19 Not Origin Mode			
Alarm Description	If Origin is performed after setting ORG_RULE value as '0'.		
Disabling Alarm			
Alarm Classification	Main		
Alarm Code	E22.19		
T/P Display	Not Origin Mode		
Cause	Cause Troubleshooting		Troubleshooting
■ To set ORG_RULE to '0' and run Origin.		<ul> <li>Set ORG_RULE to ot</li> </ul>	her value, instead of '0'.

E22.20 Not Save in			
Alarm Description	If parameter is tried to be stored during Robot Run.		
Disabling Alarm		<b>▼</b> RESET	POWER ON/OFF
Alarm Classification	Main		
Alarm Code	E22.20		
T/P Display	Not Save in		
Cause		Trou	ubleshooting
■ To save the parameter while the robot program is running.		– Stop the robot program fro	m running and save the parameter.

E22.21 Not Input port			
Alarm Description	If output contact point is set to input contact point for parameter value setting.		
		3C	
Disabling Alarm	▼ RESET		POWER ON/OFF
Alarm Classification	Main		
Alarm Code	E22.21		
T/P Display	Not Input port		
Cause		Tro	oubleshooting
<ul><li>Output contact is set to input contact parameter</li></ul>		Area except for output co	ntacts B03, B04 is set to input contact.



E22.22 Not Output port			
Alarm Description	If input contact point is set to output contact point for parameter value setting.		
Disabling Alarm			POWER ON/OFF
Alarm Classification	Main		
Alarm Code	E22.22		
T/P Display	Not Output port		
Cause		Tro	ubleshooting
■ Input contact is set to output contact parameter		- Output contact is set to the	e values for B03~B31 area.

## 13.3.5 Alarm End Code (E99.98 ~ E99.99)

E99.98 Wrong Alarm code				
Alarm Description	If Alarm code exceeds front 2 digits.			
Disabling Alarm			POWER ON/OFF	
Alarm Classification	Main			
Alarm Code	E99.98			
T/P Display	Wrong Alarm code			
Cause	Troubleshooting		ubleshooting	
■ Back up RAM error prevents an				
alarm code from saving in – Initialize either an alarm code or Back up RAM.		de or Back up RAM.		
normal order.	ormal order.			

E99.99 UNDEF ERR CODE			
Alarm Description	If it does not exist at current Alarm code.		
Disabling Alarm	▼ RESET		
Alarm Classification	Undefine		
Alarm Code	E99.99		
T/P Display	UNDEF ERR CODE		
Cause	Troubleshooting		
■ An unidentified alarm occurs.   - In the event of a persistent alarm, get an inspection authorized dealer and manufacture.		<ul> <li>In the event of a persistent alarm, get an inspection from our authorized dealer and manufacture.</li> </ul>	



# ch.14 Abnormal Symptom Troubleshooting

# 14.1 Troubleshooting for Abnormal Symptoms Likely to Occur in JOG Operation

#### ■ Occurrence of mechanical noise

NO	Cause	Troubleshooting
1	Poor precision (Floor plan) of an installation surface	Do the installation after correcting (Floor plan) using thickness tape.
2	Mixed foreign material	Rinse the area mixed with foreign material and inject grease again.
3	Used beyond the speed limit	Lower speed below the speed limit.
4	Coupling unfastened	Refasten the coupling. (Coupling may be unfastened by vibration and below limit acceleration/deceleration time.)
5	Lack of grease	Remove existing grease and inject new grease.
6	Incorrect GAIN settings	Adjust Gain.
7	Inappropriate timing belt tension	Adjust the tension of a timing belt.
8	Damage to ball screws or operation for over 15000 hours	Replace ball screws.
9	Damage to a linear-motion bearing or operation for over 25000km	Replace the linear-motion bearing.
10	Abnormal operation of a brake	Replace the brake.
11	Interference by damage to mechanism body	Replace the component.



#### ■ Vibration occurrence

NO	Cause	Troubleshooting
1	Used beyond the speed limit	Lower speed below the speed limit.
2	Used below limit acceleration/deceleration time	Adjust acceleration/deceleration time longer.
3	Insufficient rigidity of a bracket	Improve bracket rigidity and fasten the floor surface with anchor bolts.
4	Poor fastening of bolts for robot installation	Check if bolts are completely fastened. Ensure bolt length is appropriate. Check out the above and fasten with standard fastening torque. Take preventive measures against bolt loosening. (Loctite coating, fastening nylok bolts)
5	Overload	Lower speed or adjust acceleration/deceleration time longer.
6	Incorrect GAIN settings	Refer to '5.3.1.2 GAIN'.
7	Resonates with other devices	Adjust acceleration/deceleration speed.

# ■ Unstable robotic operation & congestion occurrence

NO	Cause	Troubleshooting
1	Different in Pitch/Rev(Gear Ratio) value	Modify Pitch/Rev(Gear Ratio) value.
2	Origin sensor and encoder Z-phase are consistent or adjacent (In INC serial encoder)	After completing the origin on Teach Pendant, adjust the origin sensor or coupling location when Z-phase pulse value is not in $1\sim 2000$ range.



# ■ Occurrence of poor positioning precision

NO	Cause	Troubleshooting
1	Error in mechanical lead	Contact our company when there is a need for positioning precision in process.

# ■ Occurrence of poor positioning precision

NO	Cause	Troubleshooting
1	Damage to ball screws	Replace ball screws.
2	Poor precision (Floor plan) of an installation surface	Refer to the above item 'Poor precision (Floor plan) of an installation surface'.
3	Low in Position Gain	Raise the Position Gain. (Refer to '5.3.1.2 GAIN'.)
4	Poor fastening of bolts for robot installation	Refer to the above item 'Poor fastening of bolts for robot installation'.
5	Insufficient rigidity of a bracket	Refer to the above item 'Insufficient rigidity of a bracket'.
6	Coupling unfastened or damaged	Fasten the coupling or replace it.



# 14.2 Move Robot by JOG to Check out Operating Status of Limit Sensor on Axis

- At this time, the robot is in normal operation when an alarm sounds on Teach Pendant, and when an alarm does not sound, it is not normal operation, so check out what is listed below.
  - 1) Check all connections are made properly?
  - 2) Is the interval of sensor's sensing distance attached within 1mm?
  - 3) Is the limit sensor installed within the interference range between axis and mechanism?
  - 4) Is the origin sensing dog (Magnet) attached to the carrier free of error (Damage, Polarity)?
  - 5) Are the limit sensor (CW, CCW) specifications accurate (Normal B contact)?
  - 6) Are the origin sensor specifications accurate (Normal A contact)?
  - 7) Is I/O contact accurately set to the parameter?


#### ■ Poor operation of the origin sensor

NO	Cause	Troubleshooting
1	Large interval between proximity sensor(Reed S/W) and magnet	Adjust the interval of a proximity sensor (Rees S/W). (1mm)
2	Damage to proximity sensor (Reed S/W)	Replace the proximity sensor (Reed S/W).
3	Origin parameter incorrectly set	Set the origin parameter again.




# ch.15 TEACH PENDANT MENU TREE

## 15.1 MAIN MENU






#### 15.2 ROBOT MENU






## 15.3 PLC MENU






#### 15.4 PARAMETER MENU






#### 15.5 VIEW MENU






# ch.16 Description of Operating Modes per Function

## 16.1 Initialization Setting Mode (Hidden Initial Mode)









# Step 3-3. Initialize parameter setting < 0/1>

Do you want

Current and FRAM

Parameter initial?

NO YES

Select YES to initialize parameter setting.

#### Step 3-5. Initialize JOB setting <1/1>

Do you want

JOB Initial?

NO YES

Select YES to initialize the whole JOB program.

Step 3-6.

#### Initialize PLC setting<1/1>

Do you want

PLC Initial?

NO YES

Select YES to initialize the whole PLC program.

F2


F2

F2



# ch.17 Front 7-Segment Display

#### 17.1 Normal Condition






#### 17.2 Alarm Occurrence

- Description: In the event of an alarm, it is displayed as shown in the figure below, indicating a 2-digit main alarm and a 2-digit detailed alarm.
  - . For alarm codes and description, refer to page 3-30.
  - ex) When E01.01  $\rightarrow$  IPM alarm occurs.



## 17.3 During Robot Program Operation

Description: When the robot program is running, this displays the current step number.



(Step no. 32 currently running)





### 17.4 Display by Setting User Mode Parameter

17.4.1 Display Input Contact when User Mode Parameter is '200'

#### ■ Input contact range for parameter setting

- 1) Input contact range values
  - B000, B001, B002, B003, B004, B005 B006, B007
     B010, B011, B012, B013, B014, B015, B016, B017
     B020, B021, B022
- 2) Positions of input contacts displayed on 7-segment
  - Displayed from top-right B000 on 7-segment toward the left to B007, also displaying from bottom-right B010 toward the left to B017 and from B020 at bottom-right toward the left to B022, showing a total of 19 contacts from B000 to B022.









- 17.4.2 Display Output Contact when User Mode Parameter is '201'
- 1) Output contact range values
  - B030, B031, B032, B033, B034, B035 B036, B037
     B040, B041, B042, B043, B044, B045, B046, B047
- 2) Positions of output contacts displayed on 7-segment
  - 16 contacts are displays starting from top-right B030 on 7-segment toward the left to B037, also starting at bottom-right B040 toward the left to B047.
- Description: Output is made to 7-segment according to values for input contact range.

  B037
  B047
  B040




17.4.3 Display DC LINK Voltage when User Mode Parameter is '202'






# ch.18 External-look Dimension Drawing

■ Small capacity (RCS-8001C ~ 8004C) external look and dimension






### ■ Medium capacity (RCS-8008 ~ 15C) external look and dimension





### ch.19 Cable

## 19.1 Configuration of Robot Cable Model



19-1




# 19.2 Robot Cable Type

Туре	Type of controller side	Type of motor side	Configuration
RAK1 Robot Cable		STRAIGHT/ELBOW	ENCODER BATTERY
	CN1(20pin)	HOUSING	MOTOR SENSOR BRAKE
RCK Robot Cable	STRAIGHT/ELBOW	encoder Motor	
		HOUSING	SENSOR BRAKE



## 19.2.1 RAK1 Robot Cable (STRAIGHT/ELBOW Type)



#### **■** B Connector of motor side


DINI NI -	Signal		
PIN No	INC	ABS	
1	P5V	P5V	
2	G5V	G5V	
3	PS	PS	
4	/PS	/PS	
5	CW	-	
6	CCW	-	
7	P24V	-	
8	G24V	-	
9	ORG	-	
10	BRK+	BRK+	
11	BRK-	BRK-	
12	FG(ENC)	FG(ENC)	
13	FG(MOTOR)	FG(MOTOR)	
14	U	U	
15	V	V	
16	W	W	

### ■ A CN1 Connector of Controller side

PIN No	Signal	PIN No	Signal
1	PS	11	-
2	/PS	12	SHIELD
3	-	13	-
4	-	14	-
5	-	15	-
6	-	16	-
7	-	17	-
8	-	18	-
9	G5V	19	P5V
10	-	20	-



#### 19.2.2 RAK1 Robot Cable (HOUSING Type)



#### **■** ① ENCODER Connector

PIN No	Signal	PIN No	Signal
1	BAT+	6	-
2	BAT-	7	P5V
3	FG	8	G5V
4	SD	9	-
5	/SD		

#### **■** (1-1) BATTERY Connector

PIN No	Signal
2	BAT-
1	BAT+

#### ■ ② MOTOR Connector

PIN No	Signal	PIN No	Signal
1	U	3	W
2	V	4	FG

#### **■** ③ SENSOR Connector

DYNI NI -	Signal		
PIN No	NX	PX	
1	P24V	G24V	
2	G24V	P24V	
3	CW	CW	
4	CCW	CCW	
5	ORG	ORG	
6	=	-	

#### **■ 4** BRAKE Connector


PIN No	Signal
1	BRK+
2	BRK-



The battery connector is used for the absolute type controller and added to the housing type.



## 19.2.3 RCK1 Robot Cable (STRAIGHT/ELBOW Type)



### ■ B (Connector of motor side)


PIN No	Signal	PIN	No	Signal
1	P5V	1	7	/CW
2	-	1	8	/CCW
3	G5V	19	NX	24V
4	-	19	PX	G24
5	А	20	NX	G24
6	/A	20	PX	24V
7	U	21		/ORG
8	/U	2	2	BRK+
9	В	2	3	-BRK-
10	/B	2	4	FG
11	V	-		-
12	/V	А		U
13	Z	В		V
14	/Z	С		W
15	W	D		FG
16	/W	-		_


### ■ A (CN1 Connector of controller side)


PIN No	Signal	PIN No	Signal
1	W	11	/Z
2	/W	12	SHIELD
3	V	13	/B
4	/V	14	Z
5	U	15	/A
6	/U	16	В
7	-	17	-
8	-	18	А
9	G5V	19	P5V
10	-	20	-





## 19.2.4 RCK1 Robot Cable (HOUSING Type)











#### ■ ① Motor Connector

PIN No	Signal	PIN No	Signal
1	U	3	W
2	V	4	FG

#### ■ ② Encoder Connector

PIN No	Signal	PIN No	Signal
1	А	9	V
2	/A	10	/V
3	В	11	W
4	/B	12	/W
5	Z	13	P5V
6	/Z	14	G5V
7	U	15	-
8	/U	CASE	SHIELD

#### ■ 3 Sensor Connector

PIN	Signal		
No	NX	PX	
1	P24V	G24V	
2	G24V	P24V	
3	CW	CW	
4	CCW	CCW	
5	ORG	ORG	
6	-	=	

#### **■ ④** BRAKE Connector

PIN No	Signal
1	BRK+
2	BRK-



## 19.2.5 Serial Cable (RS 232C)

## ■ COM1

Signal	9pin connector of PC side	15pin connector of Serial side	
RxD – TxD	2 (RxD)	3 (TxD)	
TxD – RxD	3 (TxD) ————	2 (RxD)	
GND	5	<del></del> 5	
DTR. DSR	No. 4. 6 short circuit		
RTS. CTS	No. 7. 8 short circuit	-	
SHILED	Connector conductor		

### ■ COM2

Signal	9pin connector of PC side	15pin connector of Serial side	
RxD – TxD	2 (RxD)	10 (TxD2)	
TxD – RxD	3 (TxD) ————	9 (RxD2)	
GND	5	5	
DTR. DSR	No.4 6 short circuit		
RTS. CTS	No. 7. 8 short circuit	-	
SHILED	Connector conductor		



#### ch.20 PC Communication

#### 20.1 Protocol

- The Data format to send to a Controller is as follows.
  - 1) You have to select and input MY\_ID among 1~255 in the PARA-ETC mode of a controller to communicate with RS-485. (MY\_ID is currently not implemented.)
  - 2) If the MY\_ID number is "0", RS-232 communication is available with REMOTE terminal. But No RS-485 communication by the RS-485 communication terminal at this time. (Currently not implemented.)

#### **■** Protocol format

- 1) The Protocol is the same to the Protocol used in the UniHost but the ID information should be inserted in the communication Data to communicate with RS-485.
- 2) ID format: ID header + ID No.

ID header :  $'\#'(ASCII\ code) - 1$  Byte data

ID No.:  $1\sim255$ (Decimal) or  $0x01\sim0x20-1$  Byte data

3) RS-485 communication packet is as follows.

Transmission shaft	STX	ID header	ID No.	DATA	ETX	LRC	
Reception							ACK
shaft							

STX: 0x02: Starts communication packet.

ETX: 0x03: Ends communication packet.

ACK: 0x06: Transmitted from the reception side when the received packet data and LRC value are not consistent.

NAK: 0x15: When the received packet data and LRC value are not consistent.

RST: 0x12: When communication time limit has been exceeded.

4) How to calculate LRC (exclusive-OR except STX, LRC)

LRC = [ID header]^[ID No.]^DATA[0]^DATA[1]^....^DATA[N]^ETX

5) If the value of LRC is 0, ETX.

Ex)Select and read position, integer data in the controller.(In case  $Y_{ID} = 1$ )



- 6) Number of the position or integer(3 bytes) + position or integer variable(3 bytes) -4 bytes
- 7) 0x30(OK flag)
- 8) DATA: Data that stored in the position or interger variable.



## ch.21 Cautions on installing Servo Motor

### 21.1 Check item when the goods arrives

- Please check item when the goods arrives as bellows.
  - 1) Confirm in the NAME PLATE of Motor whether the goods accords with the ordered product or not.
  - 2) Confirm the appearance where there is trouble or not.
  - 3) Confirm a MOTOR whether the output axis rotates softly by hand or not. (But, if does not rotate in attaching with BRAKE)
  - 4) Confirm whether the connection part of screw loses or not.
  - 5) If there is the above problem, contact our company.

#### 21.2 Measures before the installation

■ Since the paint against rust is painted during preservation in the axis part or FLANGE part of AC SERVO MOTOR, wipe this with the thinner before installation at this time, be careful lest other part the thinner should smear.

### 21.3 Selection good place to install

- Generally, it makes it a rule to install indoors. use it in the following circumstance.
  - 1) The place where there is no corrosive and explosive GAS.
  - 2) The palce where the temperature is  $0\sim +40^{\circ}$ C.
  - 3) The place where it is well ventilated, dust or mote and humidity are few.
  - 4) The place where it is easy to clean and check.
  - AC SERVO MOTOR can be protected form little oil and water by the basic structure. Howerve, in case of using it in a lot of water and oil, work out a counter measure by attaching with the extra COVER.




#### 21.4 Use circumstance

Neighboring temperature : 0~40°CPreservation temperature : -20~+80°C

■ Humidity: 80%RH(Max)

### 21.5 Combination with the opposite machinery

- It is important to accord the axis center of MOTOR axis and opposite machinery. Otherwise, it will cause vibration and it is possible to damage the BEARING.
- If installing the COUPLING, relieve the shock lest the excessive power should act on axis and BEARING by using the rubber hammer.(see Figure 1)
- Figure1.



#### 21.6 Allowable laod of BEARING

Be careful lest the excessive RADIAL load, THRUST load should be given to AC SERVO MOTOR



### 21.7 Check item when testing the operation

- Check the following items before the test operation.
  - 1) Whether the connection with machinery and equipment, wiring, FUSE, grounding is done well or not
  - 2) Where the each connection has the looseness or not
  - 3) Whether in case of the attachment type with OIL-SEAL, it is damaged or the oil is given to it, or not

If the above should occur, take a proper measure immediately. Also during the test operation, AC SERVO MOTOR should be operated without load to prevent from the unexpected accident. Unavoidably, in case of the test operation with opposite machinery, operate it in a condition that the emergency stop is possible

#### 21.8 Maintenance and Inspections

- The maintenance of AC SERVO MOTOR is enough with the ordinary simple check because there is no abrasion. See the below table.
- Check this in proper time according to the use circumstance and condition, since the check time in the table is reference.
- Also, do not disjoint AC SERVO MOTOR. Unavoidably, in case of the disjoint, call our company.

M & I	Check time	Check and cleaning Method	Remarks
Vibration and noise	Every day	By the sense of touch and hearings	The change and increase of level should not be existed comparing to the ordinary times
Appearance	Depends on the stain and damage	Clean with a piece of cloth and an air	
Insulation resistance	Every year Lose the contact with the control layer and measure the terminal with 500 V Megger		Refer to our company in case of less than $10 \mbox{M}\Omega$
OIL-SEAL	5,000 Hours	Check the state of damage by separating it from the machinery	The exchange is necessary in case of the damage
Overall check	20,000 Hours or 5 year	Contact to our company.	Exchange and clean



### 21.9 Problem and Measures

■ In case when the trouble occurred during the operation, treat a trouble properly with the method of the below table. In case when the trouble is not revised despite the examination and measure as below, call our company.

Symptom	Cause	Inspection Technique	Troubleshooting	
	The Motor terminal voltage declined	Measure the Motor Lead terminal by TESTER	Rated voltage.  Change the Motor in case of	
	Inferiority of motor	terrifical by TESTER	rated voltage.	
A Motor does not work	Excessive heavy load	Driving with no load.	In case when the Motor is oper- rated, reduce the load or replace with big capacity Motor.	
	Connection is loosed Failure of external wiring	Check the connection by a screw drive, check the wiring.	Tighten up the loosed part, wire correctly with consulting the connection chart.	
The rotation is not stable	Inferiority of Connection	Check the contact of Motor LEAD terminal.	Maintenance the wrong part.	
	The neighboring temperature is high	Confirm whether the neighboring temperature is less than 40°C or not.	Confirm whether the neighboring temperature is less than 40°C or not.	
The Motor is overheated	The surface of Motor is stained	Confirm whether other substance is attached on the surface of Motor or not.		
	The excessive load is carried	Driving with no load.	In case when the Motor is operated, reduce the load or replace with big capacity Motor.	
The unusal	Inferiority of installation	Check the stat of screw tightness in the installation part and the concentric degree in the connection part	Tighten the screw and revise the wrongly passing in the connection part	
sound is occurred	The trouble of BEARING	Inspect the gap near the Bearing and the vibration	Contact to our company.	
	Vibration from a relative machine	Check the mechanical moving part for damage or transformation due to foreign material intrusion.	Contact the machine maker.	



Rev.	Date of Revision	Content	Revised by	S/W Version
V		First Edition Prints		

# RCS8000 ROBOT CONTROLLER

# **CONTROLLER MANUAL**

FIRST EDITION JULY 2015 ROBOSTAR CO, LTD ROBOT R&D CENTER